

Radio Cassette Player

Operating Instructions/使用说明书



WM-FX890

©2003 Sony Corporation Printed in China



http://www.sony.net/

"WALKMAN" is a registered trademark of Sony Corporation to represent Headphone Stereo products.

WALKMAN is a trademark of Sony Corporation.

The validity of the CE marking is restricted to only those countries where it is legally enforced, mainly in the countries EEA (European Economic Area). CE 标志的有效性, 仅限于那些有法律限制的国家, 主要在 EEA (欧洲经济区) 国家。

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.


Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

警告



为防火灾或触电危险, 切勿让机器暴露于雨中或潮湿处。

别把机器安装在例如书橱或壁柜等密闭不通风的地方。


A





B



C



D



- * There is a tactile dot beside VOL on the main unit to show the direction to turn up the volume.
- ** The button has a tactile dot.
- 在主机上 VOL 旁边有一个触感圆点, 表示转大音量的方向。
- ** 按钮带有突起圆点。

English

- To prevent fire, do not cover the ventilation of the apparatus with newspapers, table-cloths, curtains, etc. And don't place lighted candles on the apparatus.
- To prevent fire or shock hazard, do not place objects filled with liquids, such as vases, on the apparatus.
- Certain countries may regulate disposal of the battery used to power this product. Please consult with your local authority.

Preparations

Prepare a dry battery (not supplied) or the rechargeable battery (supplied).

Dry Battery [A]

Attach the supplied battery case, and then insert one R6 (size AA) battery with correct polarity.

Note

For maximum performance we recommend that you use a Sony alkaline battery.

Rechargeable Battery [B]

Charge the rechargeable battery before using it for the first time.

- 1 Insert the supplied rechargeable battery NH-14WM (A) into the rechargeable battery compartment with correct polarity.
- 2 Connect the supplied AC power adaptor to the charging stand, plug in the AC power adaptor to the house current (mains).
- 3 Place the main unit on the charging stand. The CHG lamp will light up during charging. Full charging takes about 6 hours regardless the battery power remaining. The CHG lamp will go off when the battery is fully charged.

Notes

- This charging stand charges the rechargeable battery based on a timer. If you remove the unit from the charging stand while it is charging, the timer will be reset and full charging will take about 6 hours when you place the unit on the charging stand again.
- You can use the unit before the CHG lamp goes off, but in that case, battery life will be shorter depending on the charging time.

- Do not use the unit while it is charging. Remove the unit from the charging stand when using it.
 - If you operate the unit while it is charging, the battery will not be charged.
 - If you operate the unit while it is charging, this may cause a malfunction.
- Do not place the unit on the charging stand without the rechargeable battery. Otherwise, this may cause malfunction.

When to replace/charge the battery [C]

Replace or charge the battery when " " flashes in the display.

Battery life* (Approx. hours)	Sony alkaline LR6 (SG)**
Tape playback	50
Radio reception	56

Rechargeable battery NH-14WM (A)	Rechargeable NH-14WM (A)
Tape playback	30
Radio reception	34

Sony alkaline LR6 (SG)** and Rechargeable NH-14WM (A)	Sony alkaline LR6 (SG)** and Rechargeable NH-14WM (A)
Tape playback	80
Radio reception	90

- * Measured value by the standard of JEITA (Japan Electronics and Information Technology Industries Association). (Using a Sony HF series cassette tape)
- ** When using a Sony LR6(SG) alkaline dry battery (produced in Japan).

Notes

- The battery life may be shorter depending on the operating condition, the surrounding temperature and battery type.
- The AVLS setting (see "Using the Menu") will be cancelled when you replace the battery.

Playing a Tape [D]

- 1 Insert a cassette and if the HOLD function is on, slide the HOLD switch in the opposite direction of the arrow to unlock the controls.
- 2 Press ◀▶•REPEAT on the main unit and adjust the volume with VOL. (On the remote control, press ▶◀(play)•■(stop).)

When adjusting the volume on the remote control Set the VOL control on the main unit to around 6.

When adjusting the volume on the main unit Set the VOL control on the remote control at maximum.

Operation on the remote control

To	Press
Switch playback to the other side	▶◀•■ for 2 seconds or more during playback
Stop playback	▶◀•■ once during playback

Repeat the current track (Repeat Single Track function) ▶◀•■ twice during playback
To stop a single repeat, press ▶◀•■ once.

Fast forward*	FF + during stop
Rewind*	REW - during stop

Search forward during playback (CUE) Press and hold FF + and release it at the point you want

Search backward during playback (REVIEW)	Press and hold REW - and release it at the point you want
Play the next track/succeeding 9 tracks from the beginning (AMS**)	FF + once/ repeatedly during playback

Play the current track/previous 8 tracks from the beginning (AMS**)	REW - once/ repeatedly during playback
Play the other side from the beginning (Skip Reverse function)	FF + for 2 seconds or more during stop

Play the same side from the beginning (Rewind Auto Play function)	REW - for 2 seconds or more during stop
---	---

Operation on the main unit

To	Press
Switch playback to the other side	▶◀•REPEAT during playback
Stop playback	■ (stop)

Repeat the current track (Repeat Single Track function) ▶◀•REPEAT for 2 seconds or more during playback
To stop a single repeat, press ▶◀•REPEAT once.

Fast forward*	FF/CUE during stop
Rewind*	REW/REVIEW during stop

Search forward during playback (CUE) Press and hold FF/CUE and release it at the point you want

Search backward during playback (REVIEW) Press and hold REW/REVIEW and release it at the point you want

Play the next track/ succeeding 9 tracks from the beginning (AMS**) FF/CUE once or repeatedly during playback

Play the current track/ previous 8 tracks from the beginning (AMS**) REW/REVIEW once or repeatedly during playback

Play the other side from the beginning (Skip Reverse function) FF/CUE for 2 seconds or more during stop

Play the same side from the beginning (Rewind Auto Play function) REW/REVIEW for 2 seconds or more during stop

* Press ▶◀•REPEAT (on the remote control, press ▶◀•■) during fast forward or rewind to start playback.

**Automatic Music Sensor

To skip a long blank space (BL SKIP* function)

On the remote control:
1 Press MODE repeatedly to show "BL SKIP".

On the main unit:
1 Press MENU repeatedly to set " " (the cursor) in the display to BL SKIP.
2 Press SET to show " ".

* When the BL SKIP function is on, the tape is fast-forwarded to the next track if there is a blank space longer than 12 seconds.

(turn over)

中文

- 为防止火灾, 请勿让报纸、桌布、窗帘等盖住装置的通风孔。也不可把点燃的蜡烛放在装置上。
- 为防止火灾或触电的危险, 请勿将装满液体的物体, 例如花瓶等放在装置上。
- 一部分国家对本产品的电源用电池的处置, 可能有所规定。此请询问当地有关当局。

准备工作

准备干电池 (无附带) 或充电式电池 (附带)。

干电池 [A]

安装附带的电池盒, 然后按正确极性装入一节 R6 (AA) 电池。

注 为获得最佳效果, 建议您使用 Sony 牌碱性电池。

充电式电池 [B]

充电式电池在第一次使用前, 必须加以充电。

- 1 以正确极性将附带的充电式电池 NH-14WM (A) 装入充电式电池室。
- 2 将附带的 AC 电源转接器连接到充电座, 将 AC 电源转接器接到家庭用电源插座 (主电源)。
- 3 把主机放在充电座上。在充电期间, CHG 灯将点亮。无论电池是否有剩余电量, 完全充电需时大约 6 小时。当电池完全充满电时, CHG 灯将熄灭。

注

- 充电座根据定时器为充电式电池充电。如果在充电时将本机从充电座上卸下, 定时器将复位, 并且当您把本机重新放在充电座上时, 完全充电需时大约 6 小时。
- 您可以在 CHG 灯熄灭之前使用本机, 但是在这种情况下, 电池工作时间将较短, 具体取决于充电时间。
- 充电中, 请勿使用本机。要使用本机, 须把它从充电座上卸下。- 如果在充电时操作本机, 便不会充电。- 如果在充电时操作本机, 便可能引起故障。
- 请勿在没有安装充电式电池的情况下把本机放在充电座上。否则, 便可能引起故障。

何时更换电池/给电池充电 [C]

" " 在显示窗中闪烁时, 即请更换电池或给电池充电。

电池寿命* (大约时数)	Sony 碱电池 LR6 (SG)**
录音带收音	50
听收音机	56

充电式电池 NH-14WM (A)	充电式电池 NH-14WM (A)
录音带收音	30
听收音机	34

同时使用 Sony 碱电池 LR6 (SG)** 和充电式电池 NH-14WM (A)	同时使用 Sony 碱电池 LR6 (SG)** 和充电式电池 NH-14WM (A)
录音带收音	80
听收音机	90

- * 按 JEITA (Japan Electronics and Information Technology Industries Association) 标准测定的值。(使用 Sony HF 系列磁带)
- **使用 LR6 (SG) 型 Sony 碱电池 (日本制) 时。

注 • 电池寿命可能因操作条件、环境温度 and 电池类型而缩短些。
• 当更换电池时, AVLS 设定 (参见 "使用项目单") 将被取消。

播放录音带 [D]

- 1 装入盒带, 如果遥控器的 HOLD 功能仍开着, 即请沿相反于箭头方向滑动 HOLD 开关以释放控制钮。
- 2 按主机上的 ▶◀•REPEAT 并用 VOL 调节音量。(在遥控器上, 则请按 ▶◀(放音) •■(停止) 。

在遥控器上调节音量时 请把主机上的 VOL 控制钮设定于 6 左右。

在主机上调节音量时 请把遥控器上的 VOL 控制钮设定于最大。

在遥控器上的操作

要	请按
换播放另一面	播放中按 ▶◀•■ 2 秒以上
停止播放	播放中按一次 ▶◀•■

反复播放当前曲子 (反复播放单首曲子功能) 播放中按两次 ▶◀•■
要停止单曲反复播放, 请按一次 ▶◀•■。

快进绕* 停止中按 FF +
重绕* 停止中按 REW -

播放期间向前 按住 FF +, 在搜索 (CUE) 所要的点上释放

播放期间向后搜 按住 REW -, 在搜索 (REVIEW) 所要的点上释放

从头播放下一首 播放中按 FF + 一曲子/接下 9 首 次/多次 曲子 (AMS**)

从头播放当前曲子 (AMS**) 播放中按 REW - 子/前面 8 首 一次/多次 曲子 (AMS**)

从头播放另一面 停止中按住 FF + (跳越倒绕功 并保持 2 秒以上 能)

从头播放同一面 停止中按住 (重绕自动播放 REW - 并保持 2 秒以上 功能)

在主机上的操作

要	请按
换播放另一面	播放中按 ▶◀•REPEAT
停止播放	按 ■ (停止)

反复播放当前曲子 (反复播放单首曲子功能) 播放中按住 ▶◀•REPEAT 并保持 2 秒以上

要停止单曲反复播放, 请按一次 ▶◀•REPEAT。

快进绕* 停止中按 FF/CUE

重绕* 停止中按 REW/REVIEW

播放期间向前 按住 FF/CUE, 在所 要的点上释 放

播放期间向后 按住 REW/ REVIEW, 在所 要的点上释 放

从头播放下一首 播放中按 REW/ 曲子/前面 8 首 一次或 多次 曲子 (AMS**)

从头播放当前 播放中按 REW/ 曲子/前面 8 首 一次或 多次 曲子 (AMS**)

从头播放另一面 停止中按住 FF/ (跳越倒绕 CUE 并保持 2 秒 以上 功能)

从头播放同一面 停止中按住 REW/ (重绕自动播放 REVIEW 并保持 2 秒以上 功能)

* 在快进绕或重绕时, 按 ▶◀•REPEAT (在遥控器上按 ▶◀•■) 开始播放。
**自动乐曲探测

要跳越长空白区 (BL SKIP* 功能)


在遥控器上:
1 反复按 MODE 以显示 "BL SKIP"。

在主机上:
1 反复按 MENU 把显示窗中的 " " (光标) 设为 BL SKIP。
2 按 SET 以显示 " "。


* 当 BL SKIP 功能起作用时, 如果空白区时长超过 12 秒, 磁带将快进到下一首曲子。

(接反面)


E



F



G



English

Listening to the Radio

- Press RADIO ON/BAND to turn on the radio.
- Press RADIO ON/BAND repeatedly to select AM or FM.
- Press MENU on the main unit repeatedly and set the cursor in the display to TUNE MODE.

For manual tuning

- Press SET to choose MANUAL.
- Press TUNE/PRESET + or - repeatedly to tune in to the desired station. Hold down TUNE/PRESET + or - for a few seconds to scan for stations.

For preset tuning

- Press SET to choose PRESET.
- Press TUNE/PRESET + or - repeatedly to recall the desired preset station.

To use preset tuning, preset stations first (see "Presetting Radio Stations").

To turn off the radio

Press RADIO OFF.

To improve the broadcast reception

- For AM:** Reorient the unit itself.
- For FM:** Extend the remote control cord (antenna). If the reception is still not good, press MENU repeatedly to set the cursor in the display to FM MODE. Then press SET to choose from "MONO" (monaural), "LOCAL*" or none (stereo) for best reception. * Excluding European, Saudi Arabian, and Chinese models

To operate from the remote control

To turn on the radio, press RADIO ON/BAND•OFF for more than 1 second (while the tape is in stop mode only). To select the band, press RADIO ON/BAND•OFF for more than 1 second while the radio is on. To tune in or recall a preset station, press FF + or REW -. To turn off the radio, press RADIO ON/BAND•OFF.

Presetting Radio Stations

You can preset up to 30 stations—20 for FM and 10 for AM (for the JPN area*, up to 16 stations—8 for FM and 8 for AM).

* Only if available. See "Receiving Stations Outside Your Country/Region".

Presetting Automatically Scanned Stations

- Press RADIO ON/BAND to turn on the radio.
- Press RADIO ON/BAND repeatedly to select AM or FM.
- Press and hold ENTER for more than 3 seconds.

Preset number 1 will flash in the display and the main unit starts scanning the stations from the lower frequencies and stops for about 5 seconds when a station is received.

- If you wish to preset the currently received station, press ENTER while the preset number is flashing. The received station is preset on preset number 1 and the unit starts scanning for the next receivable station.
- Repeat step 4 until all receivable stations are preset.

To stop scanning

Press RADIO OFF. The radio is turned off at the same time.

Notes

- If stations are already stored, the newly preset stations replace the old ones when the above procedure is completed.
- If stations cannot be preset automatically, preset them manually.

Presetting Stations Manually

- Press RADIO ON/BAND to turn on the radio.
- Press RADIO ON/BAND repeatedly to select AM or FM.
- Press ENTER.

The frequency digits will flash in the display.

- While the frequency digits are flashing, tune in to a station you wish to store using TUNE/PRESET + or - and press ENTER.

The preset number will flash in the display.

- While the preset number is flashing, select the preset number you want using TUNE/PRESET + or - and press ENTER.

Notes

- If you cannot complete step 4 or 5 while the indicators are flashing, repeat from step 3.
- If a station is already stored, the new station replaces the old one.

Playing the Preset Radio Stations

- Press RADIO ON/BAND to turn on the radio.
- Press RADIO ON/BAND repeatedly to select AM or FM.
- Press MENU repeatedly to set the cursor in the display to TUNE MODE. Then press SET to display "PRESET".

- Press TUNE/PRESET + or -.

To cancel a stored station

- Follow the procedure above and in step 4, select the preset number you want to cancel and then press ENTER. The frequency digits will flash in the display.
- Press and hold TUNE/PRESET + or -. The frequency digit starts running up or down. Keep holding down the button until "----" is displayed.
- Press ENTER while "----" is flashing. A preset number will flash in the display.

- Press ENTER to cancel the stored station.

Scanning the Preset Radio Stations — DAPS (Digital Auto Preset Scanning)

- Press RADIO ON/BAND to turn on the radio.
- Press RADIO ON/BAND repeatedly to select AM or FM.
- Press and hold RADIO ON/BAND for 2 seconds or more.

The preset stations of the selected band will be played for about 5 seconds each. (During DAPS the indicators in the display flash.)

- Press RADIO ON/BAND again to select the station while the desired preset station is being played.

Notes

- If there are no stations stored, the DAPS function does not work.
- Until a station is selected in step 4, the DAPS function turned on in step 3 will continue.

Receiving Stations Outside Your Country/Region (Excluding European, Saudi Arabian, and Chinese models)

- Press RADIO ON/BAND to turn on the radio.
- Press ENTER.

The frequency digits will flash in the display.

- Press and hold RADIO ON/BAND until "Eur", "USA" or "JPN" flashes.
- Press RADIO ON/BAND repeatedly to select "Eur", "USA" or "JPN" and press ENTER.
- Tune in to and store stations as necessary following the procedure of "Listening to the Radio" and "Presetting Radio Stations".

Area indication and frequency range

Area*	Frequency range FM (MHz)	AM(kHz)
Eur	87.5 - 108	531 - 1 602
USA	87.5 - 108	530 - 1 710
JPN	76.0 - 90.0	531 - 1 710

* Eur : European and other countries/regions
USA : USA, Canada, and Central and South America
JPN: Japan

To cancel the AVLS function

On the remote control: Hold down MODE again for more than 3 seconds until "AVLS" disappears.

On the main unit: Press SET so that "AVLS" disappears from the display.

Using the Menu

Adjusting Playback Modes

On the remote control: Press MODE repeatedly. With each press, the indications change.

On the main unit: Press MENU repeatedly to set the cursor in the display to PB MODE. Then press SET to select the desired mode.

To play

both sides repeatedly

both sides once from the FWD side

Emphasizing Sound

On the remote control: Press SOUND repeatedly. With each press, the indications change.

The indications change as follows:

- RV : Sound Revitalizer Emphasizes treble sound.
- MB : Mega Bass Emphasizes bass sound (moderate effect).

GRV : Groove Emphasizes bass sound (strong effect).
no message : normal (no effect)

On the main unit:

- Press MENU repeatedly to set the cursor in the display to SOUND.
- Press SET repeatedly to select the sound emphasis of your choice.

Note

If the sound is distorted with the mode "GRV", turn down the volume of the main unit or select other modes.

Protecting Your Hearing — AVLS (Automatic Volume Limiter System)

The maximum volume is kept down to protect your ears.

On the remote control: Hold down MODE for more than 10 seconds until "AVLS" appears in the display.

On the main unit: Press MENU repeatedly in the playback, stop or radio mode to set the cursor in the display to AVLS. Then press SET to show "AVLS".

To cancel the AVLS function

On the remote control: Hold down MODE again for more than 3 seconds until "AVLS" disappears.

On the main unit: Press SET so that "AVLS" disappears from the display.

Using Other Functions

Adjusting the Tape Playback Speed

You can adjust the playback speed using SPEED CONTROL. Turn SPEED CONTROL to: - (slow) to play back at a slower speed. Center position to play back at normal speed. + (fast) to play back at a faster speed.

Locking the Controls — HOLD Function

Slide the HOLD switch in the direction of the arrow to lock the controls of the main unit (except SPEED CONTROL) or the remote control.

Emphasizing Sound

On the remote control: Press SOUND repeatedly. With each press, the indications change.

The indications change as follows:

- RV : Sound Revitalizer Emphasizes treble sound.
- MB : Mega Bass Emphasizes bass sound (moderate effect).

- The charging stand and the rechargeable battery may become warm during charging, but this is not a problem.
- Do not tear off the film on the rechargeable battery.
- Use only the supplied charging stand to charge the supplied rechargeable battery.
- Be sure not to short-circuit the battery. When you carry it with you, use the supplied carrying case. If you are not using the case, do not carry the battery with other metallic objects such as keys, rings in your pocket.
- If the rechargeable battery is new or has not been used for a long time, it may not be charged completely until you use it several times.

On batteries

- Do not charge a dry battery.
- Do not carry the dry or rechargeable batteries with coins or other metallic objects. It can generate heat if the positive and negative terminals of the batteries are accidentally contacted by a metallic object.
- When you are not going to use the main unit for a long time, remove the battery to prevent any damage from battery leakage and corrosion.

On AC power adaptor

Use only the supplied AC power adaptor (for charging stand). Do not use any other AC power adaptor.

Polarity of the plug

- Connect the AC power adaptor to an easily accessible AC outlet. Should you notice an abnormality in the AC power adaptor, disconnect it from the AC outlet immediately.
- Do not touch the AC power adaptor with wet hands.

On handling

- Do not leave the unit in a location near heat sources, or in a place subject to direct sunlight, excessive dust or sand, moisture, rain, mechanical shock, or in a car with its windows closed.
- We do not recommend the use of tape longer than 90 minutes. They are very thin and tend to be stretched easily. This may cause malfunction of the unit or sound deterioration.
- The LCD display may become hard to see or slow down when using the unit at high temperatures (above 40°C/104°F) or at low temperatures (below 0°C/32°F). At room temperature, the display will return to its normal operating condition.
- If the unit has not been used for long, set it in the playback mode to warm up for a few minutes before you start using again.

On the remote control

Use the supplied remote control only with this unit.

On headphones/earphones

Do not use headphones/earphones while driving, cycling, or operating any motorized vehicle. It may create a traffic hazard and is illegal in some areas. It can also be potentially dangerous to play your headphones/earphones at high volume while walking, especially at pedestrian crossings. You should exercise extreme caution or discontinue use in potentially hazardous situations.

Preventing hearing damage

Do not use headphones/earphones at high volume. Hearing experts advise against continuous, loud and extended play. If you experience a ringing in your ears, reduce volume or discontinue use.

Caring for others

Keep the volume to a moderate level. This will allow you to hear outside sounds and to be considerate to the people around you.

On maintenance

- Clean the tape head and tape path, using a cotton swab and commercially available cleaning solvent after every 10 hours of use.
- To clean the exterior, use a soft cloth slightly moistened in water. Do not use alcohol, benzine or thinner.
- Clean the headphones/earphones and remote control plugs periodically.
- Clean the battery case terminals (both inside and outside) and the terminals periodically with a cotton swab or soft cloth as illustrated.

Troubleshooting

The sound drops out or comes with excessive noise.

Clean the headphones/earphones and remote control plugs.

The unit does not operate at all.

Charge the battery or replace the dry battery with a new one.

HOLD is activated. Deactivate HOLD.

Tape operation is not possible.

Insert a cassette tape.

The volume cannot be turned up.

If AVLS is on, turn it off.

The display and the operations are not normal.

Remove the power sources for 15 seconds or more, and then set them again.

Specifications

Radio section

Frequency range
FM: 76.0 - 90.0 MHz (Japan)
87.5 - 108 MHz (other countries/regions)

AM: 531 - 1 710 kHz (Japan)
530 - 1 710 kHz (North, Central, and South America)
531 - 1 602 kHz (other countries/regions)

Tape section
Frequency response
Playback: 40 - 15 000 Hz

Output
Headphones (7) jack
Load impedance 8 - 300 Ω

General
Power requirements
1.5 V
Rechargeable battery
One R6 (size AA) battery

Dimensions (W/H/D)
Approx. 77.1 × 108.0 × 22.5 mm
(3¼ × 4¼ × ¾ inches) excl. projecting parts and controls

Mass
Approx. 153 g (5.4 oz) (main unit only)

Supplied accessories
AC power adaptor (1), Battery case (1) Stereo headphones or earphones with remote control (1), Charging stand (1) Rechargeable battery (NH-14WM)(A), 1.2 V, 1 350 mAh (min), Ni-MH (1) Rechargeable battery carrying case (1) Carrying pouch (1)

Design and specifications are subject to change without notice.

中文

听收音机

- 按 RADIO ON/BAND 打开收音机。
- 反复按 RADIO ON/BAND 选择 AM 或 FM。
- 反复按主机上的 MENU，将显示窗中的光标设定为 TUNE MODE。

- 要手动调台时
① 按 SET 选择 MANUAL。
- 反复按 TUNE/PRESET + 或 - 调入所要的电台。按住 TUNE/PRESET + 或 - 数秒以扫描电台。

要预设电台时
① 按 SET 选择 PRESET。
② 反复按 TUNE/PRESET + 或 - 选出所要的预设电台。要先预设电台（参见“预设电台”）。

- 如果您要预设接收到的电台，请在预设号闪烁着时按 ENTER。
- 重复步骤 4 直至所有可接收电台均被预设。

要关掉收音机时
按 RADIO OFF 键。

要改善广播接收效果时
• 收听 AM 节目时：调转本机方位。

• 收听 FM 节目时：请拉长遥控器导线（天线）。如果接收效果仍不好，请反复按 MENU 将显示窗中的光标设定为 FM MODE。然后按 SET 从 "MONO"（单耳声）、"LOCAL*" 或无（立体声）方式中进行选择以获最佳接收效果。

* 欧洲、沙特阿拉伯和中国型号除外

要从遥控器进行操作时
要打开收音机时，请按 RADIO ON/BAND•OFF 1 秒以上（限当录音带处于停止状态时）。

要选择波段时，请在打开着收音机时，按下 RADIO ON/BAND•OFF 1 秒以上。

要调入或选出预设电台时，按 FF + 或 REW -。

要关掉收音机时，请按 RADIO ON/BAND•OFF。

预设电台

您可以预设多达 30 个电台—20 个 FM 台，10 个 AM 台。（在 JPN 地区*，最多可以预设 16 个台—8 个 FM 台，8 个 AM 台）。

* 如果可以预设，请参见“接收别的国家/地区的电台”。

自动地预设扫描的电台

- 按 RADIO ON/BAND 打开收音机。
- 反复按 RADIO ON/BAND 选择 AM 或 FM。
- 按 ENTER 3 秒钟以上。预设号 1 将在显示屏上闪烁。主机开始从低频段扫描电台，在接收到电台时停止约 5 秒钟。
- 如果您要预设接收到的电台，请在预设号闪烁着时按 ENTER。

接收到的电台即被预设于预设号 1。本机将开始扫描下一个可接收的电台。

停止扫描

按 RADIO OFF，收音机将同时关掉电源。

注

• 如果已预设了电台，当完成上述步骤时，新预设的电台将取代原有的电台。

• 如果电台不能自动预设，请用手动预设电台。

手动预设电台

- 按 RADIO ON/BAND 打开收音机。
- 反复按 RADIO ON/BAND 选择 AM 或 FM。
- 按 ENTER。显示窗中即闪烁着频率数字。
- 当频率数字闪烁时，请用 TUNE/PRESET + 或 - 键调入您想存储的电台，按 ENTER。

注

• 如果没储存电台，DAPS 功能将不起作用。

• 步骤 3 里的 DAPS 功能将继续打开着一直到在步骤 4 里已选择了电台为止。

注

• 如果上述指示灯闪烁时您不能完成步骤 4 或步骤 5，请从步骤 3 开始重复操作。

• 如果已存储有电台，新电台即将取代原有的电台。

播放预设电台

- 按 RADIO ON/BAND 打开收音机。
- 反复按 RADIO ON/BAND 选择 AM 或 FM。
- 反复按 MENU，将显示窗中的光标设定于 TUNE MODE，然后按 SET 以显示 "PRESET"。
- 按 TUNE/PRESET + 或 -。

要取消所储存的电台时

1 按照上述方法而在步骤 4 里选择所要取消的预设号，然后按 ENTER。显示窗中即闪烁着频率数。

2 按住 TUNE/PRESET + 或 -。频率数开始增大或减小。按住该键至显示了 "----"。

3 当闪烁着 "----" 时按 ENTER。显示窗中即闪烁着预设号。

4 按 ENTER 以取消储存的电台。

扫描预设电台 — DAPS (Digital Auto Preset Scanning)

- 按 RADIO ON/BAND 打开收音机。
- 反复按 RADIO ON/BAND 选择 AM 或 FM。
- 按住 RADIO ON/BAND 2 秒以上。

所选波段的预设电台即各播放大约 5 秒。（在 DAPS 当中，显示窗中将闪烁着指示灯。）

- 当播放着所要预设电台时，再按一次 RADIO ON/BAND 以选择电台。

注

• 如果没储存电台，DAPS 功能将不起作用。

• 步骤 3 里的 DAPS 功能将继续打开着一直到在步骤 4 里已选择了电台为止。

接收别的国家/地区的电台

- 按 RADIO ON/BAND 打开收音机。
- 按 ENTER 键。频率数字将闪烁于显示窗中。
- 按住 RADIO ON/BAND 直到 "Eur", "USA" 或 "JPN" 闪烁。
- 反复按 RADIO ON/BAND 选择 "Eur", "USA" 或 "JPN" 并按 ENTER 键。

5 按照“听收音机”和“预设电台”的步骤操作，调入并储存所要的电台。

地区指示和频率范围

地区* 频率范围 FM (MHz) AM (kHz)

Eur 87.5 - 108 531 - 1 602

USA 87.5 - 108 530 - 1 710

JPN 76.0 - 90.0 531 - 1 710

* Eur: 欧洲和其他国家/地区
USA: 美国、加拿大和中美南
JPN: 日本

使用项目单

调整收音方式

在遥控器上:

反复按 MODE，每按一下指示灯即作变化。

在主机上:

请反复按 MENU 把显示器中的光标设定于 PB MODE。然后按 SET 以选择所要模式。

要 请选择

反复按双面

从 FWD 面放一次双面

增强声音

在遥控器上:

1 反复按 SOUND，每按一下，指示灯改变。

指示灯改变如下:

RV: Sound Revitalizer (声音再生器)。

增强低音。

MB: Mega Bass (强低音)。

增强低音 (中等效果)。

GRV: Groove (最佳状态)。

增强低音 (强烈效果)。

无信息：普通 (无效果)。

在主机上:

- 反复按 MENU 把显示器中的光标设定于 SOUND。
- 反复按 SET 以选择所喜欢的声加强模式。

注

• "GRV" 模式时，如果声音失真了，即请转小主机音量或选其他模式。

保护您的听觉 — AVLS (自动音量限制系统)

限制最大音量以保护听力。

在遥控器上:

按住 MODE 10 秒以上，直到显示窗中出现 "AVLS"。

在主机上:

在播放、停止或收音模式中，反复按 MENU 把显示器中的光标设定为 AVLS。然后按 SET 显示 "AVLS"。

要取消 AVLS 功能

在遥控器上:

再次按下 MODE 并保持 3 秒以上，直到 "AVLS" 消失时为止。