

# FM/AM Clock Radio

## Operating Instructions

## DREAM MACHINE

Dream Machine is a trademark of Sony Corporation.

### ICF-C295


Sony Corporation © 1998 Printed in Malaysia


## WARRANTY

## WARNING

To prevent fire or shock hazard,  
do not expose the unit to rain or moisture.



 This symbol is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

 This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

\* The graphical symbols are at the bottom of the unit.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

## Before You Begin

Thank you for choosing the Sony Dream Machine! The Dream Machine will give you many hours of reliable service and listening pleasure.

Before operating the Dream Machine, please read these instructions thoroughly and retain them for future reference.

## Features

- Full power back-up function to keep the clock, the alarm (radio and buzzer) and the radio operating during a power interruption, using a 6F22 battery (not supplied).

## Precautions

- Operate the unit on the power sources specified in "Specifications".
- The name plate indicating operating voltage, etc. is located at the bottom of the unit.
- To disconnect the power cord, pull it out by the plug, not by the cord.
- Do not place the unit on surfaces (rugs, blankets, etc.) or near materials (curtains, draperies) that block the ventilation holes.
- Should anything fall into the unit, unplug the unit and have it checked by qualified personnel before operating it further.
- To clean the casing, use a soft cloth dampened with a mild detergent solution.
- The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.

### Battery Warning

When the unit is to be left unplugged for a long time, remove the battery to avoid undue battery discharge and damage to the unit from battery leakage.

If you have any questions or problems concerning your unit, please consult your nearest Sony dealer.

## IMPORTANT SAFEGUARDS

For your protection, please read these safety instructions completely before operating the appliance, and keep this manual for future reference. Carefully observe all warnings, precautions and instructions on the appliance and described in the operating instructions supplied with the appliance by Sony.

### INSTALLATION

#### Water and Moisture

Do not install the appliance near water: for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.

#### Heat

Do not install the appliance near sources of heat such as radiators, heat registers, stoves, or other appliances that produce heat.

#### Ventilation

Slots and openings in the cabinet and in the back or bottom are provided for necessary ventilation. To ensure reliable and safe operation of the appliance, and to protect it from overheating, these slots and openings must never be blocked or covered.

Do not place the appliance on a bed, sofa, rug or other similar surface which may block the slots and openings.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet, unless proper ventilation is provided.

#### Carts and Stands

Do not install the appliance on an unstable table, shelf, cart or stand. Use only a cart or stand recommended by Sony.

An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

#### Wall or Ceiling Mounting

If your appliance can be mounted to a wall or ceiling, mount it only as recommended by Sony.

### USE

#### Power Source

Connect the appliance to a power supply only of the type described in the operating instructions or as marked on the appliance.

#### Grounding or Polarization

Do not defeat the grounding or polarization feature of the AC power cord. If your AC receptacle will not accept the power cord plug, contact your electrician to install a proper AC receptacle.

#### AC Receptacle

Check to make sure that the AC receptacle holds the power cord plug firmly and securely. If the power cord plug is loose, contact your electrician to replace the defective and unsafe AC receptacle.

#### Power-Cord Protection

Route the power cord so that it is not likely to be walked on or pinched by having objects placed on it, paying particular attention to the plugs, receptacles, and the point where the cord exits from the appliance.

#### When not in use

Unplug the power cord of the appliance from the outlet when left unused for a long period of time.

To disconnect the cord, pull it out by grasping the plug. Never pull the plug out by the cord.

#### Foreign Objects

Be careful that foreign objects and liquids do not enter the enclosure through openings.

#### Cleaning

Clean the appliance only as recommended by Sony.

### ANTENNAS


#### Outdoor Antenna Grounding

If an outdoor antenna or cable system is installed, follow the precautions below.

An outdoor antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can come in contact with such power lines or circuits. WHEN INSTALLING AN OUTDOOR ANTENNA SYSTEM, EXTREME CARE SHOULD BE TAKEN TO KEEP FROM CONTACTING SUCH POWER LINES OR CIRCUITS AS CONTACT WITH THEM IS ALMOST INVARIABLY FATAL.

Be sure the antenna system is grounded so as to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.

#### Antenna Grounding According to the National Electrical Code



### SERVICE

Unplug the appliance from the wall outlet and consult qualified service personnel when:

- the power cord or the plug has been damaged.
- a solid object or liquid has fallen into the cabinet.
- the appliance has been exposed to rain or moisture.
- the appliance does not appear to operate normally or exhibits a marked change in performance.
- the appliance has been dropped, or the enclosure damaged.

Do not attempt to service the appliance beyond that described in the operating instructions. For all other servicing refer to qualified service personnel only.

## Installing the Battery

To keep good time, your Dream Machine needs one 6F22 battery (not supplied), in addition to house current. The battery keeps the clock operating in the event of a power interruption. Before setting the time on your Dream Machine, open the lid at the bottom of the unit, install the battery with correct polarity and then close the lid.

- After a power interruption, the displayed time may not be always correct (it may gain or lose about 10 minutes per hour).

### Knowing When to Replace the Battery

- To check battery power, unplug the AC power cord from the wall outlet and plug it in again after a few minutes. If the displayed time is incorrect, replace the battery with a new one.

## Setting the Clock

- 1 Plug in the unit.  
The display will flash "AM 12:00".
- 2 To set the hour, while holding down **CLOCK**, press **TIME SET H**. When the correct hour appears in the display, release **CLOCK**.
- 3 To set the minute, while holding down **CLOCK**, press **TIME SET M**. When the correct minute appears in the display, release **CLOCK**. The clock will begin to operate when you release **TIME SET M**.

- The clock system varies depending on the model you own.  
12-hour system: "AM 12:00" = midnight
- Each press on **TIME SET H** or **TIME SET M** advances the displayed number by one.
- The minute digits advance to "00" after "59". The hour digits do not advance by pressing **TIME SET M**.
- To adjust the time exactly to the second, release **TIME SET M** simultaneously with the time signal.

## Playing the Radio

- 1 Set the function selector to **RADIO ON** to turn on the radio and adjust **VOL** (volume).
- 2 Select **BAND** and tune in to a station using **TUNING**.

- To turn off the radio, set the function selector to **OFF**.
- To improve radio reception  
**FM**: Since the AC power cord acts as an antenna, extend the cord to improve FM reception.  
**AM**: Rotate the unit horizontally for optimum reception. A ferrite bar antenna is built into the unit.

## Setting the Alarm

To set the radio alarm, first tune in to a station and adjust the volume.

- 1 To set the hour for alarm, while holding down **ALARM**, press **TIME SET H**. When the desired hour appears in the display, release **ALARM**.
- 2 To set the minute for alarm, while holding down **ALARM**, press **TIME SET M**. When the desired minute appears in the display, release **ALARM**.
- 3 Set the function selector to the alarm sound of your choice (**RADIO** or **BUZZER**).  
The alarm will come on at the preset time and automatically turn itself off after 119 minutes.

- To shut off the alarm, set the function selector to **OFF**.  
To sound the alarm at the preset time the next day, set the function selector to **RADIO** or **BUZZER** again.
- To cancel either alarm, set the function selector to **OFF**.
- To doze a few more minutes, press **SNOOZE / SLEEP OFF**.  
The alarm will shut off, but will come on again after about 9 minutes. You can repeat this process as many times as you like.
- To adjust the radio alarm volume, turn **VOL**. The buzzer volume is fixed.
- To check the preset time, press **ALARM**.

## Setting the Sleep Timer

Enjoy falling asleep to the radio using the built-in sleep timer that shuts off the radio automatically after a preset time.

- 1 While listening to the radio, set the function selector to **OFF**.
- 2 Press **SLEEP**.  
The radio turns on. It will go off after 59 minutes.

- To turn off the radio before the preset time, press **SNOOZE / SLEEP OFF**.
- Every time you press **SLEEP**, the sleep timer is reset to 59 minutes.
- When you set the function selector to **RADIO** or **BUZZER**, if the preset alarm time comes while the sleep timer is operating, the radio or buzzer sounds depending on which you set.

## To Use Both Sleep Timer and Alarm Function

You can fall asleep to the radio sound and you will be awakened by the radio/buzzer alarm at the preset time.

- 1 Set the alarm. (See "Setting the Alarm".)
- 2 Press **SLEEP**.

## Specifications

Frequency range:

FM: 87.5 - 108 MHz

AM: 530 - 1,605 kHz

Speaker:

Approx. 6.6 cm (2<sup>5</sup>/<sub>8</sub> inches) dia.

Power output:

150 mW (at 10 % harmonic distortion)

Power requirements:

120 V AC, 60 Hz

For the power backup function: 9 V DC, one

6F22 battery

Battery life:

Approx. 200 minutes, using Sony S-006P(U) battery

Dimensions:

Approx. 192 × 52 × 155 mm (w/h/d)

(7<sup>5</sup>/<sub>8</sub> × 2<sup>1</sup>/<sub>8</sub> × 6<sup>1</sup>/<sub>8</sub> inches) incl. projecting parts and controls

Mass:

Approx. 520 g (1 lb 2 oz.) not incl. battery

Design and specifications are subject to change without notice.

