

**SONY**

## Rear Speaker

SA-RS3S




\* 5 0 1 1 5 2 7 6 1 \* (2)

## About compatible models for the rear speaker

The SA-RS3S rear speaker works only with the specified model. For information about compatible models, visit Sony's website. In these Operating Instructions, the operations are described for speakers used with the compatible model HT-A7000.

## Parts and Controls


### Front



- 1** Power indicator
- Flashes slowly (green): The rear speaker is not connected to a compatible model.
  - Lights up (green): The rear speaker is connected to a compatible model.
  - Flashes twice repeatedly (green): The rear speaker is attempting to connect to a compatible model.
  - Flashes/lights up (amber): The software is updating.
  - Lights up (red): The rear speaker is in standby mode.
  - Turns off: The rear speaker is turned off.

**Note**  
The brightness of the power indicator syncs with the DIMMER settings of a compatible model.

### Rear



- 2** Wall mount hole  
**3** ⏻ (power) button  
**4** LINK button  
**5** Mounting hole for the general speaker stand  
**6** AC inlet



Operating Instructions

GB

使用説明書


CT

- 1** Prepare a screw (not supplied) that is suitable for the wall mount hole on the rear of the speakers.




Hole on the rear of the rear speaker

- 2** Decide the wall mounting position of the speaker and fasten the screw there.



- 3** Hang the wall mount hole on the screw. Check the label on the bottom of the speakers. "REAR R" is for the right, "REAR L" is for the left.




**Note**  
Prepare screws (not supplied) that are suitable for the wall material and strength. As a plasterboard wall is especially fragile, attach the screws securely in the wall beam. Mount the speakers onto a reinforced wall making sure that the heights of the right and left speakers are equal.

## Connection


**Tip**  
You can connect the optional subwoofer with a compatible model in the following way when installing it too.

- Turn on a compatible model.**
- Connect the AC power cords (mains leads) (supplied) to the rear speakers, and then connect the cords to the AC outlets (mains).**



- 3** Make sure that the power indicators on the speakers light in green.



When the power indicators light in green, the connection between the speakers and a compatible model is established. If the connection is not established, connect the speakers to a compatible model manually. For details, see "If the Connection is not Established Automatically".



### If the Connection is not Established Automatically


If you cannot connect the speakers to a compatible model automatically or you use multiple compatible models and want to specify the compatible model for connecting the speakers, perform the manual connection.

The following operation is described for speakers used with the compatible model HT-A7000. Use the remote control supplied with the compatible model HT-A7000 when performing this operation. If you use other compatible models, refer to the Operating Instructions supplied with them.

- Press HOME.**  
The home menu appears on the TV screen.
  - Select  [Setup] - [Advanced Settings] on the home menu.**
  - Select [Speaker Settings] - [Wireless Speaker Settings] - [Start manual linking].**  
The [Start manual linking] screen appears on the TV screen.
  - Press LINK on the speaker.**  
The power indicator of the speaker that had LINK pressed flashes twice repeatedly in green.
  - Select [Start].**  
The manual link starts. The connecting process appears on the TV screen. To cancel the manual link, select [Cancel].
  - When [Rear Speaker (R)] and [Rear Speaker (L)] display [Connected], select [Finish].**
  - Press .**  
The link is established and the power indicator of the speakers lights in green.
- Note**
- If you perform [Start manual linking], [Link mode] of [Wireless Speaker Settings] is set to [Manual] automatically.
  - Only the speakers for which [Connected] has been displayed in Step 6 connect to a compatible model. If the connection of the speakers cannot be established, perform the manual connection again.

### If Wireless Transmission is Unstable

If you use multiple wireless systems, such as a wireless LAN, the wireless signals may become unstable. In this case, the transmission may be improved by changing the following setting. The following operation is described for speakers used with the compatible model HT-A7000. Use the remote control supplied with the compatible model HT-A7000 when performing this operation. If you use other compatible models, refer to the Operating Instructions supplied with them.




- Press HOME.**  
The home menu appears on the TV screen.
- Select  [Setup] - [Advanced Settings] on the home menu.**
- Select [Speaker Settings] - [Wireless Speaker Settings] - [RF Channel].**
- Select the setting you want.**
  - [On] (default setting): Normally select this. The system automatically selects the better channel for transmission. Stronger mode for wireless interference.
  - [Off]: The system selects a channel from the limited frequency band to prevent external wireless interference. If sound dripping occurs while [On] is selected, it may be improved by selecting [Off].

- Note**
- If you change the [RF Channel] setting from [Off] to [On], it may take 1 minute to reconnect.
  - A compatible model may not meet this setting depending on countries/regions where you purchase it.

## Troubleshooting

If you experience any of the following difficulties while using the rear speakers, use this troubleshooting guide to help remedy the problem before requesting repairs. Should any problem persist, consult your nearest Sony dealer. Be sure to bring all of your rear speakers, a compatible model and optional subwoofer (not supplied) even if it seems as though only one has a problem, when you request to repair. The following solutions are described for speakers used with the compatible model HT-A7000. If you use other compatible models, refer to the Operating Instructions supplied with them.

### No sound is heard from the rear speakers.

- ➔ Make sure the AC power cord (mains lead) of the rear speaker is connected properly.
- ➔ If the power indicator on the rear speaker does not light, try the following.
  - Make sure the AC power cord (mains lead) of the rear speaker is connected properly.
  - Press  (power) of the rear speaker to turn on the power.
- ➔ If the power indicator on the rear speaker flashes slowly in green or lights in red, try the following.
  - Move the rear speaker to a location near a compatible model so that the power indicator on the rear speaker lights in green.
  - Follow the steps in "If the Connection is not Established Automatically."
  - Check the wireless connection status. For details, refer to the Operating Instructions supplied with a compatible model.
- ➔ If the power indicator on the rear speaker flashes in red, press  (power) of the rear speaker to turn off the power and check whether the ventilation holes of the rear speaker is blocked or not.
- ➔ Press REAR  + on the remote control of a compatible model to increase the volume of the rear speakers.
- ➔ If you change the [RF Channel] setting of a compatible model from [Off] to [On], it may take 1 minute for the sound to be output.
- ➔ If the power indicator flashes in red, disconnect the AC power cord (mains lead) of the rear speaker from the AC outlet (mains) and reconnect it again.

### Sound skips or has noise.

- ➔ If there is a device nearby that generates electromagnetic waves, such as a wireless LAN or a microwave oven in use, locate the rear speakers and a compatible model apart from that device.
- ➔ If there is an obstacle between a compatible model and the rear speakers, move or remove the obstacle.
- ➔ Locate a compatible model and the rear speakers as close as possible.
- ➔ Switch the network connection of the TV or Blu-ray Disc player from wireless to wired.

## Specifications

POWER OUTPUT (rated)  
30 W + 30 W (at 6 ohms, 1 kHz, 1% THD)  
POWER OUTPUT (reference)  
50 W (per channel at 6 ohms, 1 kHz)

### Speaker system

2-way 2 speaker system  
Bass reflex

**Speaker**  
Woofer: 46 mm × 54 mm cone type  
Tweeter: 16 mm dome type

**Power requirements**  
Models for Taiwan:  
120 V AC, 50 Hz/60 Hz  
Models for other countries/regions:  
220 V - 240 V AC, 50 Hz/60 Hz

### Power consumption

On: 11 W  
Standby mode: 1 W or less  
Turned off: 0.5 W or less

### Dimensions (w/h/d) (approx.)

100 mm × 187 mm × 100 mm (projecting parts not included)

### Mass (approx.)

1.1 kg

### Wireless transmitter/receiver section

**Communication system**  
Wireless Sound Specification Version 4.0

### Frequency band

5 GHz

### Modulation method

OFDM

### Included items

#### Models for Taiwan:

- Rear speaker R (1), Rear speaker L (1)
- AC power cords (mains leads) (2)
- Operating Instructions (1)


#### Models for other countries/regions:

- Rear speaker R (1), Rear speaker L (1)
- AC power cords (mains leads) (4)
- Operating Instructions (1)

## Important information on software

This product contains software that is subject to the GNU General Public License ("GPL") or GNU Lesser General Public License ("LGPL"). These establish that customers have the right to acquire, modify, and redistribute the source code of said software in accordance with the terms of the GPL or the LGPL.

For the method to confirm the GPL, LGPL and other software licenses contained in the rear speakers, please refer to the Operating Instructions of a compatible model.

When you use the compatible model HT-A7000, please refer to [Software License Information] under  [Setup] - [Advanced Settings] - [System Settings] on the home menu.

You may find a copy of the relevant source code as required under the GPLv2 (and other licenses) at <https://oss.sony.net/Products/Linux>

You may obtain the source code as required by the GPLv2 on a physical medium from us for a period of three years after our last shipment of this product by applying through the form at <https://oss.sony.net/Products/Linux>  
This offer is valid to anyone in receipt of this information.

Please note that Sony cannot answer or respond to any inquiries regarding the content of this source code.

All other trademarks are trademarks of their respective owners.

### WARNING

Do not install the speakers in a confined space, such as a bookcase or built-in cabinet.

To reduce the risk of fire, do not cover the ventilation opening of the speakers with newspapers, tablecloths, curtains, etc.  
Do not expose the speakers to naked flame sources (for example, lighted candles).

To reduce the risk of fire or electric shock, do not expose these speakers to dripping or splashing, and do not place objects filled with liquids, such as vases, on the speakers.

The speakers are not disconnected from the mains as long as they are connected to the AC outlets, even if the speakers themselves have been turned off.

As the main plug is used to disconnect the speakers from the mains, connect the speakers to an easily accessible AC outlet. Should you notice an abnormality in the speakers, disconnect the main plug from the AC outlet immediately.

### Do not place this product close to medical devices

This product (including accessories) has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

Indoor use only.

### For the speakers

The nameplates are located on the bottom of the speakers.

The operations near the radar system shall not be influenced.  
The directed antenna with high gain must apply to the fixed point-to-point system only.

## Precautions

### On safety

- Should any solid object or liquid fall into the rear speaker, unplug the system and have it checked by qualified personnel before operating it any further.
- Do not climb on the rear speaker, as you may fall down and injure yourself, or the rear speaker damage may result.

### On power sources

- Before operating the rear speaker, check that the operating voltage is identical to your local power supply. The operating voltage is indicated on the nameplate at the bottom of the rear speaker.
- If you are not going to use the rear speaker for a long time, be sure to disconnect the rear speaker from the wall outlet (mains). To disconnect the AC power cord (mains lead), grasp the plug itself; never pull the cord.
- One blade of the plug is wider than the other for the purpose of safety and will fit into the wall outlet (mains) only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- AC power cord (mains lead) must be changed only at a qualified service shop.

### On heat buildup

- Although the rear speaker heats up during operation, this is not a malfunction. If you continuously use this rear speaker at high volume, the rear speaker temperature at the rear and bottom rises considerably. To avoid burning yourself, do not touch the rear speaker.

### On placement

- Do not place the rear speaker near heat sources or in a place subject to direct sunlight, excessive dust, or mechanical shock.
- Do not place metal objects other than a TV around the rear speaker. Wireless functions may be unstable.
- If the rear speaker is being used in combination with a TV, VCR, or tape deck, noise may result and picture quality may suffer. In such a case, place the rear speaker away from the TV, VCR, or tape deck.
- Use caution when placing the rear speaker on a surface that has been specially treated (with wax, oil, polish, etc.), as staining or discoloration of the surface may result.
- The speakers of this rear speaker are not of magnetically shielded type. Do not place magnetic cards on the rear speaker or near it.

### If you encounter color irregularity on a nearby TV screen

Color irregularities may be observed on certain types of TV sets.

### On cleaning

Clean the rear speaker with a soft, dry cloth. Do not use any type of abrasive pad, scouring powder, or solvent such as alcohol or benzine.

If you have any question or problem concerning your system, please consult your nearest Sony dealer.

