

# *Portable CD Player*

---

## Operating Instructions

### **About the area code**

The area code of the location in which you purchased the CD player is shown on upper left of the bar code label on the package.

For accessories supplied with your CD player, check the area code of your model and see "Accessories (supplied/optional)."



*D-EJ621*

*D-EJ622*

*D-EJ625*

## CAUTION

The use of optical instruments with this product will increase eye hazard.

## Owner's Record

The model number is located at the rear and the serial number is located inside the lid of the CD player. Record these numbers in the spaces provided below. Refer to them whenever you call upon your Sony dealer regarding this product.

Model No. \_\_\_\_\_

Serial No. \_\_\_\_\_

Certain countries may regulate disposal of the battery used to power this product. Please consult with your local authority.

For the customers in the USA and Canada

This mark is available in the USA and Canada only

### RECYCLING NICKEL-CADMIUM BATTERIES

Nickel-Cadmium batteries are recyclable. You can help preserve our environment by returning your unwanted batteries to your nearest point for collection, recycling or proper disposal.

**Note:** In some areas the disposal of nickel-cadmium batteries in household or business trash may be prohibited.



RBRC (Rechargeable Battery Recycling Corporation) advises you about spent battery collection by the following phone number.

Call toll free number: 1-800-822-8837 (United States and Canada only)

**Caution:** Do not handle damaged or leaking nickel-cadmium batteries.

For the customers in the USA and Canada

### DISPOSAL OF NICKEL METAL HYDRIDE BATTERY.

NICKEL METAL HYDRIDE BATTERY.  
DISPOSE OF PROPERLY.

You can return your unwanted nickel metal hydride batteries to your nearest Sony Service Center or Factory Service Center.

**Note:** In some areas the disposal of nickel metal hydride batteries in household or business trash may be prohibited.

For the Sony Service Center nearest you call 1-800-222-SONY (United States only)

For the Sony Factory Service Center nearest you call 416-499-SONY (Canada only)

**Caution:** Do not handle damaged or leaking nickel metal hydride battery.

For the customers in the USA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

# Table of Contents

## Getting started

|                             |   |
|-----------------------------|---|
| Locating the controls ..... | 4 |
|-----------------------------|---|

## Playing a CD

|                                 |   |
|---------------------------------|---|
| 1. Connect your CD player. .... | 6 |
| 2. Insert a CD. ....            | 6 |
| 3. Play a CD. ....              | 6 |

## Playback options

|   |    |
|---|----|
| Playing tracks repeatedly (Repeat play) .....             | 9  |
| Playing a single track (Single play) .....                | 9  |
| Playing tracks in random order<br>(Shuffle play) .....    | 9  |
| Playing tracks in your favorite order<br>(PGM play) ..... | 10 |

## Available features

|  |    |
|--|----|
| G-PROTECTION function .....                | 11 |
| Emphasizing the bass sound (SOUND) ....    | 11 |
| Protecting your hearing (AVLS) .....       | 12 |
| Locking the controls (HOLD) .....          | 12 |
| Turning off the operation beep sound ..... | 13 |

## Connecting your CD player

|                                     |    |
|-------------------------------------|----|
| Connecting a stereo system .....    | 14 |
| Using your CD player in a car ..... | 15 |

## Connecting a power source

|  |    |
|--|----|
| Using the rechargeable batteries ..... | 16 |
| Using the dry batteries .....          | 18 |
| Notes on the power source .....        | 18 |

## Additional information


|                                       |    |
|---------------------------------------|----|
| Precautions .....                     | 19 |
| Maintenance .....                     | 19 |
| Troubleshooting .....                 | 20 |
| Specifications .....                  | 22 |
| Accessories (supplied/optional) ..... | 23 |

# Getting started


## Locating the controls

For details, see pages in parentheses.


### CD player (front)




### CD player (inside)



### CD player (rear)



## Remote control (for the models supplied with the remote control)




### Note

Use only the supplied remote control. You cannot operate this CD player with the remote control supplied with other CD players.



## Using the hand strap

To carry during strenuous activity, use the supplied hand strap.

- 1 Pass the hand strap through the strap holes of the player.



- 2 Put your hand through the hand strap, and hold the player in one of two ways as illustrated below.



# Playing a CD


You can also use rechargeable batteries, dry batteries and a car battery as a power source.

## 1. Connect your CD player.

- 1 Connect the AC power adaptor.
- 2 Connect the headphones/earphones.


For models supplied with the remote control

- Connect the plug of the headphones/earphones to the remote control.
- Connect the headphones/earphones to the remote control firmly. A loose connection may cause noise during playback.




## 2. Insert a CD.


- 1 Slide OPEN to open the lid.



- 2 Place the CD on the tray and close the lid.



## 3. Play a CD.



Adjust the volume by pressing VOLUME + or -.

|   |                   |
|---|-------------------|
| To  | Press             |
| Play/Pause  | ▶                 |
| Stop  | ■/CHG*2           |
| Find the beginning of the current track (AMS*1)   | ◀◀ once quickly*2 |
| Find the beginning of the previous tracks (AMS)   | ◀◀ repeatedly*2   |
| Find the beginning of the next track (AMS)        | ▶▶ once quickly*2 |
| Find the beginning of the succeeding tracks (AMS) | ▶▶ repeatedly*2   |
| Go backwards quickly                              | Hold down ◀◀*2    |
| Go forward quickly                                | Hold down ▶▶*2    |

\*1 Automatic Music Sensor

\*2 These operations can be done during both play and pause.

### About the display

- When you press ▶|| (▶ for the remote control) after changing the CD or turning off and on the player, the total number of tracks in the CD and total playing time appear for about two seconds.
- During play, the track number and the elapsed playing time of the current track appear.
- During pause, the elapsed playing time flashes.

### If the volume level does not increase


- Is AVLS set to "LIMIT"? Set AVLS to "NORM." For details, see "Protecting your hearing (AVLS)."
- Are the headphones connected to the LINE OUT jack? Connect them to the ◡ (headphones) jack.

### About CD-Rs/CD-RWs

This CD player is compatible with CD-Rs/CD-RWs but playback capability may vary depending on the quality of the disc, the recording device and application software.

### Removing the CD

Remove the CD while pressing the pivot in the center of the tray.




# Playback options

You can enjoy various ways of playback using PLAY MODE and REPEAT/ENTER.

## PLAY MODE button

Each time you press the button, you can change the playback mode.




## REPEAT/ENTER button

### REPEAT

You can repeat play that is selected using PLAY MODE.

### ENTER

You can select tracks for PGM play mode.





---

## *Playing tracks repeatedly* (Repeat play)

You can play tracks repeatedly in normal, single, shuffle and PGM play modes.



---

**During playback, press REPEAT/ENTER.**



---

### **Note on**

During Repeat play, you can locate the first track after the last track by pressing  repeatedly. You can also locate the last track after first track by pressing  repeatedly.

---

## *Playing a single track* (Single play)

**During playback, press PLAY MODE repeatedly until "1" appears.**



---

## *Playing tracks in random order* (Shuffle play)

**During playback, press PLAY MODE repeatedly until "SHUF" appears.**



---

## Playing tracks in your favorite order (PGM play)


You can program the CD player to play up to 64 tracks in your favorite order.

---

- 1** During playback, press **PLAY MODE** repeatedly until “PGM” appears.



- 2** Press **◀◀** or **▶▶** to select a track.



- 3** Press **REPEAT/ENTER** quickly (less than 0.5 second) to enter the selected track.

“00” appears and the playing order increases by one.



- 4** Repeat steps 2 and 3 to select the tracks in your favorite order.

- 5** Press **▶||**, or hold down **REPEAT/ENTER** until play starts.
- 

### To check the program

#### During programming:

Press **REPEAT/ENTER** repeatedly before step 5.

#### During the PGM play:

Press **PLAY MODE** repeatedly until “PGM” flashes, then press **REPEAT/ENTER**. Each time you press **REPEAT/ENTER**, the track number appears.

#### Notes

- When you finish entering the 64th track in step 3, the first selected track appears in the display.
- If you select more than 64 tracks, the first selected tracks are erased.

## G-PROTECTION function

The G-PROTECTION function has been developed to provide excellent protection against sound skipping during many active uses. This function provides a higher level of shock protection than the traditional one.

**Set G-PROTECTION (under the lid) to "ON."**



During active uses, be sure to hold your CD player with the OPEN switch facing upward.

**To turn off the G-PROTECTION function**

Set G-PROTECTION to "OFF."

### Note



Sound may skip:

- if the CD player receives stronger continuous shock than expected,
- if a dirty or scratched CD is played or
- when using poor-quality CD-Rs/CD-RWs or if there is a problem with the recording device or application software.

## Emphasizing the bass sound (SOUND)

You can emphasize the bass-boosted sound.

**Press SOUND to select "BASS ■" or "BASS ■■."**



The selected sound mode is displayed.

"BASS ■■" enhances the bass sound more than "BASS ■."

### Note

If the sound is distorted when using the SOUND function, turn down the volume.



---

## Protecting your hearing (AVLS)

The AVLS (Automatic Volume Limiter System) function keeps down the maximum volume to protect your hearing.

---

### Set AVLS (in the battery compartment) to "LIMIT."



Flashes when the volume is turned up and beyond a certain level.

---

### To turn off the AVLS function

Set AVLS to "NORM."


---

## Locking the controls (HOLD)

You can lock the controls on your CD player to prevent accidental button presses.

---

### Slide HOLD in the direction of the arrow.



Displayed when the HOLD function is working.

You can use the HOLD function with both the CD player and remote control. You can still operate your CD player using the remote control when HOLD on the remote control is set to off.

---

### To unlock the controls

Slide HOLD in the opposite direction of the arrow.

---

## *Turning off the operation beep sound*

You can turn off the beep sound that is heard from your headphones/earphones when you operate your CD player.

---

**1 Remove the power source (AC power adaptor, rechargeable batteries or dry batteries) from the CD player.**

---

**2 Connect the power source while pressing ■/CHG on the CD player or ■ on the remote control.**

---


### **To turn on the beep sound**

Remove the power source and then connect the power source without pressing ■/CHG or ■.

## Connecting a stereo system

You can listen to CDs through a stereo system and record CDs on a cassette tape. For details, see the instruction manual that comes with the connected device.


Be sure to turn off all connected devices before making connections.




### Notes

- Before you play a CD, turn down the volume of the connected device to avoid damaging the connected speakers.
- Use the AC power adaptor for recording. If you use the rechargeable batteries or dry batteries as a power source, batteries may become completely depleted during recording.
- Adjust the volume properly on the connected device so that the sound will not be distorted.

### When using the connecting cord

If the sound is distorted, connect the device to the  jack.

### About the G-PROTECTION and SOUND functions when using the connecting cord

- To record high quality CD sound, set the G-PROTECTION switch to "OFF."
- The SOUND function works only on the output sound from the  jack and not work on the output sound from the LINE OUT jack.

## *Using your CD player in a car*

You can use your CD player in a car by connecting it to the car cassette deck.

You cannot use the car mount plate for this CD player.

When you use your CD player in a car, install it securely in a location that does not interfere with your driving.

### **Optional car accessory needed**

To connect your CD player to a car cassette deck, you need the following car accessories in "Accessories (supplied/optional)":

- Car battery cord, and
- Car connecting pack\*

For details, see the instruction manuals that come with the optional accessories.

\* Noise may be heard if you use an optional connecting cord. It is recommended that you use a Sony car connecting pack to reduce noise.

### **Switched ignition function (when using the car battery cord)**

With this feature, your CD player stops automatically when you turn off the car engine (turn off the ignition key) even if the batteries are inserted in the CD player. This function is invalid depending on the car models.

#### **Note**

Use only the car battery cord listed in "Accessories (supplied/optional)." If you use any other car battery cord, a heat, smoke or malfunction may occur.

## ► Connecting a power source

You can use the following power sources:

- Rechargeable batteries
- AC power adaptor (see “Playing a CD”)
- LR6 (size AA) alkaline batteries

For the battery life and charging time of the rechargeable batteries, see “Specifications.”

---


## Using the rechargeable batteries

Charge the rechargeable batteries before using them for the first time. You can use only the following rechargeable batteries for your CD player.

- NC-WMAA
- NH-WM2AA

---


### 1 Open the battery compartment lid.



(rear)


---



### 2 Insert two rechargeable batteries by matching the ⊕ to the diagram in the battery compartment and close the lid.




---

### 3 Connect the AC power adaptor to the DC IN 4.5 V jack of your CD player and an AC outlet, then press ■/CHG to start charging.



The CD player charges the batteries. The “CHG” indicator turns on in the display, and the indicator sections of  light up in succession. When the batteries are completely charged, the “CHG” and  indicators turn off.

If you press ■/CHG after the charge has already been completed, the  indicator flashes and “Full” appears in the display.

---


### 4 Disconnect the AC power adaptor.

---




## To remove the rechargeable batteries

Remove the batteries as illustrated below.





## When to charge the rechargeable batteries

You can check the remaining power of the batteries in the display.



To keep the original battery capacity for a long time, charge the batteries only when they are completely depleted.

### Notes

- The indicator sections of  roughly shows the remaining battery power. One section does not always indicate one-fourth of the battery power.
- Depending on operating conditions, the indicator sections of  may increase or decrease.

## When to replace the rechargeable batteries

If the battery life becomes shorter by about half, replace the batteries with new rechargeable batteries.

## Note on the rechargeable batteries


If the battery is new or has not been used for a long time, it may not be charged completely until you charge and discharge it several times.

## Note on carrying the rechargeable batteries

Use the supplied battery carrying case to prevent unexpected heat. If the rechargeable batteries and the metallic objects are contacted, heat or fire may occur due to a short circuit.

## To attach the battery compartment lid

If the battery compartment lid is detached by an accidental drop, excessive force, etc., attach it as illustrated below.



## Using the dry batteries

Use only the following dry battery type for your CD player:

- LR6 (size AA) alkaline batteries

### Note

Be sure to remove the AC power adaptor when using the dry batteries.

## 1 Open the battery compartment lid.


## 2 Insert two LR6 (size AA) batteries by matching the ⊕ to the diagram in the battery compartment.

### To remove the batteries

Remove the batteries in the same way as rechargeable batteries.

### When to replace the batteries

You can check the remaining power of the batteries in the display.



When the batteries are depleted, replace both batteries with new ones.

## Notes on the power source

Disconnect all power sources when the CD player is not used.

### On AC power adaptor

- Use only the AC power adaptor supplied or recommended in "Accessories (supplied/optional)." Do not use any other AC power adaptor. It may cause a malfunction.

Polarity of the plug



- When disconnecting the AC power adaptor from the AC outlet, grasp the adaptor itself. Do not pull it by the cord.
- Do not touch the AC power adaptor with wet hands.

### On rechargeable batteries and dry batteries

- Do not charge the dry batteries.
- Do not throw the batteries into fire.
- Do not carry the batteries with coins or other metallic objects. It can generate heat if the positive and negative terminals of the battery are accidentally contacted by a metallic object.
- Do not mix rechargeable batteries with dry batteries.
- Do not mix new batteries with old ones.
- Do not use different types of batteries together.
- When the batteries are not to be used for a long time, remove them.
- If battery leakage occurs, wipe off any deposit in the battery compartment, and install new batteries. In case the deposit adheres to you, wash it off thoroughly.

---

## Precautions

### On safety


- Should any solid objects or liquid fall into the CD player, unplug it and have it checked by qualified personnel before operating it any further.
- Do not put any foreign objects in the DC IN 4.5 V (external power input) jack.

### On the CD player

- Keep the lens on the CD player clean and do not touch it. If you do so, the lens may be damaged and the CD player will not operate properly.
- Do not put any heavy object on top of the CD player. The CD player and the CD may be damaged.
- Do not leave the CD player in a location near heat sources, or in a place subject to direct sunlight, excessive dust or sand, moisture, rain, mechanical shock, unlevelled surface, or in a car with its windows closed.
- If the CD player causes interference to the radio or television reception, turn off the CD player or move it away from the radio or television.
- Discs with non-standard shapes (e.g., heart, square, star) cannot be played on this CD player. Attempting to do so may damage the CD player. Do not use such discs.

### On handling CDs

- To keep the CD clean, handle it by its edge. Do not touch the surface.
- Do not stick paper or tape onto the CD.



- Do not expose the CD to direct sunlight or heat sources such as hot air ducts. Do not leave the CD in a car parked under direct sunlight.

### On headphones/earphones

#### Road safety

Do not use headphones/earphones while driving, cycling, or operating any motorized vehicle. It may create a traffic hazard and is illegal in some areas. It can also be potentially dangerous to play your headsets at high volume while walking, especially at pedestrian crossings. You should exercise extreme caution or discontinue use in potentially hazardous situations.

#### Preventing hearing damage

Avoid using headphones/earphones at high volume. Hearing experts advise against continuous, loud and extended play. If you experience a ringing in your ears, reduce volume or discontinue use.

#### Consideration for others

Keep the volume at a moderate level. This will allow you to hear outside sounds and to be considerate to the people around you.

---

## Maintenance




### To clean the casing

Use a soft cloth slightly moistened in water or a mild detergent solution. Do not use alcohol, benzine or thinner.

---

## Troubleshooting

Should any problem persist after you have checked these symptoms, consult your nearest Sony dealer.

| Symptom  | Cause and/or corrective actions   |
|--|---|
| The volume does not increase even if you press the VOLUME + button repeatedly.   | <ul style="list-style-type: none"><li>→ Set the AVLS switch to "NORM." (page 12)</li><li>→ The headphones/earphones are connected to the LINE OUT jack. Connect them to the  (headphones) jack. (page 6)</li></ul>   |
| Cannot adjust the volume.  | <ul style="list-style-type: none"><li>→ The headphones/earphones are connected to the LINE OUT jack. Connect them to the  (headphones) jack. (page 6)</li></ul>  |
| No sound, or noise is heard.   | <ul style="list-style-type: none"><li>→ Connect the plugs firmly. (page 6)</li><li>→ Plugs are dirty. Clean the plugs with a dry soft cloth periodically.</li></ul>   |
| The playing time is too short when powered with the dry batteries.   | <ul style="list-style-type: none"><li>→ Check that you are using alkaline batteries and not manganese batteries. (page 18)</li><li>→ Replace the batteries with new LR6 (size AA) alkaline batteries. (page 18)</li></ul>   |
| The playing time is too short when powered with the rechargeable batteries.  | <ul style="list-style-type: none"><li>→ Charge and discharge the rechargeable batteries several times. (pages 16, 17)</li></ul>   |
| When you press  , "Lo batt" or "00" appears in the display. The CD does not play. | <ul style="list-style-type: none"><li>→ The rechargeable batteries are used up completely. Charge the batteries. (page 16)</li><li>→ Replace the batteries with new LR6 (size AA) alkaline batteries. (page 18)</li></ul>   |
| "HI dc In" appears in the display.   | <ul style="list-style-type: none"><li>→ Use only the AC power adaptor or car battery cord in "Accessories (supplied/optional)." (page 23)</li><li>→ Remove all power sources, then insert the batteries or connect the AC power adaptor again. (pages 6, 16, 17, 18)</li></ul>  |
| The CD does not play or "no DISC" appears in the display when a CD is placed in the CD player.   | <ul style="list-style-type: none"><li>→ The CD is dirty or defective. (page 19)</li><li>→ Check that the CD is inserted with the label side up. (page 6)</li><li>→ Moisture condensation has occurred.<br/>Leave the CD player aside for several hours until the moisture evaporates.</li><li>→ Close the lid of the battery compartment firmly. (page 16)</li><li>→ Make sure the batteries are inserted correctly. (pages 16 - 18)</li><li>→ Connect the AC power adaptor to an AC outlet securely. (page 6)</li><li>→ The CD-R/CD-RW was not finalized. Finalize the CD-R/CD-RW with the recording device.</li><li>→ There is a problem with the quality of the CD-R/CD-RW, recording device, or application software.</li></ul> |
| "Hold" appears in the display when you press a button, and the CD does not play.   | <ul style="list-style-type: none"><li>→ The buttons are locked. Slide the HOLD switch back. (page 12)</li></ul>   |

| Symptom   | Cause and/or corrective action   |
|---|--|
| The CD player does not start charging.                        | → During stop, press ■/CHG. (page 16)  |
| Playback starts from the point you stopped. (resume function) | → The resume function is working. To start play from the first track, open the lid of the CD player; or remove all power sources, then insert the batteries or connect the AC power adaptor again. (pages 6, 16, 18) |

# Specifications

## System

Compact disc digital audio system

## Laser diode properties

Material: GaAlAs

Wavelength:  $\lambda = 780 \text{ nm}$

Emission duration: Continuous

Laser output: Less than  $44.6 \mu\text{W}$

(This output is the value measured at a distance of 200 mm from the objective lens surface on the optical pick-up block with 7 mm aperture.)

## D-A conversion

1-bit quartz time-axis control

## Frequency response

20 - 20 000 Hz  $\pm 1$  dB (measured by EIAJ CP-307)

## Output (at 4.5 V input level)

Line output (stereo minijack)

Output level 0.7 V rms at 47 k $\Omega$

Recommended load impedance over 10 k $\Omega$

Headphones (stereo minijack)

Approx. 5 mW + Approx. 5 mW at 16  $\Omega$

## Power requirements

For the area code of the model you purchased, check the upper left side of the bar code on the package.

- Two Sony NC-WMAA rechargeable batteries: 2.4 V DC
- Sony NH-WM2AA rechargeable batteries: 2.4 V DC
- Two LR6 (size AA) batteries: 3 V DC
- AC power adaptor (DC IN 4.5 V jack):  
U2/U/CA2/E92/MX2/TW2/BR3 model:  
120 V, 60 Hz  
CED/CET/CEW/CEX/CE7/EE/EE1/E13/G5/  
G6/G7/G8/BR1 model:  
220 - 230 V, 50/60 Hz  
CEK/3CE7 model: 230 - 240 V, 50 Hz  
AU2 model: 240 V, 50 Hz  
JE.W/E33/EA3 model: 100 - 240 V, 50/60 Hz  
HK2 model: 220 V, 50/60 Hz  
AR1/CNA model: 220 V, 50 Hz
- Sony DCC-E345 car battery cord for use on car battery: 4.5 V DC

## Battery life\* (approx. hours)

(When you use the CD player on a flat and stable surface.)

Playing time varies depending on how the CD player is used.

| When using                                      | G-PROTECTION function |     |
|---|-----------------------|-----|
|   | on                    | off |
| Two NC-WMAA<br>(charged for<br>about 3 hours**) | 8                     | 10  |
| NH-WM2AA<br>(charged for<br>about 5 hours**)    | 18                    | 21  |
| Two Sony alkaline<br>batteries LR6(SG)          | 34                    | 36  |

\* Measured value by the standard of EIAJ (Electronic Industries Association of Japan).

\*\* Charging time varies depending on how the rechargeable battery is used.

## Operating temperature

5°C - 35°C (41°F - 95°F)

## Dimensions (w/h/d) (excluding projecting parts and controls)

Approx. 131.6 × 29.5 × 135.5 mm  
(5 1/4 × 1 3/16 × 5 3/8 in.)

## Mass (excluding accessories)

Approx. 191 g (6.8 oz.)

Design and specifications are subject to change without notice.

## Accessories (supplied/optional)

### Supplied accessories

For the area code of the location in which you purchased the CD player, check the upper left side of the bar code on the package.

D-E1621/E1622  
D-E1625

|  |   |   |
|--|---|---|
| AC power adaptor (1)                         | ○ | ○ |
| Headphones/earphones with remote control (1) | — | ○ |
| Headphones/earphones (1)                     | ○ | — |
| Rechargeable batteries (2)                   | — | ○ |
| Battery carrying case (1)                    | — | ○ |
| Hand strap (1)                               | ○ | ○ |

### For US customers


The AC power adaptor supplied is not intended to be serviced. Should the AC power adaptor cease to function in its intended manner, during the warranty period, the adaptor should be returned to your nearest Sony Service Center or Sony Authorized Repair Center for replacement, or after warranty period, it should be discarded.

### Optional accessories

|   |                          |
|---|--------------------------|
| AC power adaptor                          | AC-E45HG                 |
| Active speaker system                     | SRS-Z1<br>SRS-Z500       |
| Car battery cord                          | DCC-E345                 |
| Car battery cord with car connecting pack | DCC-E34CP                |
| Car connecting pack                       | CPA-9C                   |
| Connecting cord                           | RK-G129<br>RK-G136       |
| Rechargeable battery                      | NH-WM2AA                 |
| Earphones                                 | MDR-E848LP<br>MDR-EX70LP |
| Headphones                                | MDR-A44L<br>MDR-A110LP   |

### When connecting optional headphones/earphones to the supplied remote control

Use only headphones with stereo mini plugs. You cannot use headphones with micro plugs.



Stereo miniplug

Micro plug

Your dealer may not handle some of the above listed accessories. Please ask the dealer for detailed information about the accessories in your country.

**This warranty is valid only in the United States.**

**SONY®**

## **LIMITED WARRANTY**

Portable Audio

Sony Electronics Inc. ("Sony") warrants this Product (including any accessories) against defects in material or workmanship as follows:

1. **LABOR:** For a period of 90 days from the date of purchase, if this Product is determined to be defective, Sony will repair or replace the Product, at its option, at no charge, or pay the labor charges to any Sony authorized service facility. After the Warranty Period, you must pay for all labor charges.

2. **PARTS:** In addition, Sony will supply, at no charge, new or rebuilt replacements in exchange for defective parts for a period of one (1) year. After 90 days from the date of purchase, labor for removal and installation is available from Sony authorized service facilities or a Sony Service Center at your expense.

To obtain warranty service, you must take the Product, or deliver the Product freight prepaid, in either its original packaging or packaging affording an equal degree of protection, to any authorized Sony service facility.

This warranty does not cover customer instruction, installation, set up adjustments or signal reception problems.

This warranty does not cover cosmetic damage or damage due to acts of God, accident, misuse, abuse, negligence, commercial use, or modification of, or to any part of the Product, including the antenna. This warranty does not cover damage due to improper operation or maintenance, connection to improper voltage supply, or attempted repair by anyone other than a facility authorized by Sony to service the Product. This warranty does not cover Products sold AS IS or WITH ALL FAULTS, or consumables (such as fuses or batteries). This warranty is valid only in the United States.

Proof of purchase in the form of a bill of sale or receipted invoice which is evidence that the unit is within the Warranty period must be presented to obtain warranty service.

This warranty is invalid if the factory applied serial number has been altered or removed from the Product.

**REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. SONY SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.**

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you. In addition, if you enter into a service contract with the Sony Partnership within 90 days of the date of sale, the limitation on how long an implied warranty lasts does not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

For your convenience, Sony Electronics Inc. has established telephone numbers for frequently asked questions:

To locate the servicer or dealer nearest you, or for service assistance or resolution of a service problem, or for product information or operation, call:

**Sony Direct Response Center**

1-(800)-222-7669

or write to:

Sony Direct Response Center

12451 Gateway Blvd.

Fort Myers, FL 33913

For an accessory or part not available from your authorized dealer, call:

1-(800)-488-SONY (7669)

W 455714701 (T1)

Sony online <http://www.world.sony.com/>