

HOME THEATRE SYSTEM

HT-DDW680

Speaker Connection Raccordement des enceintes

English

This Speaker Connection explains how to connect the DVD player, TV, speakers, and sub woofer so you can enjoy multi channel surround sound from the DVD player. For details, refer to the operating instructions supplied with the receiver.

Before you connect the speakers, check the speaker label at the bottom of the front and surround speakers for the model name. The speaker label for center speaker and sub woofer is on the rear panel of the speaker as shown in the illustration at right. Connect the speakers as shown in the illustration at right.

The front and center speakers and the sub woofer are magnetically shielded to allow it to be installed near a TV set. However, as the surround speakers are not magnetically shielded, we recommend that you place the surround speakers slightly further away from the TV set.

Notes

- To view the image of the DVD on the TV screen, make sure that the video output of the DVD player is connected to the TV. For details, refer to the operating instructions supplied with the DVD player and TV.
- To fully enjoy surround sound while watching TV programmes, we recommend that you
 - connect the audio output of your TV to the VIDEO 2 AUDIO IN jack of the receiver. Then, select VIDEO 2 as an input.
 - turn down or mute the TV's volume.
 For details on selecting the surround sound, see "Enjoying Surround Sound" in the operating instructions supplied with the receiver.

Español

La sección "Conexión de los altavoces" explica cómo conectar el reproductor de DVD, una televisión, los altavoces y el altavoz potenciador de graves a fin de poder disfrutar de un sonido envolvente multicanal del reproductor de DVD. Si desea obtener más información, consulte el manual de instrucciones suministrado con el receptor.

Antes de conectar los altavoces compruebe la etiqueta del altavoz, que se encuentra en la parte posterior de los altavoces frontales y de sonido envolvente, para conocer el nombre del modelo. La etiqueta del altavoz central y altavoz potenciador de graves se encuentra en el panel posterior del mismo, tal y como se muestra en la ilustración de la derecha. Conecte los altavoces tal y como se muestra en dicha ilustración.

Los altavoces frontales, el altavoz central y el altavoz potenciador de graves están protegidos magnéticamente, lo que permite su instalación cerca de un aparato de televisión. Sin embargo, dado que los altavoces de sonido envolvente no están protegidos magnéticamente, es recomendable colocarlos a cierta distancia del aparato de televisión.

Notas

- Para ver las imágenes del DVD en la pantalla de la televisión, asegúrese de que la salida de vídeo del reproductor de DVD esté conectada a la televisión. Para obtener más información, consulte el manual de instrucciones suministrado con el reproductor de DVD y con la televisión.
- Para disfrutar totalmente de sonido envolvente mientras visualiza programas de televisión, le recomendamos que
 - conecte la salida de audio del televisión a la toma VIDEO 2 AUDIO IN del receptor. A continuación, seleccione VIDEO 2 como entrada.
 - baje el volumen del televisión o silencie el sonido.
 Para obtener más información sobre cómo seleccionar la función de sonido envolvente, consulte "Para disfrutar de sonido envolvente" en el manual de instrucciones suministrado con el receptor.

