

Notice:

When connecting equipment using 480p resolution to "IN5 COMPONENT," the video output will always be **Full** mode, even if the **Auto Wide** setting of your TV is on (e.g., 16:9 programming will display as 4:3 full screen).

Solutions:

- Manually change the **Wide Mode** setting of the TV as preferred (e.g., **Normal, Full, Zoom** or **Wide Zoom**). OR,
- Change the resolution of the source to 480i. (See your source manual for changing the resolution.)

Remarque :

En reliant un appareil qui utilise une résolution 480p à «IN5 COMPONENT», l'image affichée sera toujours en mode **Plein écran**, même si la configuration **Cinéma autom.** du téléviseur est activée (par exemple : une émission 16:9 sera affichée en 4:3 plein écran).

Solutions :

- Changez manuellement la configuration du **Mode cinéma** du téléviseur comme vous le souhaitez (par exemple : **Normal, Plein écran, Zoom**, ou **Grand zoom**). OU,
- Changez la résolution de la source en 480i. (Vérifiez le manuel de la source pour changer la résolution.)



4 1 3 2 5 2 9 0 1 0

4-132-529-01(1)

© 2008 Sony Corporation Printed in Japan

Notice:

When connecting equipment using 480p resolution to "IN5 COMPONENT," the video output will always be **Full** mode, even if the **Auto Wide** setting of your TV is on (e.g., 16:9 programming will display as 4:3 full screen).

Solutions:

- Manually change the **Wide Mode** setting of the TV as preferred (e.g., **Normal, Full, Zoom** or **Wide Zoom**). OR,
- Change the resolution of the source to 480i. (See your source manual for changing the resolution.)

Remarque :

En reliant un appareil qui utilise une résolution 480p à «IN5 COMPONENT», l'image affichée sera toujours en mode **Plein écran**, même si la configuration **Cinéma autom.** du téléviseur est activée (par exemple : une émission 16:9 sera affichée en 4:3 plein écran).

Solutions :

- Changez manuellement la configuration du **Mode cinéma** du téléviseur comme vous le souhaitez (par exemple : **Normal, Plein écran, Zoom**, ou **Grand zoom**). OU,
- Changez la résolution de la source en 480i. (Vérifiez le manuel de la source pour changer la résolution.)



4 1 3 2 5 2 9 0 1 0

4-132-529-01(1)

© 2008 Sony Corporation Printed in Japan

Notice:

When connecting equipment using 480p resolution to "IN5 COMPONENT," the video output will always be **Full** mode, even if the **Auto Wide** setting of your TV is on (e.g., 16:9 programming will display as 4:3 full screen).

Solutions:

- Manually change the **Wide Mode** setting of the TV as preferred (e.g., **Normal, Full, Zoom** or **Wide Zoom**). OR,
- Change the resolution of the source to 480i. (See your source manual for changing the resolution.)

Remarque :

En reliant un appareil qui utilise une résolution 480p à «IN5 COMPONENT», l'image affichée sera toujours en mode **Plein écran**, même si la configuration **Cinéma autom.** du téléviseur est activée (par exemple : une émission 16:9 sera affichée en 4:3 plein écran).

Solutions :

- Changez manuellement la configuration du **Mode cinéma** du téléviseur comme vous le souhaitez (par exemple : **Normal, Plein écran, Zoom**, ou **Grand zoom**). OU,
- Changez la résolution de la source en 480i. (Vérifiez le manuel de la source pour changer la résolution.)



4 1 3 2 5 2 9 0 1 0

4-132-529-01(1)

© 2008 Sony Corporation Printed in Japan

Notice:

When connecting equipment using 480p resolution to "IN5 COMPONENT," the video output will always be **Full** mode, even if the **Auto Wide** setting of your TV is on (e.g., 16:9 programming will display as 4:3 full screen).

Solutions:

- Manually change the **Wide Mode** setting of the TV as preferred (e.g., **Normal, Full, Zoom** or **Wide Zoom**). OR,
- Change the resolution of the source to 480i. (See your source manual for changing the resolution.)

Remarque :

En reliant un appareil qui utilise une résolution 480p à «IN5 COMPONENT», l'image affichée sera toujours en mode **Plein écran**, même si la configuration **Cinéma autom.** du téléviseur est activée (par exemple : une émission 16:9 sera affichée en 4:3 plein écran).

Solutions :

- Changez manuellement la configuration du **Mode cinéma** du téléviseur comme vous le souhaitez (par exemple : **Normal, Plein écran, Zoom**, ou **Grand zoom**). OU,
- Changez la résolution de la source en 480i. (Vérifiez le manuel de la source pour changer la résolution.)



4 1 3 2 5 2 9 0 1 0

4-132-529-01(1)

© 2008 Sony Corporation Printed in Japan