

# SONY®

**Viktig informasjon**

©2015

## Web-område for Sony-brukere

På [www.sonymobile.com/support](http://www.sonymobile.com/support) finner du en kundestøttedel der du raskt får tilgang til hjelp og tips. Her finner du de siste programoppdateringene og tips om hvordan du kan bruke produktene mer effektivt.

## Service og kundestøtte

Du har tilgang til en rekke eksklusive servicefordeler, for eksempel:

- Globale og lokale kundestøtte på internett.
- Et globalt nettverk av kundestøttesentre.
- Et omfattende nettverk av Sony-servicepartnere.
- En garantiperiode. Les mer om garantibetingelsene i delen *Begrenset garanti*.

På [www.sonymobile.com/support](http://www.sonymobile.com/support) eller [www.sonymobile.com/contact](http://www.sonymobile.com/contact) kan du finne det siste innen kundestøtteverktøy og kundestøtteinformasjon. Ta kontakt med nettoperatoren for informasjon om operatørspesifikke tjenester og funksjoner.

Du kan også kontakte våre kundestøttesentre eller den lokale forhandleren. (Samtaler belastes i henhold til lokale satser, inkludert lokale avgifter, med mindre det er et grønt nummer.)

Hvis produktet skulle ha behov for service, kontakter du forhandleren du kjøpte produktet fra, eller en av våre servicepartnere. Hvis du vil komme med krav i henhold til den begrensede garantien, må du ha en kjøpsbevis.





## Retningslinjer for sikker og effektiv bruk

Følg alltid disse retningslinjene. Hvis du ikke gjør det, kan dette medføre helsefare eller at produktet ikke fungerer som det skal. Er du i tvil om produktet fungerer som det skal, bør du få det kontrollert av en sertifisert servicepartner før du lader eller bruker det.




## Anbefalinger for vedlikehold og sikker bruk av produktene våre

- Vær forsiktig med produktet når du bruker det, og oppbevar det på et rent og støvfritt sted.
- **Advarsel!** Kan eksplodere dersom det kastes på åpen ild.
- Må ikke brukes i omgivelser som ikke dekkes av den gjeldende IP-vurderingen, hvis aktuelt, (inkludert for stor dybde og/eller trykk fra væske og/eller støv) eller utsettes for ekstrem fuktighet.

- For best mulig ytelse bør du ikke bruke produktet i temperaturer under  $-10^{\circ}\text{C}$  og over  $+45^{\circ}\text{C}$ . Ikke utsett batteriet for temperaturer over  $+60^{\circ}\text{C}$ . 
- Ikke utsett produktet for åpen ild eller tente sigaretter og lignende. 
- Ikke slipp ned, kast eller bøy produktet. 
- Ikke mal produktet eller prøv å demontere eller endre det. Service skal bare utføres av personell som er autorisert av Sony. 
- Hør med autorisert helsepersonell og les instruksene fra produsenten av det medisinske utstyret før du bruker produktet i nærheten av hjertestimulatorer eller annet medisinsk utstyr.
- Stopp bruken av elektroniske enheter eller deaktiver enhetens radiosender der dette er påkrevd, eller dersom du blir bedt om å gjøre det.
- Ikke bruk produktet på steder med eksplosjonsfare.
- Ikke legg produktet eller installer trådløst utstyr i området over bilens kollisjonspute.
- **Forsiktig:** Sprukne eller ødelagte displayer kan lage skarpe kanter eller fragmenter som kan være skadelige ved kontakt.
- Ikke bruk Bluetooth-hodetelefonen på en måte som føles ubekvem, eller slik at den utsettes for trykk og støt.
- Unngå kontakt med huden over lengre perioder. Varmen som genereres når enheten din sender signaler, kan irritere huden. Det anbefales å bruke hodetelefoner for lange telefonsamtaler.

## Barn

**Advarsel!** Oppbevares utilgjengelig for barn. Ikke la barn leke med mobile enheter eller tilbehør. De kan skade seg selv eller andre. Produktene kan inneholde små deler som kan løsne og utgjøre en kvelningsfare. 

## Strømtilførsel (lader)

Koble laderen til strømkilder som vist på produktet. Ikke lad produktet utendørs eller i fuktige omgivelser. Ikke modifier ledningen eller utsett den for skader eller slitasje. Koble fra enheten før du rengjør den. Du må aldri modifisere støpselet på noe vis. Hvis støpselet ikke passer i kontakten, må du få en elektriker til å

montere en kontakt som passer. Når en strømkilde er koblet til, brukes det en liten mengde strøm. Vil du unngå å sløse med strømmen, kobler du produktet fra strømkilden når det er helt oppladet. Bruk av ladere fra andre produsenter enn Sony kan medføre økt risiko.

## **Batteri**

Nye batterier eller batterier som ikke har blitt brukt på en stund, kan ha midlertidig nedsatt kapasitet. Lad batteriet helt opp før du bruker det for første gang. Batteriet skal brukes bare til det det er ment for. Lad batteriet i temperaturer mellom +5 °C og +45 °C. Ikke putt batteriet i munnen. Ikke la batterikontaktene komme i kontakt med andre metallobjekter. Slå av produktet før du tar ut batteriet. Batteriets ytelse avhenger av temperaturen, signalstyrken, hvordan du bruker enheten, hvilke funksjoner du bruker, samt hvor mye du bruker enheten til å snakke med andre eller overføre/motta data. Innebygde batterier skal bare fjernes eller erstattes av Sony servicepartnere. Bruk av batterier fra andre produsenter enn Sony kan medføre økt risiko. Batteriet skal erstattes bare med et annet Sony-batteri som er kompatibelt med produktet i henhold til IEEE-1725-standarden. Bruk av batterier som ikke er kompatible, kan medføre fare for brann, eksplosjon, lekkasjer eller annen fare.

## **Personlig medisinsk utstyr**

Mobile enheter/enheter med radiosendere kan påvirke implantert medisinsk utstyr. Reduser faren for forstyrrelser ved å opprettholde en avstand på minst 15 cm (6 tommer) mellom det medisinske utstyret og produktet fra Sony. Bruk enheten fra Sony mot det høyre øret, når dette er aktuelt. Du må ikke bære enheten i brystlommen. Slå av enheten dersom du mistenker at den forårsaker forstyrrelser. Hvis enheten skal benyttes i nærheten av personlige medisinske enheter, må du ta kontakt med en lege og produsenten av det medisinske utstyret.

## **Bilkjøring**

Enkelte produsenter forbyr bruk av mobile enheter i sine kjøretøy med mindre du bruker et håndfrisett med ekstern antenne. Hør med produsenten av kjøretøyet for å forsikre deg om at en mobil enhet eller Bluetooth-håndfrisettet ikke vil påvirke de elektroniske systemene i kjøretøyet. Du må alltid konsentrere deg fullt og helt om kjøringen og følge lokale lover og forskrifter angående bruken av trådløse enheter i trafikken.

## **GPS-/posisjonsbaserte funksjoner**

Noen produkter har GPS-/posisjonsbaserte funksjoner. Funksjonalitet som kan bestemme posisjonen, tilbys "som den er" og "med eventuelle mangler". Sony har ikke noe ansvar for og garanterer ikke for nøyaktigheten til slik posisjonsinformasjon.

Enhetens bruk av posisjonsbasert informasjon skjer kanskje ikke uten avbrudd eller feil og kan i tillegg være avhengig av nettdekningen. Vær oppmerksom på at funksjonaliteten kan bli redusert eller hindret i visse omgivelser, for eksempel inne i bygninger eller i områder nær bygninger.

Forsiktig: Ikke bruk GPS-funksjonaliteten på en slik måte at den reduserer oppmerksomheten din i trafikken.

## **Nødanrop**

Kontakt med mobilnettet kan ikke garanteres under alle forhold. Du må derfor aldri stole bare på mobile enheter fra Sony Mobile for viktig kommunikasjon. Du kan kanskje ikke ringe overalt, i alle mobilnett eller når visse nettjenester og/eller mobile funksjoner er i bruk. Merk at enkelte Sony-enheter ikke er kompatible med taleanrop, inkludert nødanrop.

## **Antenne**

Bruk av antenneenheter fra andre produsenter enn de som markedsføres av Sony kan skade enheten, redusere ytelsen og generere SAR-nivåer over de fastsatte grenseverdiene. Ikke dekk antennen med hånden. Dette reduserer lyd kvaliteten og signalstyrken og kan forkorte tale- og standby-tiden.

## **Radiostråling (RF) og SAR (Specific Absorption Rate)**

Når den mobile enheten eller Bluetooth-håndfrienheten er slått på utstråler den lave nivåer med radiostråling. Internasjonale sikkerhetsretningslinjer har blitt utarbeidet gjennom periodisk og grundig vurdering av vitenskapelige undersøkelser. Disse retningslinjene fastsetter tillatte grenseverdier for radiostråling. Retningslinjene har en sikkerhetsmargin som er ment å ivareta sikkerheten til alle og ta hensyn til eventuelle variasjoner i målinger.

SAR (Specific Absorption Rate) brukes for å måle mengden radiostråling som absorberes av kroppen ved bruk av en mobil enhet. SAR-verdien fastsettes på det høyeste sertifiserte strålenivået i et laboratorium, men fordi enheten er laget for å bruke så lite strøm som mulig for å tilgang til det valgte nettet, kan det faktiske SAR-nivået være vesentlig lavere enn denne verdien. Det finnes ikke bevis for at høye SAR-verdier utgjør en høyere risiko enn lave verdier.

Produkter med radiosendere som selges i USA, må være sertifisert av Federal Communications Commission (FCC). Når dette kreves, foretas det tester der enheten holdes mot øret, og når den bæres på kroppen. Tester av enheten når den bæres på kroppen, utføres ved at enheten testes når den bæres minst 15 mm fra kroppen uten noen metalldele i nærheten av enheten, eller når den brukes på riktig måte med tilhørende Sony-tilbehør mens den bæres på kroppen. Når den benyttes med funksjonaliteten "Hotspot" aktivert, ble en egen avstand på 10 mm benyttet.

Vil du vite mer om SAR og radiostråling, gå du til: <http://blogs.sonymobile.com/about-us/sustainability/health-and-safety/sar/>.

## Flymodus

Bluetooth- og WLAN-funksjonalitet, dersom enheten har dette, kan aktiveres i flymodus, men kan være forbudt å bruke om bord i fly eller på andre steder der bruk av radiosendere er forbudt. På slike steder må du ikke aktivere Bluetooth- eller WLAN-funksjonalitet i flymodus uten tillatelse.

## Skadelig programvare

Skadelig programvare (Malware) er programvare som kan skade enheten. Skadelig programvare kan omfatte virus, ormer, spionprogrammer og andre uønskede programmer. Selv om enheten har sikkerhetsfunksjoner som kan motstå skadelig programvare, garanterer eller hevder ikke Sony at enheten ikke kan rammes av skadelig programvare. Du kan imidlertid redusere risikoen for angrep fra skadelig programvare ved å være forsiktig når du laster ned innhold eller godtar programmer, avstå fra å åpne eller svare på meldinger fra ukjente avsendere, bruke pålitelige tjenester til å få tilgang til Internett og bare laste ned innhold til enheten fra kjente og sikre kilder.

## Tilbehør

Bruk bare originalt tilbehør fra Sony, og benytt bare sertifiserte servicepartnere. Sony tester ikke tilbehør fra tredjeparter. Tilbehør kan påvirke radiostråling, radiolytelse, lydvolum, elektrisk sikkerhet og andre områder. Tilbehør og deler fra tredjeparter kan redusere ytelsen eller medføre en fare for helse eller sikkerhet.

## Løsninger for personer med funksjonshemninger/spesialbehov

Du kan bruke teksttelefonterminalen din sammen med Sony Mobile-enheten. Du finner informasjon om tilgjengelighetsfunksjoner og løsninger for personer med spesialbehov på [blogs.sonymobile.com/about-us/sustainability/accessibility](http://blogs.sonymobile.com/about-us/sustainability/accessibility), eller du kan kontakte Sony Mobile på 1-866-766-9374.

## Kassering av gammelt elektrisk og elektronisk utstyr (gjelder for EU og andre europeiske land med separate innsamlingsystemer)



Dette symbolet på enheten eller emballasjen viser at denne enheten ikke skal behandles som husholdningsavfall. I stedet skal den leveres på det aktuelle innsamlingsstedet der elektrisk og elektronisk utstyr resirkuleres.

Når du sørger for at enheten kasseres på riktig måte, hjelper du med å hindre negative følger når det gjelder miljøet og menneskers helse som ellers kunne forårsakes av uegnet kassering av denne enheten. Resirkulering av materialer er med på å konservere naturressurser. Kontakt de lokale kommunale myndighetene, tjenesten som tar seg av husholdningsavfall eller butikken der du kjøpte enheten for å få flere opplysninger om resirkulering av denne enheten.

## **Minnekort**

Hvis produktet leveres med et uttakbart minnekort, er det generelt sett kompatibelt med enheten du har kjøpt, men det er ikke sikkert at det er kompatibelt med andre enheter eller funksjonene til minnekortene i disse enhetene. Kontroller kompatibiliteten med andre enheter før du kjøper eller bruker dem. Hvis produktet er utstyrt med en minnekortleser, bør du kontrollere at minnekortet er kompatibelt med produktet før du kjøper eller bruker kortet. Minnekort formateres vanligvis før de kommer i salg. Når du vil formatere minnekortet på nytt, må du bruke en kompatibel enhet. Ikke bruk operativsystemets standardformat når du skal formatere minnekortet på en datamaskin. Se i brukerveiledningen for enheten eller ta kontakt med kundestøtte hvis du vil ha mer informasjon.

## **SIM-kort**

Dersom enheten er utstyrt med et SIM-kortspor med standard størrelse, kan et SIM-kort som settes inn i SIM-kortsporet og som ikke er kompatibelt (f.eks. en mikro-SIM-kort, et mikro-SIM-kort uten Sony-adapter eller et standard SIM-kort kuttet ned til mikro-SIM-kortstørrelse) skade SIM-kortet eller enheten for bestandig. Sony går ikke god for og påtar seg ikke ansvar for eventuelle skader som forårsakes av ikke-kompatible eller endrede SIM-kort.

## **Advarsel**

Dersom enheten krever at du må bruke en adapter med enheten eller en annen enhet, må du ikke sette inn kortet direkte uten den nødvendige adapteren.

## **Forholdsregler ved bruk av minnekort**

- Ikke utsett minnekortet for fuktighet.
- Ikke ta på kontaktene eller la dem komme i kontakt med metallobjekter.
- Ikke bøy, slipp ned eller slå på minnekortet.
- Ikke prøv å demontere eller endre minnekortet.
- Ikke bruk eller lagre minnekortet i fuktige eller korroderende omgivelser, i høy temperatur, som f.eks. i en bil om sommeren, i direkte sollys eller nær varmeovner og lignende.
- Ikke trykk på eller bøy enden av minnekortadapteren med stor kraft.
- Ikke la smuss, støv eller fremmedlegemer komme inn i porten på minnekortadapteren.
- Kontroller at du har satt minnekortet riktig inn.

- Skyv minnekortet helt inn i en eventuell minnekortadapter. Hvis ikke minnekortet er satt helt inn, fungerer det kanskje ikke som det skal.
- Vi anbefaler at du tar sikkerhetskopier av viktige data. Vi er ikke ansvarlige for eventuelle tap av eller skade på innhold som du lagrer på minnekortet.
- Lagret informasjon kan skades eller gå tapt når du tar ut minnekortet eller minnekortadapteren, eller hvis du slår av strømmen mens du formaterer, leser eller skriver informasjon, eller når du bruker minnekortet på steder med statisk elektrisitet eller kraftige elektriske felt.

## **Beskyttelse av personlig informasjon**

Slett personlig informasjon før du kaster produktet. Nullstill enheten for å slette informasjon. Det kan være at informasjon kan gjenopprettes selv om den slettes fra enhetens minne. Sony gir ingen garantier mot gjenoppretting av informasjon og påtar seg intet ansvar for offentliggjøring av informasjon selv om enheten har blitt nullstilt.

## **For enheter som har 3D-visningskapasiteter**

Ved visning av 3D-bilder tatt med denne enheten, hvis mulig, og som vises på en skjerm med 3D-kapasiteter, er det mulig å oppleve ubehag i forbindelse med anstrengte øye, tretthet eller kvalme. Vi anbefaler at du tar regelmessige pauser for å hindre disse symptomene. Du må imidlertid selv bestemme hvor lange pauser du trenger og hvor ofte du trenger pauser da dette varierer fra person til person. Hold opp med å se på 3D-bilder til du føler deg bedre eller kontakt en lege om nødvendig dersom du opplever ubehag. Du kan også se i bruksanvisningen som fulgte med enheten eller programvaren som du har koblet til eller som du bruker på enheten. Vær oppmerksom på at barnas syn fremdeles er i utvikling (spesielt barn under 6 år). Kontakt en barnelege eller oftalmologist før du lar barn se på 3D-bilder, og sørg for at barnet overholder forholdsreglene ovenfor når de ser på slike bilder.

## **Advarsel om lydstyrke**

Unngå volumnivå som kan skade hørselen din.

## **Lisensavtale for sluttbruker**

Programvare som leveres sammen med denne enheten, og de tilhørende mediene eies av Sony Mobile Communications Inc., og/eller dets tilknyttede selskaper og dets leverandører og lisensgivere.

Sony gir deg en ikke-eksklusiv begrenset lisens til å bruke programvaren kun sammen med enheten den er installert på eller levert sammen med.



Eiendomsretten til programvaren blir ikke solgt, overført eller overdratt på annen måte.

Bruk ikke noen midler for å finne kildekoden eller noen annen komponent i programvaren, reprodusere og distribuere programvaren eller modifisere programvaren. Du har rett til å overføre rettigheter og forpliktelser angående programvaren til en tredjepart, kun sammen med enheten som du mottok programvaren sammen med, forutsatt at tredjeparten skriftlig samtykker i å være bundet av vilkårene i denne lisensen.

Denne lisensen gjelder i hele levetiden til denne enheten. Den kan opphøre ved at du skriftlig overfører rettighetene dine til enheten til en tredjepart.

Hvis du bryter noen av disse vilkårene, opphører lisensen umiddelbart.

Sony og Sonys tredjepartsleverandører og -lisensgivere beholder alle rettigheter, eiendomsrett og interesser i og til programvaren. I den utstrekning programvaren inneholder materiale eller kode tilhørende en tredjepart, skal slike tredjeparter være begunstiget av disse vilkårene.

Denne lisensen er underlagt lovgivningen i Japan. Der det kan anvendes, gjelder det foranstående for lovbestemte forbrukerrettigheter.

I tilfelle programvare som følger med eller leveres sammen med enheten din, kommer med flere vilkår, skal også slike vilkår styre din besittelse og bruk av programvaren.

## **Eksportforskrifter**

Eksportforskrifter: Enheten eller programmet kan være underlagt import- og eksportforskrifter i EU, USA og andre land. Du må følge disse lovene og reglene, og skal skaffe deg eventuell nødvendig eksport eller importlisens for leveringen av utstyret som en del av denne avtalen. Uten at det begrenser ovenforstående, og som et eksempel, skal du ikke med viten og vilje eksportere eller reeksportere varer til destinasjoner som identifiseres å komme inn under artiklene i kapittel II av Europaråd-forskrift (EC) 428/2009; og spesielt og uten begrensning skal du også følge eksportadministrasjonsforskriftene fra USAs myndigheter ("EAR", 15 C.F.R. §§ 730-774, <http://www.bis.doc.gov/>), som administreres av Handelsdepartementet, kontoret for industri og sikkerhet; og følge forskriftene om økonomiske sanksjoner (30 C.F.R. §§ 500 et. seq., <http://www.treas.gov/offices/enforcement/ofac/>), som administreres av USAs finansdepartement, kontoret for kontroll av utenlandske aktiva.

## **Begrenset garanti**

Sony Mobile Communications AB, SE-221 88 Lund, Sweden, eller dets lokale tilknyttede selskap, gir denne begrensede garantien på din mobile enhet, originalt tilbehør som ble levert med den mobile enheten og/eller ditt mobile databehandlingsprodukt, heretter kalt "Produkt").

Hvis produktet skulle ha behov for garantiservice, må du returnere det til forhandleren som produktet ble kjøpt hos, ta kontakt med ditt lokale Sony

kontaktsenter (nasjonale samtalekostander kan påløpe eller gå til [www.sonymobile.com](http://www.sonymobile.com) for mer informasjon.

## Vår garanti

Produktet er underlagt betingelsene i denne begrensede garantien, og Sony garanterer at dette produktet ikke har konstruksjonsmessige defekter med tanke på design, materiale og håndverk når produktet ble kjøpt av en forbruker første gang. Denne begrensede garantien vil gjelde i en periode på to (2) år fra original kjøpsdato for den mobile enheten, og i en periode på ett (1) etter original kjøpsdato når det gjelder alt tilleggsutstyr (slik som batterier, lader eller handfri) som kan ha blitt levert med enheten din.

## Hva vi vil gjøre

Hvis dette produktet skulle slutte å fungere i løpet av garantiperioden som en følge av defekter i design, materialer eller håndverk, vil Sony-autoriserte distributører eller servicepartnere i landet/regionen som du kjøpte produktet, i henhold til deres vurdering, enten reparere, erstatte eller refundere kjøpsprisen for produktet i henhold til betingelsene som er nevnt her.

Sony og dets servicepartnere forbeholder seg rettet til å kreve en avgift for håndteringen hvis det viser seg at produktet ikke er under noen garanti i henhold til betingelsene under.

Merk at enkelte av dine personlige innstillinger, nedlastinger eller annen informasjon kan forsvinne når ditt Sony-produkt blir reparert eller erstattet. I øyeblikket kan Sony være forhindret som følge av gjeldende lover og regler eller begrenset av tekniske hindringer fra å ta en sikkerhetskopi av innholdet. Sony tar ikke ansvar for tapt informasjon av noen art, og vil ikke kompensere for denne typen tap. Du må alltid sørge for sikkerhetskopier av all informasjon som er lagret på ditt Sony-produkt, slik som nedlastinger, kalender og kontaktinformasjon før du overlater ditt Sony-produkt til reparasjon eller bytte.

## Vilkår

1. Denne begrensede garantien er bare gyldig sammen med den originale kjøpskvitteringen utstedt av en autorisert Sony-forhandler, og hvor dato og serienummer\*\* er spesifisert. Sony forbeholder seg retten til å avvise garantiansvar hvis denne informasjonen har blitt fjernet eller endret etter at produktet ble kjøpt fra forhandleren.
2. Hvis Sony reparerer eller erstatter produktet, skal garantien for det reparerte eller erstattede produktet gjelde i den gjenværende tiden av den opprinnelige garantiperioden eller i nitti (90) dager fra reparasjonsdatoen. Den av disse

periodene som er lengst, blir den nye garantiperioden. Reparasjon eller erstatning kan skje med funksjonelt tilsvarende, nyoverholte enheter. Deler eller komponenter som byttes ut, blir Sonys eiendom.

3. Denne garantien dekker ikke produktfeil som er forårsaket av:

- Vanlig slitasje.
- Bruk i omgivelser som ikke dekkes av den gjeldende IP-vurderingen, hvis aktuelt, (inkludert væskeskader eller oppdagelse av væske inne i enheten på grunn av slik bruk).
- Misbruk eller bruk som ikke er i samsvar med Sonys instruksjoner for bruk og vedlikehold av produktet.

Garantien gjelder heller ikke feil ved produktet som skyldes ulykker, endringer eller tilpasninger i programvare eller maskinvare eller force majeure.

Et oppladbart batteri kan lades og utlades hundrevis av ganger. Det vil imidlertid etter hvert bli utslitt. Dette er ikke en feil, og kommer som en følge av den normale bruken og slitasjen. Når samtaltiden eller standby-tiden blir merkbart kortere, er det på tide å bytte ut batteriet. Sony anbefaler at du bare bruker batterier og ladere som er godkjent av Sony.

Enheter kan ha mindre variasjoner i lysstyrken i displayet og i farger. Det kan være små lyse eller mørke punkter på displayet. Dette oppstår når to individuelle punkter har feilet, og kan ikke justeres. To skadede piksler betraktes som akseptabelt.

Mindre variasjoner i bildene fra kameraet kan oppstå mellom enheter. Dette er ikke uvanlig og blir ikke betraktet som skade på kameramodulen.

4. Siden mobilsystemet som produktet skal brukes i, drives av en operatør

uavhengig av Sony, vil Sony ikke være ansvarlig for drift, tilgjengelighet, dekning, tjenester eller rekkevidde i forbindelse med dette systemet.

5. Denne garantien gjelder ikke skade på produktet som skyldes installasjoner,

endringer, reparasjoner eller åpning av produktet utført av personer som ikke er autorisert av Sony.

6. Garantien dekker ikke feil ved produktet som skyldes bruk av tilbehør eller andre eksterne enheter som ikke er originaltilbehør fra Sony, ment for bruk sammen med produktet.

Sony fraskriver seg alle garantier, uttalte eller indirekte, for feil på produktet som skyldes virus, trojanere, spionvare og ondsinnede programmer. Sony anbefaler på det sterkeste at du installerer egnet virusbeskyttelse på produktet og alle tilleggsenheter som er koblet til produktet hvis dette er mulig, og at denne virusbeskyttelsen oppdateres med jevne mellomrom for å beskytte enheten. Det er imidlertid forstått at denne typen programvare aldri vil kunne gi en total beskyttelse av produktet, og Sony frasier seg alle garantier, direkte

eller indirekte, som skyldes at denne typen programmer ikke greier å utføre oppgaven sin.

7. Hvis noen av forseglingene på produktet brytes, blir garantien ugyldig.
8. DET FINNES INGEN UTTRYKTE GARANTIER, VERKEN SKRIFTLIGE ELLER MUNTlige, BORTSETT FRA DENNE BEGRENSEDE GARANTIEN. ALLE INDIREKTE GARANTIER, SOM UTEN BEGRENSNING OMFATTER INDIREKTE GARANTIER FOR SALGBARHET ELLER SKIKKETHET FOR ET BESTEMT FORMÅL, ER BEGRENSET TIL VARIGHETEN AV DENNE BEGRENSEDE GARANTIEN. SONY ELLER DETS LISENSINNEHAVERE ER UNDER INGEN OMSTENDIGHETER ANSVARLIG FOR TILFELDIGE TAP ELLER FØLGETAP AV NOE SLAG, HERUNDER, MEN IKKE BEGRENSET TIL TAPT FORTJENESTE ELLER TAPT NÆRINGSVIRKSOMHET SÅ LANGT ANSVAR FOR SLIKE TAP KAN FRASKRIVES MED HJEMMEL I LOVEN.

Noen land/stater tillater ikke utelatelser eller begrensninger av følgeskade eller tilfeldig skade, eller begrensninger på varigheten av implisitte garantier, noe som kan medføre at de følgende begrensningene eller utelatelsene ikke gjelder for deg.

Den medfølgende garantien berører ikke forbrukerens lovbestemte rettigheter under anvendt nasjonal gjeldende lov, fastsatt i markedsføringsloven av 1972 og senere endringer, og heller ikke forbrukerens rettigheter overfor forhandler som følger av deres salgs-/kjøpskontrakt.

### **Landsspesifikke vilkår**

Hvis du har kjøpt produktet i et land som er medlem av det europeiske økonomiske samarbeidsområdet (EØS), eller i Sveits eller Tyrkia, og det aktuelle produktet var beregnet for salg i EØS eller Sveits eller Tyrkia, kan du få service på produktet ditt i ethvert EØS-land eller i Sveits eller Tyrkia, i henhold til garantivilkårene som gjelder i landet der du krever service, forutsatt at et identisk produkt selges i angjeldende land av en autorisert Sony-forhandler. Kontakt det lokale Sony-kontaktsenteret for å finne ut om produktet selges i landet du oppholder deg i. Det kan være at enkelte tjenester ikke er tilgjengelig andre steder enn i landet der produktet opprinnelig ble kjøpt, for eksempel fordi produktet kan ha indre eller ytre komponenter som er forskjellig fra tilsvarende modeller som selges i andre land. Vær også oppmerksom på at det i enkelte tilfeller ikke vil være mulig å reparere produkter der SIM-kortet er låst.

\*\* I enkelte land/regioner kan ytterligere informasjon (for eksempel gyldig garantikort) være påkrevd.

## Varemerker og opphavsrett

©2015 Sony Mobile Communications Inc. og dets tilknyttede selskaper. Med enerett.

Xperia er et varemerke eller registrert varemerke som tilhører Sony Mobile Communications Inc.

Sony er et varemerke eller et registrert varemerke som tilhører Sony Corporation.

Bluetooth er et varemerke eller et registrert varemerke som tilhører Bluetooth SIG Inc., og Sonys bruk av varemerket er i henhold til lisens.

Alle produkt- og firmanavn som nevnes i dette dokumentet, er varemerker eller registrerte varemerker for sine respektive eiere.

Alle rettigheter som ikke eksplisitt gis i dette dokumentet, er reservert. Se [www.sonymobile.com](http://www.sonymobile.com) hvis du vil vite mer.

[www.sonymobile.com](http://www.sonymobile.com)

**SONY®**

Sony Mobile Communications Inc.  
1-8-15 Konan, Minato-ku, Tokyo 108-0075, Japan

# SONY®

## Important information

©2015

## Sony Consumer Web site

At [www.sonymobile.com/support](http://www.sonymobile.com/support) there is a support section where help and tips are only a few clicks away. Here you will find the latest computer software updates and tips on how to use your product more efficiently.

## Service and support

You have access to a portfolio of exclusive service advantages such as:

- Global and local Web sites providing support.
- A global network of Contact Centers.
- An extensive network of Sony service partners.
- A warranty period. Learn more about the warranty conditions in the *Limited Warranty* section.

At [www.sonymobile.com/support](http://www.sonymobile.com/support) or [www.sonymobile.com/contact](http://www.sonymobile.com/contact), you can find the latest support tools and information. For operator-specific services and features, please contact your network operator.

You can also contact our Contact Centers or contact your local dealer. (Calls are charged according to national rates, including local taxes, unless it is a toll-free number.)

If your product needs service, please contact the dealer from whom it was purchased, or one of our service partners. To make a claim under the limited warranty, proof of purchase is required.

## Guidelines for Safe and Efficient Use

Please follow these guidelines. Failure to do so might entail a potential health risk or product malfunction. If in doubt as to its proper function, have the product checked by a certified service partner before charging or using it.



## Recommendations for care and safe use of our products

- Handle with care and keep in a clean and dust-free place.
- Warning! May explode if disposed of in fire.
- Do not use in environments where relevant IP rating limitations, if applicable, are exceeded (including excess depths and/or pressures of liquid and/or dust) or expose to excess humidity.
- For optimum performance, the product should not be operated in temperatures below  $-10^{\circ}\text{C}$ ( $+14^{\circ}\text{F}$ ) or above  $+45^{\circ}\text{C}$ ( $+113^{\circ}\text{F}$ ). Do not expose the battery to temperatures above  $+60^{\circ}\text{C}$ ( $+140^{\circ}\text{F}$ ).
- Do not expose to flames or lit tobacco products.
- Do not drop, throw or try to bend the product.





- Do not paint or attempt to disassemble or modify the product. Only Sony authorised personnel should perform service.
- Consult with authorised medical staff and the instructions of the medical device manufacturer before using the product near pacemakers or other medical devices or equipment.
- Discontinue use of electronic devices, or disable the radio transmitting functionality of the device, where required or requested to do so.
- Do not use where a potentially explosive atmosphere exists.
- Do not place the product, or install wireless equipment, in the area above an air bag in a car.
- Caution: Cracked or broken displays may create sharp edges or splinters that could be harmful upon contact.
- Do not use a Bluetooth Headset in positions where it is uncomfortable or will be subject to pressure.
- Avoid contact against your skin for longer periods. The heat generated when your device is transmitting can irritate your skin. It is recommended to use a headset for long phone calls.



## Children

Warning! Keep out of the reach of children. Do not allow children to play with mobile devices or accessories. They could hurt themselves or others. Products may contain small parts that could become detached and create a choking hazard.



## Power supply (Charger)

Connect the charger to power sources as marked on the product. Do not use outdoors or in damp areas. Do not alter or subject the cord to damage or stress. Unplug the unit before cleaning it. Never alter the plug. If it does not fit into the outlet, have a proper outlet installed by an electrician. When a power supply is connected there is a small drain of power. To avoid this small energy waste, disconnect the power supply when the product is fully charged. Use of charging devices that are not Sony branded may pose increased safety risks.

## Battery

New or idle batteries can have short-term reduced capacity. Fully charge the battery before initial use. Use for the intended purpose only. Charge the battery in temperatures between +5°C(+41°F) and +45°C(+113°F). Do not put the battery into your mouth. Do not let the battery contacts touch another metal object. Turn off the product before removing the battery. Performance depends on temperatures, signal strength, usage patterns, features selected and voice or data transmissions. Only Sony service partners should remove or replace built-in batteries. Use of batteries that are not Sony branded may pose increased

safety risks. Replace the battery only with another Sony battery that has been qualified with the product per the standard IEEE-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.

### **Personal medical devices**

Mobile devices / devices with radio transmitters may affect implanted medical equipment. Reduce risk of interference by keeping a minimum distance of 15 cm(6 inches) between the Sony product and the medical device. Use the Sony device at your right ear, when applicable. Do not carry the device in your breast pocket. Turn off the device if you suspect interference. For use in proximity to personal medical devices, please consult a physician and the device manufacturer.

### **Driving**

In some cases, vehicle manufacturers may forbid the use of mobile devices in their vehicles unless a handsfree kit with an external antenna supports the installation. Check with the vehicle manufacturer's representative to be sure that a mobile device or Bluetooth handsfree will not affect the electronic systems in the vehicle. Full attention should be given to driving at all times and local laws and regulations restricting the use of wireless devices while driving must be observed.

### **GPS/Location based functions**

Some products provide GPS/Location based functions. Location determining functionality is provided "As is" and "With all faults". Sony does not make any representation or warranty as to the accuracy of such location information.

Use of location-based information by the device may not be uninterrupted or error free and may additionally be dependent on network service availability. Please note that functionality may be reduced or prevented in certain environments such as building interiors or areas adjacent to buildings.

Caution: Do not use GPS functionality in a manner which causes distraction from driving.

### **Emergency calls**

Calls cannot be guaranteed under all conditions. Never rely solely upon Sony Mobile devices for essential communication. Calls may not be possible in all areas, on all networks, or when certain network services and/or mobile device features are used. Please note that some Sony devices are not capable of supporting voice calls, including emergency calls.

### **Antenna**

Use of antenna devices not marketed by Sony could damage the mobile device, reduce performance, and produce Specific Absorption Rate (SAR) levels above the established limits. Do not cover the antenna with your hand as this affects call quality, power levels and can shorten talk and standby times.

### **Radio Frequency (RF) exposure and Specific Absorption Rate (SAR)**

When the mobile device or Bluetooth handsfree functionality is turned on, it emits low levels of radio frequency energy. International safety guidelines have been developed through periodic and thorough evaluation of scientific studies. These guidelines establish permitted levels of radio wave exposure. The guidelines include a safety margin designed to assure the safety of all persons and to account for any variations in measurements.

Specific Absorption Rate (SAR) is used to measure radio frequency energy absorbed by the body when using a mobile device. The SAR value is determined at the highest certified

power level in laboratory conditions, but because the device is designed to use the minimum power necessary to access the chosen network, the actual SAR level can be well below this value. There is no proof of difference in safety based on difference in SAR value.

Products with radio transmitters sold in the US must be certified by the Federal Communications Commission (FCC). When required, tests are performed when the device is placed at the ear and when worn on the body. For body-worn operation, the device has been tested when positioned a minimum of 15 mm from the body without any metal parts in the vicinity of the device or when properly used with an appropriate Sony accessory and worn on the body. When operating with "Hotspot" functionality engaged, a separation distance of 10 mm was used.

For more information about SAR and radio frequency exposure, go to: <http://blogs.sonymobile.com/about-us/sustainability/health-and-safety/sar/>.

## Flight mode

Bluetooth and Wireless Local Area Network (WLAN) functionality, if available in the device, can be enabled in Flight mode but may be prohibited onboard aircraft or in other areas where radio transmissions are prohibited. In such environments, please seek proper authorisation before enabling Bluetooth or WLAN functionality even in Flight mode.

## Malware

Malware (short for malicious software) is software that can harm device. Malware or harmful applications can include viruses, worms, spyware, and other unwanted programs. While the device does employ security measures to resist such efforts, Sony does not warrant or represent that the device will be impervious to the introduction of malware. You can however reduce the risk of malware attacks by using care when downloading content or accepting applications, refraining from opening or responding to messages from unknown sources, using trustworthy services to access the Internet, and only downloading content to the mobile device from known, reliable sources.

## Accessories

Use only Sony branded original accessories and certified service partners. Sony does not test third-party accessories. Accessories may influence RF exposure, radio performance, loudness, electric safety and other areas. Third-party accessories and parts may pose a risk to your health or safety or decrease performance.

## Accessible Solutions/Special Needs

You can use your TTY terminal with your Sony Mobile device. For information on accessibility features and solutions for persons with special needs, please visit [blogs.sonymobile.com/about-us/sustainability/accessibility](http://blogs.sonymobile.com/about-us/sustainability/accessibility) or contact Sony Mobile at 1-866-766-9374.

## Disposal of Old Electrical and Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)



This symbol on the device or on its packaging indicates that this device shall not be treated as household waste. Instead it shall be handed over to the appropriate collection point for the recycling of electrical and electronic equipment.

By ensuring this device is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this device. The recycling of materials will help to conserve

natural resources. For more detailed information about recycling of this device, please contact your local Civic office, your household waste disposal service, or the shop where you purchased the device.

## **Memory card**

If the product comes complete with a removable memory card, it is generally compatible with the handset purchased but may not be compatible with other devices or the capabilities of their memory cards. Check other devices for compatibility before purchase or use. If the product is equipped with a memory card reader, check memory card compatibility before purchase or use.

Memory cards are generally formatted prior to shipping. To reformat the memory card, use a compatible device. Do not use the standard operating system format when formatting the memory card on a PC. For details, refer to the operating instructions of the device or Sony contact center.

## **SIM card**

If your device is equipped with a standard-sized SIM card slot, inserting an incompatible SIM card (for example, a micro SIM card, a micro SIM card with a non-Sony adapter, or a standard SIM card cut into a micro SIM card size) in the SIM card slot may damage your SIM card or your device permanently. Sony does not warrant and will not be responsible for any damage caused by use of incompatible or modified SIM cards.

## **Warning!**

If the device requires an adapter for insertion into the handset or another device, do not insert the card directly without the required adapter.

## **Precautions on memory card use**

- Do not expose the memory card to moisture.
- Do not touch terminal connections with your hand or any metal object.
- Do not strike, bend, or drop the memory card.
- Do not attempt to disassemble or modify the memory card.
- Do not use or store the memory card in humid or corrosive locations or in excessive heat such as a closed car in summer, in direct sunlight or near a heater, etc.
- Do not press or bend the end of the memory card adapter with excessive force.
- Do not let dirt, dust, or foreign objects get into the insert port of any memory card adapter.
- Check you have inserted the memory card correctly.
- Insert the memory card as far as it will go into any memory card adapter needed. The memory card may not operate properly unless fully inserted.
- We recommend that you make a backup copy of important data. We are not responsible for any loss or damage to content you store on the memory card.

- Recorded data may be damaged or lost when you remove the memory card or memory card adapter, turn off the power while formatting, reading or writing data, or use the memory card in locations subject to static electricity or high electrical field emissions.

### **Protection of personal information**

Erase personal data before disposing of the product. To delete data, perform a master reset. Deleting data from the memory of the device does not ensure that it cannot be recovered. Sony does not warrant against recovery of information and does not assume responsibility for disclosure of any information even after a master reset.

### **For Devices Supporting 3D Viewing capabilities**

In viewing 3D images shot with this device, if applicable, on a 3D-compatible monitor, you may experience discomfort in the form of eye strain, fatigue, or nausea. To prevent these symptoms, we recommend that you take regular breaks. However, you need to determine for yourself the length and frequency of breaks you require, as they vary according to the individual. If you experience any type of discomfort, stop viewing the 3D images until you feel better, and consult a physician as necessary. Also refer to the operating instructions supplied with the device or software you have connected or are using with this device. Note that a child's eyesight is still at the development stage (particularly children below the age of 6). Consult a pediatrician or ophthalmologist before letting your child view 3D images, and make sure he/she observes the above precautions when viewing such images.

### **Loudness warning!**

Avoid volume levels that may be harmful to your hearing.

### **End user licence agreement**

Software delivered with this device and its media is owned by Sony Mobile Communications Inc., and/or its affiliated companies and its suppliers and licensors.

Sony grants you a non-exclusive limited licence to use the software solely in conjunction with the device on which it is installed or delivered. Ownership of the software is not sold, transferred or otherwise conveyed.

Do not use any means to discover the source code or any component of the software, reproduce and distribute the software, or modify the software. You are entitled to transfer rights and obligations to the software to a third party, solely together with the device with which you received the software, provided the third party agrees in writing to be bound by the terms of this Licence.

This licence exists throughout the useful life of this device. It can be terminated by transferring your rights to the device to a third party in writing.

Failure to comply with any of these terms and conditions will terminate the licence immediately.

Sony and its third party suppliers and licensors retain all rights, title and interest in and to the software. To the extent that the software contains material or code of a third party, such third parties shall be beneficiaries of these terms.

This licence is governed by the laws of Japan. When applicable, the foregoing applies to statutory consumer rights.

In the event software accompanying or provided in conjunction with your device is provided with additional terms and conditions, such provisions shall also govern your possession and usage of the software.

## Export regulations

Export regulations: The device or software may be subject to import and export regulations of the European Union, the United States and other countries. You will comply with these applicable laws and regulations and will obtain and maintain any export and import license required for the delivery of goods to you under this Agreement. Without limiting the foregoing, and as an example, you will not knowingly export or re-export goods to destinations identified pursuant to Articles in Chapter II of European Council Regulation (EC) 428/2009 and specifically, and without limitation, you will also comply with U.S. government Export Administration Regulations ("EAR", 15 C.F.R. §§ 730-774, <http://www.bis.doc.gov/>) administered by Department of Commerce, Bureau of Industry and Security and economic sanctions regulations (30 C.F.R. §§ 500 et. seq., <http://www.treas.gov/offices/enforcement/ofac/>) administered by the U.S. Department of Treasury, Office of Foreign Assets Control.

## Limited Warranty

Sony Mobile Communications AB, SE-221 88 Lund, Sweden, or its local affiliated company, provides this Limited Warranty for your mobile device, original accessory delivered with your mobile device, and/or your mobile computing product (hereinafter referred to as "Product"). Should your Product need warranty service, please return it to the dealer from whom it was purchased, or contact your local Sony Contact Center (national rates may apply) or visit [www.sonymobile.com](http://www.sonymobile.com) to get further information.

## Our warranty

Subject to the conditions of this Limited Warranty, Sony warrants this Product to be free from defects in design, material and workmanship at the time of its original purchase by a consumer. This Limited Warranty will last for a period of two (2) years as from the original date of purchase of the Product for your mobile device, and for a period of one (1) year following the original purchase date of the Product for all original accessories (such as the battery, charger or handsfree kit) which may be delivered with your device.

## What we will do

If, during the warranty period, this Product fails to operate under normal use and service, due to defects in design, materials or workmanship, Sony authorised distributors or service partners, in the country/region\* where you purchased the Product, will, at their option, either repair, replace or refund the purchase price of the Product in accordance with the terms and conditions stipulated herein.

Sony and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads and other information may be lost when your Sony Product is repaired or replaced. At present, Sony may be prevented by applicable law, other regulation or technical restrictions from making a backup copy of certain downloads. Sony does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your Sony Product such as downloads, calendar and contacts before handing in your Sony Product for repair or replacement.

## Conditions

1. This Limited Warranty is valid only if the original proof of purchase for this Product issued by a Sony authorised dealer specifying the date of purchase and serial number\*\*, is

presented with the Product to be repaired or replaced. Sony reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.

2. If Sony repairs or replaces the Product, the repair for the defect concerned, or the replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sony.
3. This warranty does not cover any failure of the Product that is due to:
  - Normal wear and tear.
  - Use in environments where relevant IP rating limitations, if applicable, are exceeded (including liquid damage or the detection of liquid inside the device resulting from such use).
  - Misuse or failure to use in accordance with the Sony instructions for use and maintenance of the Product.

Nor does this warranty cover any failure of the Product due to accident, software or hardware modification or adjustment, or acts of God.

A rechargeable battery can be charged and discharged more than a hundred times. However, it will eventually wear out – this is not a defect and corresponds to normal wear and tear. When the talk-time or standby time is noticeably shorter, it is time to replace the battery. Sony recommends that you use only batteries and chargers approved by Sony.

Minor variations in display brightness and colour may occur between devices. There may be tiny bright or dark dots on the display. It occurs when individual dots have malfunctioned and can not be adjusted. Two defective pixels are deemed acceptable.

Minor variations in camera image appearance may occur between devices. This is nothing uncommon and is not regarded as a defective camera module.

4. Since the cellular system on which the Product is to operate is provided by a carrier independent from Sony, Sony will not be responsible for the operation, availability, coverage, services or range of that system.
5. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sony authorised person.
6. The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sony branded original accessories intended for use with the Product.

Sony disclaims any and all warranties, whether express or implied, for failures caused to the Product or peripheral devices as a result of viruses, trojan horses, spyware, or other malicious software. Sony strongly recommends that you install appropriate virus protection software on your Product and any peripheral devices connected to it, as available, and update it regularly, to better protect your device. It is understood, however, that such software will never fully protect your Product or its peripheral devices and Sony disclaims all warranties, whether express or implied, in case of failure by such antivirus software to fulfil its intended purpose.

7. Tampering with any of the seals on the Product will void the warranty.
8. THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONY OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The warranty provided does not affect the consumer's statutory rights under applicable legislation in force, nor the consumer's rights against the dealer arising from their sales / purchase contract.

### **Country specific terms**

If you have purchased your Product in a country member of the European Economic Area (EEA) or in Switzerland or the Republic of Turkey, and such Product was intended for sale in the EEA or in Switzerland or in Turkey, you can have your Product serviced in any EEA country or in Switzerland or in Turkey, under the warranty conditions prevailing in the country in which you require servicing, provided that an identical Product is sold in such country by an authorised Sony distributor. To find out if your Product is sold in the country you are in, please call the local Sony Contact Center. Please observe that certain services may not be available outside the country of original purchase, for example, due to the fact that your Product may have an interior or exterior which is different from equivalent models sold in other countries. Please note in addition that it may sometimes not be possible to repair SIM-locked Products.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. If you purchased your product in Australia, you are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For warranty service in Australia, please contact 1300 650 050 or Sony Service Centre, Unit 4 / 189 Woodville Road Villawood NSW 2163.

\*\* In some countries/regions additional information (such as a valid warranty card) may be requested.

### **Trademarks, acknowledgements and copyright**

©2015 Sony Mobile Communications Inc. and its affiliated entities. All rights reserved.

Xperia is a trademark or registered trademark of Sony Mobile Communications Inc.

Sony is a trademark or a registered trademark of Sony Corporation.

Bluetooth is a trademark or a registered trademark of Bluetooth SIG Inc. and any use of such mark by Sony is under license.



All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners.

Any rights not expressly granted herein are reserved. Visit [www.sonymobile.com](http://www.sonymobile.com) for more information.

[www.sonymobile.com](http://www.sonymobile.com)

**SONY®**

Sony Mobile Communications Inc.  
1-8-15 Konan, Minato-ku, Tokyo 108-0075, Japan

1222-9269.10