

CDX-CA810X US: page 26, FR: page 28

CDX-CA710X US: page 24, FR: page 26

Error displays/Messages

Error displays

FAILURE (Illuminates until any button is pressed)

The connection of speakers/amplifiers is incorrect.

→ See the installation guide manual of this model to check the connection.

FAILURE (Illuminates for about 1 second)

When the XM tuner is connected, storing an XM radio channel into a preset failed.

→ Be sure to receive the channel that you want to store, then try it again.

Affichage des erreurs et messages

Affichage des erreurs

FAILURE (Reste allumé jusque l'on appuie sur une touche)

Le raccordement des haut-parleurs ou de l'amplificateur est incorrect.

→ Reportez-vous au document d'installation de cet appareil et vérifiez le raccordement.

FAILURE (Reste allumé pendant environ 1 seconde)

Lorsque le tuner XM est connecté, la mémorisation d'une station radio XM sur un numéro présélectionné a échoué.

→ Vérifiez que vous recevez bien la station que vous souhaitez mémoriser, puis essayer de nouveau.
