

## Caution/Precaución/注意

### Before you insert a CD

Be sure to wait about 10 seconds before inserting a CD in the following circumstances:

- After resetting the unit
  - The next time the power is turned on after resetting the unit
- If a CD is inserted within 10 seconds in these cases, a malfunction could occur.

### To play back an 8 cm (3 in.) CD

Be sure to use the optional Sony compact disc single adapter (CSA-8). If you use an 8 cm CD without adapter, a malfunction could occur.

### Antes de insertar un CD

Asegúrese de esperar unos 10 segundos antes de insertar un CD en las siguientes circunstancias:

- Después de restaurar la unidad
- La próxima vez que active la alimentación después de restaurar la unidad

Si inserta un CD antes de que transcurran los 10 segundos en dichos casos, podría producirse un fallo de funcionamiento.

### Para reproducir un CD de 8 cm

Asegúrese de emplear el adaptador opcional de discos compactos sencillos de Sony (CSA-8). Si utiliza un CD de 8 cm sin adaptador, podría producirse un fallo de funcionamiento.

fb · i / J / @ - CD / § « e

“ ¥ † % T » { ¥ H / U - i “ p / U fb · i / CD - Si « e ¥ † ¶ • ¥ k 0 < ~ ` i G

— ¥ » † Q · \_ f « E

— ¥ » † Q · \_ f « E / U / @ f , „ q · % ¥ · ¶ } fi

> Y fb ¥ H / W - i “ p / U / @ B f b l 0 < ~ ` / § / “ † Q · i / J ; A « h f † ¥ i fl o ¥ ” < G » i C

> n ... % ' æ / @ - 8 cm CD fi

“ ¥ † % T » { « ¥ ¥ . ¿ ` S 0 f y p f i g “ - † / ø ´ · † C S A - 8 ¶

> Y fb ... % ' æ cm CD fi / f « ¥ ¥ . ’ · « „ i A « h f † ¥ i fl o ¥ ” < G » i C