

English**Note on the Timer function**

When using the Timer-recording function (page 15) or the Daily Timer function (page 19), make sure the clock is displayed while the system is off (see page 23).

Note on Power Saving Mode

When you switch the system to Power Saving Mode (page 23), the following information will be cleared.

- The disc number of the CD that was played last.
- The tracks programmed for Program Play (page 10).

Français**Remarque sur les fonctions Minuterie**

A l'emploi de la fonction Enregistrement par minuterie (page 15) ou de la fonction Minuterie de réveil (page 19), vérifiez que l'horloge est affichée quand la chaîne est hors tension (voir la page 23).

Remarque sur le mode Economie d'énergie

Quand vous commutez la chaîne au mode Economie d'énergie (page 23), les informations suivantes sont supprimées.

- Le numéro du CD lu en dernier
- Les plages programmées pour la Lecture programmée (page 10).

Español**Nota sobre las funciones del temporizador**

Cuando se utiliza la función de grabación con temporizador (página 15) o la función del temporizador diario (página 19), asegúrese de que aparece el reloj cuando el sistema está desactivado (vea la página 23).

Nota sobre el modo de ahorro de energía

Cuando se conmuta el sistema al modo de ahorro de energía (página 23), se borra la siguiente información.

- El número de disco del disco compacto reproducido en último lugar.
- Las canciones programadas para la reproducción programada (página 10).