

## Correction

Please correct the supplied Operating Instructions as follows:

### Page 47

Auto play

#### Incorrect

- **ON** to start playback by pressing ▷ PLAY, when the VCR is turned off with the tape inserted.
- **OFF** to turn off Auto play. You need to press I/⏏ and then ▷ PLAY to start playback, when the VCR is turned off with the tape inserted.

#### Correct

- **ON** to start playback automatically, when you insert a tape with its safety tab removed.
- **OFF** to turn off Auto play. You need to press ▷ PLAY to start playback, even if you insert a tape with its safety tab removed.

## Correction

Veillez corriger le mode d'emploi fourni comme suit :

### Page 49

Lecture auto

#### Incorrect

- **OUI** pour commencer la lecture en appuyant sur ▷ PLAY, lorsque le magnéscope est éteint avec la cassette insérée.
- **NON** pour désactiver la lecture auto. Vous devez appuyer sur I/⏏ puis sur ▷ PLAY pour commencer la lecture, lorsque le magnéscope est éteint avec la cassette insérée.

#### Correct

- **OUI** pour commencer la lecture automatiquement lorsque vous introduisez une cassette protégée.
- **NON** pour désactiver la lecture auto. Vous devez appuyer sur ▷ PLAY pour commencer la lecture, même si vous introduisez une cassette protégée.