

# USB クレードル

## 取扱説明書

## Operating Instructions

お買い上げいただきありがとうございます。

**警告** 電気製品は安全のための注意事項を守らないと、火災や人身事故になることがあります。

この取扱説明書をよくお読みのうえ、製品を安全にお使いください。お読みになったあとは、いつでも見られるところに必ず保管してください。

# CLiÉ

## PEGA-UC600

Sony Corporation © 2001 Printed in Japan

## 警告 安全のために

ソニー製品は安全に十分配慮して設計されています。しかし、電気製品はすべて、まちがった使いかたをすると、火災や感電などにより人身事故になることがあります。事故を防ぐために次のことを必ずお守りください。

### 安全のための注意事項を守る

この「安全のために」の注意事項をよくお読みください。

### 故障したら使わない

すぐにお買い上げ店またはソニーサービス窓口にご依頼ください。

### 万一、異常が起きたら



- ACアダプターをコンセントから抜く
- お買い上げ店またはソニーサービス窓口にご依頼する。

### CLIEホームページ

CLIEを楽しく使っていただくための情報をご案内します。

● <http://www.sony.co.jp/CLIE/>

### ネットコミュニケーション カスタマーリンク ホームページ

CLIEを楽しく使っていただくための情報をご案内します。

● <http://www.nccl.sony.co.jp/>

ソニー株式会社 〒141-0001 東京都品川区北品川6-7-35
使い方のご相談、技術的なお問い合わせは ネットコミュニケーション カスタマーリンクへ ● 0466-30-3080
カスタマー登録、一般的なお問い合わせは ソニーカスタマー専用デスクへ ● 03-5977-7255

<http://www.sony.net/>  
Printed on recycled paper

### 警告表示の意味

取扱説明書および製品では、次のような表示をしています。表示の内容をよく理解してから本文をお読みください。

- 警告** この表示の注意事項を守らないと、火災・感電などにより死亡や大けがなど人身事故の原因となります。
- 注意** この表示の注意事項を守らないと、感電やその他の事故によりけがをしたり周辺の家財に損害を与えたりすることがあります。

注意を促す記号	行為を禁止する記号	行為を指示する記号
火災	禁止	プラグをコンセントから抜く
感電	水ぬれ禁止	指示
	分解禁止	
	ぬれ手禁止	

**警告** 下記の注意を守らないと**火災・感電**により**死亡**や**大けが**の原因となります

湿気やほこり、油煙、湯気の多い場所では使わない  
上記のような場所で使うと、火災や感電の原因となります。



分解や改造をしない

火災や感電の原因となります。内部の点検や修理はお買い上げ店またはソニーサービス窓口にご依頼ください。



内部に水や異物を入れない

水や異物が入ると火災や感電の原因となります。万一、水や異物が入ったときは、ACアダプターをコンセントから抜いて、お買い上げ店またはソニーサービス窓口にご相談ください。



雷が鳴り出したらACアダプターに触れない  
感電の原因となります。



**注意** 下記の注意を守らないと**けが**をしたり周辺の**家財に損害**を与えたりすることがあります。

指定以外の機器に使わない

火災やけがの原因となることがあります。



ぬれた手でACアダプターをさわらない

感電の原因となることがあります。



長期間使用しないときは、ACアダプターをはずす  
長期間使用しないときはACアダプターをコンセントから抜いてください。火災の原因となることがあります。



安定した場所に置く

ぐらついた台の上や傾いたところなどに置くと、製品が落ちてけがの原因となることがあります。



コード類は正しく配置する

コード類は足に引っ掛けたりして引っばると製品の落下や転倒などによりけがの原因となることがあるため、十分注意して接続・配置してください。  
また、コードをACアダプターに巻き付けしないでください。断線や故障の原因になります。



通電中のACアダプターに長時間ふれない

温度が相当上がることがあります。長時間皮膚がふれたままになっていると、低温やけどの原因となることがあります。



ACアダプターを布団などでおおった状態で使わない  
熱がこもってケースが変形したり、火災の原因となることがあります。



コネクタの先端の突起部に注意する

ACアダプターのコネクタ先端部の突起に指などを引っかけないようにご注意ください。



・ CLIEはソニー株式会社の商標です。

・ HotSyncは、Palm, Inc.またはその子会社の登録商標であり、Palm Desktop、HotSyncのロゴは、Palm, Inc.またはその子会社の商標です。  
・ その他、本書に記載されているシステム名、製品名は、一般に各開発メーカーの登録商標または商標です。なお、本文中ではTM、®マークは明記していません。

## はじめに

USBクレードルの使い方については、お使いのソニーCLIEに付属の取扱説明書もあわせてご覧ください。

## 主な仕様

### USBクレードル

最大外形寸法	約80×51×77 mm(幅/高さ/奥行)
質量	約142 g
接続コードの長さ	約2 m
動作温度	5 ~ 35

### ACアダプター

入力	AC100 V ~ 240 V、50-60 Hz
出力	DC5.2 V、2000 mA
質量	約150 g
接続コードの長さ	約1.8 m

### ACコード

質量	約50 g
コードの長さ	約0.8 m

### 付属品

USBクレードル(1)、ACアダプター(1)、ACコード(1)、取扱説明書(1)、保証書(1)* ソニーご相談窓口のご案内(1)*
--

仕様および外観は、改良のため予告なく変更することがありますが、ご了承ください。

\*一部の国と地域でお買い上げの製品には付属していない場合があります。

## 使用上のご注意

### 置いてはいけない場所

使用中、保管中にかかわらず、次のような場所に置かないでください。故障の原因になります。

- ・ 異常に高温になる場所  
炎天下や夏場の窓を閉め切った自動車内は特に高温になり、放置すると変形したり、故障したりすることがあります。
- ・ 直射日光の当たる場所、熱器具の近く  
変形したり、故障したりすることがあります。
- ・ 激しい振動のある場所
- ・ 強力な磁気のある場所
- ・ 砂地、砂浜などの砂ぼこりの多い場所

海辺や砂地、あるいは砂ぼこりが起こる場所などでは、砂がかからないようにしてください。故障の原因になるばかりか、修理できなくなることもあります。

使用について

- 強い衝撃を与えたり、落としたりしないでください。
- TVやAMラジオやチューナーの近くで使わないでください。TVやラジオ、チューナーに雑音が入ることがあります。
- 使用後は必ずACアダプターをコンセントから抜いておいてください。
- アダプター本体やコード類の接点部に他の金属類が触れないようにしてください。ショートすることがあります。
- ACアダプターを海外旅行者用の「電子式変圧器」などに接続しないでください。発熱や故障の原因となります。

お手入れについて

- 汚れがついたときは、柔らかい布やティッシュペーパーなどで、きれいに拭き取ってください。汚れがひどいときは、水でうすめた中性洗剤に柔らかい布をひたし、固くしぼってから汚れを拭き取り、乾いた布で仕上げてください。
- アルコール、シンナー、ベンジンなどは使わないでください。変質したり、塗装がはげたりすることがあります。
- 化学ぞうきんをご使用の際は、その注意書きに従ってください。
- 殺虫剤のような揮発性のものをかけたり、ゴムやビニール製品に長時間接触させると、変質したり、塗装がはげたりすることがあります。

# 保証書とアフターサービス

## 保証書

- この製品は保証書が添付されていますので、お買い上げの際、お買い上げ店からお受け取りください。
- 所定事項の記入および記載内容をお確かめのうえ、大切に保存してください。
- 保証期間は、お買い上げ日より1年間です。

## アフターサービス

調子が悪いときはまずチェックを

この取扱説明書をもう1度ご覧になってお調べください。

それでも具合の悪いときはサービスへ

お買い上げ店、または「ソニーご相談窓口のご案内」にあるお近くのソニーサービスの窓口にご相談ください。

保証期間中の修理は

保証書の記載内容に基づいて修理させていただきます。ただし、故障の原因が不当な分解や改造であると判明した場合は、保証期間内であっても有償修理とさせていただきます。詳しくは保証書をご覧ください。

保証期間経過後の修理は

修理によって機能が維持できる場合は、ご希望により有料で修理させていただきます。

部品の交換について

この製品は修理の際に交換した部品を再生、再利用する場合があります。その際、交換した部品は回収させていただきます。

部品の保有期間について

当社ではUSBクレードルの補修用性能部品(製品の機能を維持するために必要な部品)を、製造打ち切り後6年間保有しています。この部品保有期間を修理可能の期間とさせていただきます。保有期間が経過したあとも、故障箇所によっては修理可能な場合がありますので、ネットコミュニケーション カスタマーリンク(ソニーPDA専用サポートセンター)にご相談ください。

ご相談になるときは次のことをお知らせください。

- 型名：PEGA-UC600
- 故障の状態：できるだけ詳しく
- 購入年月日：

English

## WARNING

**To prevent fire or shock hazard, do not expose the unit to rain or moisture.**

**To avoid electric shock, do not open the cabinet. Refer servicing to qualified personnel only.**

**Owner’s Record**

The model and lot numbers are located on the bottom of your USB cradle. Record the lot number in the space provided below. Refer to the model and lot numbers when you call your Sony dealer regarding this product.

Model No. PEGA-UC600  
Lot No. \_\_\_\_\_

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including any interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Rules of the FCC.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe B est conforme a la norme NMB-003 du Canada.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

The socket-outlet shall be installed near the equipment and shall be easily accessible.

- CLiÉ is a trademark of Sony Corporation.
- HotSync is a registered trademark of Palm, Inc. or its subsidiaries.
- All other trademarks are trademarks of their respective owners.

## Before use

The USB cradle is used to charge the device and to transfer data between the device and a computer.

The USB cradle is used to charge the device and to transfer data between the device and a computer.

For details on how to use the USB cradle, please read the Operating Instructions provided with your CLiÉ handheld and this Operating Instructions manual.

## Specifications

<b>USB Cradle</b>	
<b>Dimensions</b>	Approx. 3 1/4×2 1/8×3 1/8 inches (w/h/d) (Approx. 80×51×77 mm)
<b>Mass</b>	Approx. 5 oz. (142 g)
<b>Cord length</b>	Approx. 78 3/4 inches (2 m)
<b>Operating temperature</b>	41°F to 95°F (5°C to 35°C)

<b>AC Adapter</b>	
<b>Input</b>	100 ~ 240 V AC, 50 - 60 Hz
<b>Output</b>	5.2 V DC, 2000 mA
<b>Mass</b>	Approx. 5 oz. (150 g)
<b>Cord length</b>	Approx. 70 7/8 inches (1.8 m)

<b>AC Cord</b>	
<b>Mass</b>	Approx. 2 oz. (50 g)
<b>Cord length</b>	Approx. 31 1/2 inches (0.8 m)

<b>Supplied accessories</b>	
	USB cradle (1)
	AC adapter (1)
	AC cord (1)
	Operating Instructions (1)
	Warranty Card (1)*

Design and specifications are subject to change without notice.
\* Depending on the country or region where you bought this product, this may not be supplied.

## Notes on use

Do not place the unit in locations that are extremely hot or cold, dusty or dirty, very humid, vibrating, subject to strong magnetic fields, sandy, or exposed to direct sunlight.

- Do not place the unit in locations that are:
  - Extremely hot or cold
  - Dusty or dirty
  - Very humid
  - Vibrating
  - Subject to strong magnetic fields
  - Sandy
  - Exposed to direct sunlight
- Do not apply mechanical shock or drop the unit.
- Unplug the AC adapter from the AC outlet when not in use for a long time. To disconnect the power cord, pull it out by the plug. Never pull the cord itself.
- Be sure that nothing metallic comes into contact with the metal parts of this unit. If this happens, a short circuit may occur and the unit may be damaged.
- Do not operate the unit with a damaged cord or if it has been dropped or damaged.
- Always keep the metal contacts clean.
- Do not disassemble or modify the unit.
- While the unit is in use, it gets warm. This is normal.
- Keep the unit away from TV or AM receivers, as it may disturb reception.

**Cleaning**

Clean the unit with a soft dry cloth, or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent, such as alcohol or benzine, which may damage the finish.