



		Camera Body														
		NEX-VG10 NEX-VG20	DSC-HX50V DSC-HX50 DSC-RX100M2 NEX-VG30 NEX-VG900	DSC-HX60V DSC-HX60 DSC-HX400V DSC-HX400 DSC-RX10 DSC-RX1 DSC-RX1R	NEX-3 NEX-C3 NEX-F3 NEX-3N NEX-5 NEX-5N NEX-5T NEX-5R ILCE-5000	NEX-7	NEX-6 ILCE-3000 ILCE-6000 ILCE-7R ILCE-7	DSLR-A100	DSLR-A200 DSLR-A300 DSLR-A350 DSLR-A700	DSLR-A230 DSLR-A290 DSLR-A330 DSLR-A380 DSLR-A500 DSLR-A550 DSLR-A560 DSLR-A580	DSLR-A850 DSLR-A900	SLT-A33 SLT-A35 SLT-A55V	SLT-A58	SLT-A37 SLT-A57 SLT-A65V SLT-A77V	SLT-A99V	
Flash Function	Compatibility	Usable	Usable	Usable	Not Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	
	Attaching	Yes	Yes(*4)	Yes(*4)	No	Yes(*2,3)	Yes(*4)	Yes	Yes	Yes	Yes	Yes	Yes(*4)	Yes	Yes(*4)	
	Burst	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	Program Reset	No	No	No	No	No	No	No	No	No	No	No	No	No	No	
	Flash Metering	ADI flash metering	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	OK
		P-TTL flash metering	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	OK
		TTL flash metering	No	No	No	No	No	No	No	N/A	No	No	No	No	No	NO
	Auto Zoom	No	No	No	No	No	No	No	No	No	No	No	No	No	N/A	No
	Flash Range Display	No	No	No	No	No	No	No	No	No	No	No	No	No	No	
	HSS (High-Speed Sync)	No	No	No	No	No	No	No	No	No	No	No	No	No	N/A	No
	Wireless/Remote HSS	No	No	No	No	No	No	No	No	No	No	No	No	No	N/A	No
	Wireless/Remote flash	No	No	No	No	No	No	No	No	No	No	No	No	No	N/A	No
	Wireless controller	No	No	Yes (*1)	No	Yes (*1)	Yes (*1)	No	No	No	No	Yes (*1)	No	Yes (*1)	Yes (*1)	Yes (*1)
	Wireless Ratio	Controller Flash	No	No	No	No	No	No	No	No	No	No	No	No	N/A	N/A
		Remote Flash	No	No	No	No	No	No	No	No	No	No	No	No	N/A	N/A
	Slow sync.	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes
	Modeling	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	Multiple flash	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	Manual flash	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	AF illuminator	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
Auto zoom control optimized for image sensor size	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	
Auto WB Adjustment with Color Temperature Info	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
Red-Eye Reduction	Yes	Yes	Yes	No	Yes	Yes	No	No	Yes	Yes	No	Yes	Yes	Yes	Yes	
FEL Lock	No	No	No	No	No	No	No	No	No	No	No	No	No	No	Yes(*5)	

\*1 In addition, wireless remote flashes are necessary.

\*2 Some of the E-mount lens operation may be interfered with a flash body when the flash is in OFF position.

\*3 Not recommended to use this flash when A-mount lens is attached ,because the flash may interfere with the lens.

\*4 Requires Shoe adaptor (included with camera) or Shoe adaptor ADP-MAA (optional).

\*5 It can be used only as a wireless controller, and cannot be used as a remote flash in wireless flash mode.