

HVL-RL1



		Camera Name										
		NEX-VG10 NEX-VG20 NEX-VG30	NEX-VG900 NEX-6	NEX-3 NEX-C3 NEX-F3 NEX-3N NEX-5T NEX-5R NEX-5N NEX-5	NEX-7	DSC-HX400V DSC-HX400 DSC-RX1 DSC-RX1R	DSC-HX50V DSC-HX50 DSC-HX60V DSC-HX60 DSC-RX10 DSC-RX100M2	ILCE-5000	ILCE-3000 ILCE-6000 ILCE-7 ILCE-7R	DSLR-A100 DSLR-A200 DSLR-A230 DSLR-A290 DSLR-A300 DSLR-A330 DSLR-A350 DSLR-A380 DSLR-A390 DSLR-A500 DSLR-A550 DSLR-A560 DSLR-A580 DSLR-A700 DSLR-A850 DSLR-A900	SLT-A33 SLT-A35 SLT-A37 SLT-A55 SLT-A55V SLT-A57 SLT-A58 SLT-A65 SLT-A65V SLT-A77 SLT-A77V	SLT-A58 SLT-A99V
Camera Function	Compatibility	Not Usable	Usable	Usable	Usable	Usable	Not Usable	Usable	Usable	Usable	Usable	Usable
	Attaching	No	Yes	Yes (*1)	Yes (*2)	Yes	No	Yes (*1)	Yes	Yes (*2)	Yes (*2)	Yes
	Lighting	No	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes

*1 – Requires Bracket VCT-55LH. (optional)

*2 – Requires Shoe adaptor (included with accessory) or Shoe adaptor ADP-AMA (optional).