

PROGRAM / MAXXUM® 1800AF



		Konica Minolta™	2181	2186	2098	2162	2166	2165	2169	2163	2164	2153	2154	2155	2152	2089	2097	2151	2092	
		Japan	Alpha™-7 DIGITAL	AlphaSweet DIGITAL	Alpha-9	Alpha-7	Alpha-70	Dynax™ 3L	-	Alpha-SweetII	Alpha-SweetIII	Alpha-Sweet	-	Alpha-SweetS	Alpha-807si	Alpha-707si	Alpha-507si	Alpha-303si SUPER	Alpha-303si	
		Euro	Dynax 7D	Dynax 5D	Dynax 9	Dynax 7	Dynax 60	Dynax 3L	Dynax 30/40	Dynax 5	Dynax 3	Dynax 505Si Super	Dynax 505Si	Dynax 404Si	Dynax 800si	Dynax 700si	Dynax 600si	Dynax 500si SUPER	Dynax 500si	
		USA	Maxxum 7D	Maxxum 5D	Maxxum 9	Maxxum 7	Maxxum 70	Maxxum 3	Maxxum 50	Maxxum 5	Maxxum 4	Maxxum XTSi	Maxxum HTSi	Maxxum STSi	Maxxum 800si	Maxxum 700si	Maxxum 600si	Maxxum 500si	Maxxum 400si	
Flash Function	Compatibility		Not Recommended	Not Recommended	Usable	Usable	Usable	Not Usable	Not Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	
	Attaching		Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	No	No	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)	Yes (*1)
	Burst		Yes	Yes	Yes	Yes	Yes			Yes	Yes									
	Program Reset		No	No	No	No	No			No	No									
	Flash Metering	ADI flash metering		No	No	No	No			No	No									
		P-TTL flash metering		No	No	No	No			No	No									
		TTL flash metering		No	No	Yes	Yes			Yes	Yes									
	Auto Zoom		No	No	No	No	No			No	No									
	Flash Range Display		No	No	No	No	No			No	No									
	HSS (High-Speed Sync)		No	No	No	No	No			No	No									
	Wireless/Remote HSS		No	No	No	No	No			No	No									
	Wireless/Remote flash		No	No	No	No	No			No	No									
	Slow sync.		Yes	Yes	Yes	Yes	Yes			Yes	Yes									
	Modeling		No	No	No	No	No			No	No									
	Multiple flash		No	No	No	No	No			No	No									
	Manual flash		No	No	No	No	No			No	No									
	AF illuminator		No	No	No	No	No			No	No									
FEL Lock		No	No	No	No	No	No			No										

Not Recommended - The flash can be attached by using the Konica Minolta FS-1100 Flash Shoe Adapter. However, the Auto Focus illuminator is not available and overexposure is likely to occur due to incompatibility with the flash metering system.

*1 - It is available with Flash Shoe Adapter FS-1100 (Konica Minolta made).

PROGRAM / MAXXUM 1800AF



Konica Minolta	2156	2099	2181	2082 (2096)	2084 (2093)	2085 (2094)	2095	2087	2075	2076	2077	2078	2071	2072	2073	2101	2102
Japan	Alpha-360si	Alpha-101si	Alpha-9xi	Alpha-7xiP /7xi	Alpha-5xiP /5xi	Alpha-3xiP /3xi	Alpha-2Xi	Alpha-SPXi	Alpha-8700i	Alpha-7700i	Alpha-5700i	Alpha-3700i	Alpha-9000	Alpha-7000	Alpha-5000	Vectis S-1	Vectis S-100
Euro	Dynax 303si	Dynax 300si	Dynax 9xi	Dynax 7xi	Dynax 5xi	Dynax 3xi	Dynax 2Xi	Dynax SPXi	Dynax 8000i	Dynax 7000i	Dynax 5000i	Dynax 3000i	Dynax 9000	Dynax 7000	Dynax 5000	Vectis S-1	Vectis S-100
USA	Maxxum QTsi	Maxxum 350si	Maxxum 9xi	Maxxum 7xi	Maxxum 5xi	Maxxum 3xi	Maxxum 2Xi	Maxxum SPXi	Maxxum 8000i	Maxxum 7000i	Maxxum 5000i	Maxxum 3000i	Maxxum 9000	Maxxum 7000	Maxxum 5000	Vectis S-1	Vectis S-100

Flash Function	Compatibility			Usable	Usable	Usable	Usable	Not Usable												
	Attaching			Yes (*1)	Yes	Yes	Yes	Yes (*1)	No											
	Burst			Yes	Yes	Yes	Yes	Yes												
	Program Reset			No	No	No	No	No												
	Flash Metering	ADI flash metering		No	No	No	No	No												
		P-TTL flash metering		No	No	No	No	No												
		TTL flash metering		Yes	Yes	Yes	Yes	Yes												
	Auto Zoom			No	No	No	No	No												
	Flash Range Display			No	No	No	No	No												
	HSS (High-Speed Sync)			No	No	No	No	No												
	Wireless/Remote HSS			No	No	No	No	No												
	Wireless/Remote flash			No	No	No	No	No												
	Slow sync.			Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No		Yes
	Modeling			No	No	No	No	No		No										
	Multiple flash			No	No	No	No	No		No										
	Manual flash			No	No	No	No	No		No										
AF illuminator			No	No	No	No	No	No	No	No	No	No	No	Yes	Yes	Yes	No			
FEL Lock			No	No	No	No	No	No	No	No	No	No	No	No	No	No	No			

*1 - It is available with Flash Shoe Adapter FS-1100 (Konica Minolta made).

[<< Back to top](#)