

HVL-MT24AM



Camera Body													
NEX-VG10 NEX-VG20 NEX-VG30	NEX-VG900	DSC-HX50V DSC-HX50 DSC-HX60V DSC-HX60 DSC-HX400V DSC-HX400 DSC-RX10 DSC-RX100M2	DSC-RX1 DSC-RX1R	NEX-3 NEX-C3 NEX-F3 NEX-3N NEX-5 NEX-5N NEX-5R NEX-5T ILCE-5000	NEX-7	NEX-6 ILCE-3000 ILCE-6000 ILCE-7 ILCE-7R	DSLR-A100 DSLR-A200 DSLR-A230 DSLR-A290 DSLR-A300 DSLR-A330 DSLR-A350 DSLR-A380 DSLR-A390 DSLR-A500 DSLR-A550 DSLR-A560 DSLR-A580 DSLR-A700 DSLR-A850 DSLR-A900	SLT-A33 SLT-A35 SLT-A37 SLT-A55V SLT-A57	SLT-A58	SLT-A65V SLT-A77V	SLT-A99V		

Flash Function	Compatibility		Not Usable	Usable	Not Usable	Usable	Not Usable	Usable	Usable	Usable	Usable	Usable	Usable	
	Attaching		No	Yes(*3)	No	Yes(*3)	No	Yes	Yes(*3)	Yes	Yes	Yes(*3)	Yes	Yes(*3)
	Burst		No	Yes	No	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Program Reset		No	No	No	No	No	No	No	No	No	No	No	No
	Flash Metering	ADI flash metering	No	No	No	No	No	No	No	No	No	No	No	No
		P-TTL flash metering	No	Yes	No	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes(*2)	Yes
		TTL flash metering	No	No	No	No	No	No	No	No	No	No	No	No
	Auto Zoom		No	No	No	No	No	No	No	No	No	No	No	No
	Flash Range Display		No	No	No	No	No	No	No	No	No	No	No	No
	HSS (High-Speed Sync)		No	No	No	No	No	No	No	No	No	No	No	No
	Wireless/Remote HSS		No	No	No	No	No	No	No	No	No	No	No	No
	Wireless/Remote flash		No	No	No	No	No	No	No	No	No	No	No	No
	Slow sync.		No	Yes	No	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes(*2)	Yes
	Modeling		No	Yes	No	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Multiple flash		No	No	No	No	No	No	No	No	No	No	No	No
	Manual flash		No	Yes(*1)	No	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
AF illuminator		No	No	No	No	No	No	No	No	No	No	No	No	
FEL Lock		No	No	No	No	No	No	No	No	No	No	No	No	

*1 It is available by setting the recording mode that can use the manual flash mode with custom setting on the flash unit.

*2 It is available with the camera firmware Ver.1.03 or later.

*3 Requires Shoe adaptor (included with camera) or Shoe adaptor ADP-MAA (optional).