

HVL-F56AM



Camera Body															
NEX-VG10	NEX-VG20	NEX-VG30 NEX-VG900	DSC-HX50V DSC-HX50 DSC-RX100M2	DSC-HX60V DSC-HX60 DSC-HX400V DSC-HX400 DSC-RX10 DSC-RX1 DSC-RX1R	NEX-3 NEX-C3 NEX-F3 NEX-3N NEX-5 NEX-5N NEX-5R NEX-5T ILCE-5000	NEX-7	NEX-6 ILCE-3000 ILCE-6000 ILCE-7 ILCE-7R	DSLR-A100 DSLR-A200 DSLR-A230 DSLR-A290 DSLR-A300 DSLR-A330 DSLR-A350 DSLR-A380 DSLR-A390 DSLR-A500 DSLR-A550 DSLR-A560 DSLR-A580 DSLR-A700 SLT-A33 SLT-A35	DSLR-A850 DSLR-A900	SLT-A37 SLT-A57	SLT-A55V	SLT-A58	SLT-A65V SLT-A77V	SLT-A99V	

Flash Function	Compatibility	Usable	Usable	Usable	Usable	Usable	Not Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	
	Attaching	Yes	Yes	Yes(*6)	Yes(*6)	Yes(*6)	No	Yes	Yes(*6)	Yes	Yes	Yes	Yes	Yes(*6)	Yes	Yes(*6)
	Burst	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Program Reset	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	Flash Metering	ADI flash metering	No	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
		P-TTL flash metering	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		TTL flash metering	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	Auto Zoom	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Flash Range Display	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	HSS (High-Speed Sync)	No	Yes	Yes	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Wireless/Remote HSS	No	No	No	No	No	No	Yes (*3)	Yes (*3)	Yes	Yes (*3)	Yes	Yes(*5)	Yes	Yes	Yes (*3)
	Wireless/Remote flash	No	No	No	No	Yes (*3)	No	Yes (*3)	Yes (*3)	Yes	Yes (*3)	Yes	Yes	Yes	Yes	Yes (*3)
	Wireless Ratio	Controller Flash	No	No	No	No	No	No	No	No	No	No	No	No	No	No
		Remote Flash	No	No	No	No	Yes (*2,4)	Yes (*2,4)	Yes (*2,4)	No	Yes (*2,4)	Yes (*2,4)	N/A	Yes (*2,4)	Yes (*2,4)	Yes (*2,4)
	Slow sync.	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Modeling	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Multiple flash	Yes	Yes(*1)	Yes(*1)	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
Manual flash	Yes	Yes(*1)	Yes(*1)	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
AF illuminator	No	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
FEL Lock	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	

*1 It is available by setting the recording mode that can use the manual flash mode with custom setting on the flash unit.

*2 In addition, wireless controller (HVL-F43AM, HVL-F58AM, HVL-F60M or HVL-F43M) is necessary.

*3 In addition, wireless controller (HVL-F20AM, HVL-F43AM, HVL-F58AM, HVL-F60M, HVL-F20M or HVL-F43M) is necessary.

*4 It cannot be used to the lighting ratio of 3 groups.

*5 Overexposure or underexposure may occur when the shutter speed is 1/200 sec. or faster It is supported by updating the camera firmware Ver. 2.00 or later.

*6 Requires Shoe adaptor (included with camera) or Shoe adaptor ADP-MAA (optional).