

HVL-F36AM



Camera Body														
NEX-VG10 NEX-VG20	NEX-VG30 NEX-VG900	DSC-HX50 DSC-HX50V DSC-RX100M2	DSC-HX60V DSC-HX60 DSC-HX400V DSC-HX400 DSC-RX10 DSC-RX1 DSC-RX1R	NEX-3 NEX-3N NEX-C3 NEX-F3 NEX-5 NEX-5N NEX-5T NEX-5R ILCE-5000	NEX-7	NEX-6 ILCE-3000 ILCE-6000 ILCE-7 ILCE-7R	DSLR-A100 DSLR-A200 DSLR-A230 DSLR-A290 DSLR-A300 DSLR-A330 DSLR-A350 DSLR-A380 DSLR-A390 DSLR-A500 DSLR-A550 DSLR-A560 DSLR-A580 DSLR-A700	DSLR-A850 DSLR-A900	SLT-A33 SLT-A35	SLT-A37 SLT-A57 SLT-A65V SLT-A77V	SLT-A55V	SLT-A58	SLT-A99V	

Flash Function	Compatibility		Usable	Usable	Usable	Usable	Not Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	
	Attaching		Yes	Yes(*5)	Yes(*5)	Yes(*5)	No	Yes	Yes(*5)	Yes	Yes	Yes	Yes	Yes(*5)	Yes(*5)
	Burst		Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Program Reset		No	No	N/A	N/A	No	No	No	N/A	N/A	N/A	N/A	N/A	N/A
	Flash Metering	ADI flash metering	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
		P-TTL flash metering	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		TTL flash metering	No	No	No	No	No	No	No	N/A	N/A	N/A	N/A	N/A	N/A
	Auto Zoom		Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Flash Range Display		No	No	No	No	No	No	No	No	No	No	No	No	No
	HSS (High-Speed Sync)		Yes	Yes	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Wireless/Remote HSS		No	No	No	No	No	Yes (*2)	Yes (*2)	Yes	Yes (*2)	Yes	Yes	Yes(*4)	Yes (*2)
	Wireless/Remote flash		No	No	No	Yes (*2)	N/A	Yes (*2)	Yes (*2)	Yes	Yes (*2)	Yes	Yes	Yes	Yes (*2)
	Wireless Ratio	Controller Flash	No	No	No	No	No	No	No	N/A	N/A	N/A	N/A	N/A	N/A
		Remote Flash	No	No	No	Yes (*1,3)	N/A	Yes (*1,3)	Yes (*1,3)	N/A	Yes (*1,3)	N/A	Yes (*1,3)	N/A	Yes (*1,3)
	Slow sync.		Yes	Yes	Yes	Yes	N/A	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Modeling		No	No	No	No	No	No	No	No	No	No	No	No	No
	Multiple flash		No	No	No	No	No	No	No	No	No	No	No	No	No
Manual flash		No	No	No	No	No	No	No	No	No	No	No	No	No	
AF illuminator		No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	
FEL Lock		No	No	No	No	No	No	No	N/A	N/A	N/A	N/A	N/A	N/A	

*1 In addition, wireless controller (HVL-F43AM ,HVL-F58AM ,HVL-F60M or HVL-F43M) is necessary.

*2 In addition, wireless controller (HVL-F20AM,HVL-F43AM, HVL-F58AM, HVL-F60M,HVL-F20M or HVL-F43M) is necessary.

*3 It cannot be used to the lighting ratio of 3 groups.

*4 Overexposure or underexposure may occur when the shutter speed is 1/200 sec. or faster (Updated on xx/xx, 2010). It is supported by updating the camera firmware Ver.2.00 or later. (2011/6/xx)

*5 Requires Shoe adaptor (included with camera) or Shoe adaptor ADP-MAA (optional).