



HVL-F43M

		Camera Body																		
		NEX-VG10	NEX-VG20	NEX-VG30 NEX-VG900	NEX-7	NEX-5 NEX-5N NEX-5T NEX-5R NEX-3 NEX-C3 NEX-F3 NEX-3N ILCE-5000	NEX-6 ILCE-3000 ILCE-6000 ILCE-7R ILCE-7	DSC-HX50V DSC-HX50 DSC-RX100M2	DSC-HX60V DSC-HX60 DSC-HX400V DSC-HX400 DSC-RX10 DSC-RX1 DSC-RX1R	SLT-A33 SLT-A35	SLT-A55 SLT-A55V	SLT-A58	SLT-A37 SLT-A57 SLT-A65 SLT-A65V SLT-A77 SLT-A77V	SLT-A99 SLT-A99V	DSLR-A100	DSLR-A200 DSLR-A300 DSLR-A350	DSLR-A230 DSLR-A290 DSLR-A330 DSLR-380 DSLR-A390 DSLR-A500 DSLR-A550 DSLR-A560 DSLR-A580	DSLR-A700	DSLR-A850 DSLR-A900	
Camera Function	Compatibility	Usable	Usable	Usable	Usable	Not Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	
	Attaching	Yes (*7)	Yes (*7)	Yes	Yes (*7)	No	Yes	Yes	Yes	Yes (*7)	Yes (*7)	Yes	Yes (*7)	Yes	Yes (*7)	Yes (*7)	Yes (*7)	Yes (*7)	Yes (*7)	
	Burst	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Program Reset	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	Flash Metering	ADI flash metering	No	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		P-TTL flash metering	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		TTL flash metering	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	Auto Zoom	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Flash Range Display	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	HSS (High-Speed Sync)	No	Yes	Yes	Yes	No	Yes	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Wireless/Remote HSS	No	No	No	Yes (*5)	No	Yes (*5)	No	No	Yes	Yes(*6)	Yes	Yes	Yes (*5)	Yes	Yes	Yes	Yes	Yes	Yes (*4)
	Wireless/Remote flash	No	No	No	Yes (*5)	No	Yes (*5)	No	Yes (*5)	Yes	Yes	Yes	Yes	Yes (*5)	Yes	Yes	Yes	Yes	Yes	Yes (*4)
	Wireless controller	No	No	No	Yes (*2)	No	Yes (*2)	No	Yes (*2)	No	No	Yes (*2)	Yes (*2)	Yes (*2)	No	No	No	No	No	Yes (*2)
	Wireless Ratio	Controller Flash	No	No	No	Yes (*2)	No	Yes (*2)	No	Yes (*2)	No	No	Yes (*2)	Yes (*2)	Yes (*2)	No	No	No	Yes (*2)	Yes (*2)
		Remote Flash	No	No	No	Yes (*3)	No	Yes (*3)	No	Yes (*3)	No	No	Yes (*3)	Yes (*3)	Yes (*3)	No	No	No	Yes (*3)	Yes (*3)
	Slow sync.	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Modeling	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Multiple flash	Yes	Yes(*1)	Yes(*1)	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Manual flash	Yes	Yes(*1)	Yes(*1)	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	AF illuminator	No	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Auto zoom control optimized for image sensor size	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes
	Auto WB Adjustment with Color Temperature Info	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes
	Red-Eye Reduction	Yes	Yes	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	No	No	Yes	No	No
Flash Compensation	No	No	Yes	No	No	Yes	Yes	Yes	Yes	No	No	Yes	No	Yes	No	No	No	No	No	
FEL Lock	No	No	No	No	No	No	No	No	No	No	No	No	Yes	No	No	No	No	No	No	

\*1 – It is available by setting the recording mode that can use the manual flash mode with custom setting on the flash unit.

\*2 – In addition, wireless remote flashes are necessary.

\*3 – In addition, wireless controller (HVL-F43AM ,HVL-F58AM ,HVL-F60M or HVL-F43M) is necessary.

\*4 – In addition, wireless remote flash or wireless controller (HVL-F20AM,HVL-F43AM, HVL-F58AM, HVL-F60M,HVL-F20M or HVL-F43M) is necessary.

\*5 – In addition, wireless controller (HVL-F20AM,HVL-F43AM, HVL-F58AM, HVL-F60M,HVL-F20M or HVL-F43M) is necessary.

\*6 – Overexposure or underexposure may occur when the shutter speed is 1/200 sec. or faster. (Updated on xx/xx, 2010)

\*7 – Requires Shoe adaptor (included with accessory) or Shoe adaptor ADP-AMA (optional).