

**PROGRAM / MAXXUM® 2500 (D)**



Camera Name									
NEX-VG30/ NEX-VG30H/ NEX-VG900/ NEX-EA50UH	NEX-VG10/ NEX-VG20/ NEX-VG20H/	DSC-HX400V/ DSC-HX400/ DSC-HX60V/ DSC-HX50V/ DSC-RX100M2/ DSC-RX10/ DSC-RX1R/ DSC-RX1	ILCE-3000/ ILCE-5000/ ILCE-6000/ ILCE-7R/ ILCE-7	NEX-3/ NEX-3N/ NEX-5/ NEX-5N/ NEX-5R/ NEX-5T/ NEX-6/ NEX-C3/ NEX-F3	NEX-7	SLT-A58/ SLT-A99V	SLT-A33/ SLT-A35/ SLT-A37/ SLT-A55V/ SLT-A57/ SLT-A65V/ SLT-A77V	DSLR-A100/ DSLR-A200/ DSLR-A230/ DSLR-A290/ DSLR-A300/ DSLR-A330/ DSLR-A350/ DSLR-A380/ DSLR-A390/ DSLR-A500/ DSLR-A550/ DSLR-A560/ DSLR-A580/ DSLR-A700/ DSLR-A850/ DSLR-A900	

Flash Function	Compatibility	Not Usable	Usable	Not Usable	Not Usable	Not Usable	Usable	Not Usable	Usable	Usable
	Attaching	No	Yes	No	No	No	Yes	No	Yes	Yes
	Burst		Yes				Yes			
	Program Reset		No				No			
	Flash Metering		ADI flash metering				No		No	
			P-TTL flash metering				Yes		Yes	
			TTL flash metering				No		No	
	Auto Zoom		No				No			
	Flash Range Display		No				No			
	HSS (High-Speed Sync)		No				No			
	Wireless/Remote HSS		No				No			
	Wireless/Remote flash		No				No			
	Slow sync.		Yes				Yes			
	Modeling		No				No			
	Multiple flash		No				No			
	Manual flash		No				No			
	AF illuminator		No				No		Yes	Yes
FEL Lock	No	No	No	No						