

PROGRAM / MAXXUM® 3600HS(D)



		Camera Name																
		NEX-VG900/ NEX-VG30/ NEX-VG30H/ NEX-EA50UH	NEX-VG10/ NEX-VG20/ NEX-VG20H/	DSC-HX400V/ DSC-HX400/ DSC-HX60V/ DSC-RX10/ DSC-RX1R/ DSC-RX1	DSC-HX50V/ DSC-RX100M2	ILCE-7R/ ILCE-7/ ILCE-3000/ ILCE-6000	ILCE-5000	NEX-6	NEX-7	NEX-5T/ NEX-5R/ NEX-5N/ NEX-5/ NEX-3N/ NEX-F3/ NEX-C3/ NEX-3	SLT-A99V	SLT-A58	SLT-A77V/ SLT-A57/ SLT-A65V/ SLT-A37	SLT-A55V	SLT-A35/ SLT-A33	DSLR-A560/ DSLR-A390/ DSLR-A290/ DSLR-A550/ DSLR-A500/ DSLR-A380/ DSLR-A330/ DSLR-A230/ DSLR-A200/ DSLR-A300/ DSLR-A350/ DSLR-A700/ DSLR-A100	DSLR-A850/ DSLR-A900	
Flash Function	Compatibility	Usable	Usable	Usable	Usable	Usable	Not Usable	Usable	Usable	Not Usable	Usable	Usable	Usable	Usable	Usable	Usable	Usable	
	Attaching	Yes(*5)	Yes	Yes(*5)	Yes(*5)	Yes(*5)	No	Yes(*5)	Yes	No	Yes(*5)	Yes(*5)	Yes	Yes	Yes	Yes	Yes	
	Burst	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	Program Reset	N/A	N/A	N/A	N/A	N/A	No	N/A	N/A	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
	Flash Metering	ADI flash metering	N/A	N/A	N/A	N/A	N/A	No	N/A	N/A	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		P-TTL flash metering	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes
		TTL flash metering	N/A	N/A	N/A	N/A	N/A	No	N/A	N/A	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A
	Auto Zoom	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	Flash Range Display	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	
	HSS (High-Speed Sync)	Yes	Yes	N/A	N/A	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
	Wireless/Remote HSS	N/A	N/A	N/A	N/A	Yes (*2)	No	Yes (*2)	Yes (*2)	No	Yes (*2)	Yes	Yes	Yes	Yes(*14)	Yes	Yes	Yes (*2)
	Wireless/Remote flash	N/A	N/A	Yes (*2)	N/A	Yes (*2)	No	Yes (*2)	Yes (*2)	No	Yes (*2)	Yes	Yes	Yes	Yes	Yes	Yes	Yes (*2)
	Wireless Ratio	Controller Flash	N/A	N/A	N/A	N/A	N/A	No	N/A	N/A	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A
		Remote Flash	N/A	N/A	Yes (*1,3)	N/A	Yes (*1,3)	No	Yes (*1,3)	Yes (*1,3)	No	Yes (*1,3)	Yes (*1,3)	Yes (*1,3)	N/A	N/A	N/A	Yes (*1,3)
	Slow sync.	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
	Modeling	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	Multiple flash	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
Manual flash	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	
AF illuminator	N/A	N/A	N/A	N/A	N/A	No	N/A	N/A	No	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	
FEL Lock	N/A	N/A	N/A	N/A	N/A	No	N/A	N/A	No	N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	

*1 – In addition, wireless controller (HVL-F43AM ,HVL-F58AM ,HVL-F60M or HVL-F43M) is necessary.

*2 – In addition, wireless controller (HVL-F20AM,HVL-F43AM, HVL-F58AM, HVL-F60M,HVL-F20M or HVL-F43M) is necessary.

*3 – It cannot be used to the lighting ratio of 3 groups.

*4 – Overexposure or underexposure may occur when the shutter speed is 1/200 sec. or faster. (Updated on xx/xx, 2010). It is supported by updating the camera firmware Ver.2.00 or later. (2011/6/xx).

*5 – Requires Shoe adaptor (included with camera) or Shoe adaptor ADP-MAA (optional).