

PROGRAM / MAXXUM® 5600HS(D)



		Camera Name																
		NEX-VG900/ NEX-VG30/ NEX-VG30H/ NEX-EA50UH	NEX-VG20/ NEX-VG20H/	NEX-VG10	DSC-HX400V/ DSC-HX400/ DSC-HX60V/ DSC-RX10/ DSC-RX1R/ DSC-RX1	DSC-HX50V/ DSC-RX100M2	ILCE-7R/ ILCE-7/ ILCE-3000/ ILCE-6000	ILCE-5000	NEX-6	NEX-7	NEX-5T/ NEX-5R/ NEX-5N/ NEX-5/ NEX-3N/ NEX-F3/ NEX-C3/ NEX-3	SLT-A99V	SLT-A58	SLT-A77V/ SLT-A57/ SLT-A65V/ SLT-A37	SLT-A55V	SLT-A35/ SLT-A33	DSLR-A560/ DSLR-A390/ DSLR-A290/ DSLR-A550/ DSLR-A500/ DSLR-A380/ DSLR-A330/ DSLR-A230/ DSLR-A200/ DSLR-A300/ DSLR-A350/ DSLR-A700/ DSLR-A100	DSLR-A850/ DSLR-A900
Flash Function	Compatibility	Usable	Usable	Usable	Usable	Usable	Usable	Not Usable	Usable	Usable	Not Usable	Usable	Usable	Usable	Usable	Usable	Usable	
	Attaching	Yes(*6)	Yes	Yes	Yes(*6)	Yes(*6)	Yes(*6)	No	Yes(*6)	Yes	No	Yes(*6)	Yes(*6)	Yes	Yes	Yes	Yes	
	Burst	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	
	Program Reset	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	
	Flash Metering	ADI flash metering	No	No	No	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes
		P-TTL flash metering	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes
		TTL flash metering	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
	Auto Zoom	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	
	Flash Range Display	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	
	HSS (High-Speed Sync)	Yes	Yes	No	No	No	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	
	Wireless/Remote HSS	No	No	No	No	No	Yes (*3)	No	Yes (*3)	Yes (*3)	No	Yes (*3)	Yes	Yes	Yes(*5)	Yes	Yes	
	Wireless/Remote flash	No	No	No	Yes (*3)	No	Yes (*3)	No	Yes (*3)	Yes (*3)	No	Yes (*3)	Yes	Yes	Yes	Yes	Yes	
	Wireless Ratio	Controller Flash	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No
		Remote Flash	No	No	No	Yes (*2,4)	No	Yes (*2,4)	No	Yes (*2,4)	Yes (*2,4)	No	Yes (*2,4)	Yes (*2,4)	Yes (*2,4)	No	No	
	Slow sync.	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	
	Modeling	Yes	Yes	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	
	Multiple flash	Yes(*1)	Yes(*1)	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes	
Manual flash	Yes(*1)	Yes(*1)	Yes	Yes	Yes	Yes	No	Yes	Yes	No	Yes	Yes	Yes	Yes	Yes	Yes		
AF illuminator	No	No	No	No	No	No	No	No	No	No	Yes	Yes	Yes	Yes	Yes	Yes		
FEL Lock	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No	No		

*1 – It is available by setting the recording mode that can use the manual flash mode with custom setting on the flash unit.

*2 – In addition, wireless controller (HVL-F43AM ,HVL-F58AM ,HVL-F60M or HVL-F43M) is necessary.

*3 – In addition, wireless controller (HVL-F20AM,HVL-F43AM, HVL-F58AM, HVL-F60M,HVL-F20M or HVL-F43M) is necessary.

*4 – It cannot be used to the lighting ratio of 3 groups.

*5 – Overexposure or underexposure may occur when the shutter speed is 1/200 sec. or faster. (Updated on xx/xx, 2010). It is supported by updating the camera firmware Ver.2.00 or later. (2011/6/xx).

*6 – Requires Shoe adaptor (included with camera) or Shoe adaptor ADP-MAA (optional).