

About sound that might be recorded as noise

Sounds that cause noise



The IC recorder may record various sounds other than voice, and the sounds will be heard as noise.

- Sounds that occur when you touch the IC recorder (touch noise)
- Rustling sounds of your clothes (when putting the IC recorder in your pocket)
- Vibration sounds (when putting the IC recorder on a desk or a piano, etc.)
- Noise from air conditioner, projector, PC, etc.
- Extra ambient sounds (when recording a lecture or a lesson)
- Breath hitting the microphone when recording near your mouth (pop noise)
- Noise caused when recording in long play recording mode ("LP" mode, etc.)

To reduce the recording noise

- Touch noises may be recorded when you touch the IC recorder during recording. Try to avoid touching the IC recorder until the recording ends.
- Move the IC recorder far from the sound source, or eliminate the noise.
- Select the best recording mode according to the situation. We recommend you to set the recording mode to the high-quality mode ("HQ" mode, "SHQ" mode, etc.) when you are concerned about ambient noise.
- Select the best microphone sensitivity according to the situation. Please try to lower the setting of the microphone sensitivity when the ambient sounds become noise and it is not easy to hear the target sound.

For details about the settings of the recording mode and the microphone sensitivity installed on the IC recorder, refer to the supplied operating instructions.

See "Techniques for Better Recording" on the reverse side of this paper.



Techniques for Better Recording

The IC recorder allows you to record in a variety of situations. This section introduces easy recording setup for 4 typical scenes.

To record a meeting




💡 Tips for setup

- The noise of vibration, etc., transmitted from the desk can be reduced by putting a handkerchief under the IC recorder.
- Record near the speaker.

MODE	SHQ (Super high-quality monaural recording mode)
-------------	--

SENS	🎙️H
-------------	-----

To record a lecture or a lesson



💡 Tip for setup

- Turn the built-in microphone in the direction of the sound source to be recorded. Or use a directional microphone (not supplied).

MODE	SHQ (Super high-quality monaural recording mode)
-------------	--

SENS	🎙️H
-------------	-----

To record voice memos or dictation



💡 Tips for setup

- When recording, hold the IC recorder beside your mouth to avoid breathing into the built-in microphone.
- When you record holding the IC recorder in your hand, please note that the sounds from touching the IC recorder (touch noise) are not recorded.

MODE	SP (Standard play monaural recording mode)
-------------	--

SENS	🎙️L
-------------	-----

To record in your pocket



💡 Tips for setup

- The rustling noise of your clothes can be reduced by putting a handkerchief, etc. in your pocket to hold the IC recorder.
- You can use the stereo microphone with shirt-clip (not supplied) to reduce the noise further.

MODE	SP (Standard play monaural recording mode)
-------------	--

SENS	🎙️L
-------------	-----

For better recording and playback

- To obtain the best recording results, perform a trial recording in advance.
- The IC recorder is equipped with a noise cut function. The noise cut function reduces the noise, therefore you can hear the recorded message more clearly.