

HOME THEATRE SYSTEM

HT-SL800/HT-SL700

Speaker Connection 扬声器连接

English

This Speaker Connection explains how to connect the DVD player, TV, speakers, and sub woofer so you can enjoy multi channel surround sound from the DVD player. For details, refer to the operating instructions supplied with the receiver.

Before you connect the speakers, attach the supplied colour labels near the speaker terminals. The front speaker terminals are located at the bottom of the front speaker base. Connect the speakers as shown in the illustration at right.

The speakers and the sub woofer are magnetically shielded to allow it to be installed near a TV set.

中文

本扬声器连接说明怎样连接DVD播放机、电视机、扬声器和副低音扬声器以便欣赏来自DVD播放机的多声道环绕声。详情参考接收机附带的操作说明。

连接扬声器以前，请将附带的彩色标签附置於扬声器端子附近。前扬声器端子位於前扬声器基座的底部。请如右图所示连接扬声器。

扬声器及副低音扬声器被磁性封蔽以便它可被安置在电视机附近。

