


SONY®

Before using the Wall-Mount Bracket

Attach the VESA Plate to your TV as illustrated below to mount the TV on the wall safely and securely. For instructions on using the Wall-Mount Bracket with your TV please go to <http://esupport.sony.com> for your TV model and download "Additional Information for Using Sony Wall-Mount Bracket".



4-262-657-11(1)

