

Quick Setup Guide 快速設定指南

HT-M7

Sony Corporation © 2012 Printed in Malaysia

English **Traditional Chinese**

1 Installing and connecting the speakers

You can install all the speakers in front position or install the surround and surround back speakers in rear position.

When you install the surround back speakers in rear position, we recommend that you put the surround back speakers on the speaker stands (not supplied).

When connecting the speaker cords, match the color of the connector to the color label under the SPEAKERS terminal on the receiver.

A Speaker cord (supplied)*

* Connect grey wire to the positive (+) speaker terminal and black wire to the negative (-) speaker terminal.

安裝和連接揚聲器



您可以將所有揚聲器安裝在前面位置或將環繞和後置環繞揚聲器安裝在後面位置。

當您將後置環繞揚聲器安裝在後面位置時，建議您將後置環繞揚聲器放在揚聲器支架（無附帶）上。


連接揚聲器線時，將連接器的顏色與接收器上 SPEAKERS 端子下的顏色標籤相匹配。

A 揚聲器線（附帶）*

* 將灰色導線連接至揚聲器端子的正 (+) 極，將黑色導線連接至揚聲器端子的負 (-) 極。



For details, refer to the Operating Instructions.
有關詳情，請參閱使用說明書。



2

Connecting video equipment


- B** HDMI cable (not supplied)
- C** Audio cord (not supplied)*

* If your TV is compatible with Audio Return Channel (ARC) function, this connection is not needed.

連接視頻設備

- B** HDMI 連接線（無附帶）
- C** 音頻線（無附帶）*

* 如果電視機與音頻回傳信道（ARC）功能相容，則無需該連接。



3

Preparing the receiver

I/⏻: on/standby

* The shape of AC power cord (mains lead) and AC outlet varies depending on the area.

準備接收器

I/⏻: 開/待機

* 交流電源線和交流電源插座的形狀因區域而有所不同。

