

SONY®

How to use / 使用方法 / 사용 방법

Stereo Headphones

Operating Instructions

使用說明書


사용설명서



* 4 4 6 3 7 7 6 2 2 * (1)

4-463-776-22(1)

MDR-ZX310



Do the same for the left side.


對左側執行相同的操作。

왼쪽도 동일하게 하십시오.

Check the **Ⓜ** mark on the right side.

確認右側的 **Ⓜ** 標記。

오른쪽의 **Ⓜ** 표시를 확인하십시오.





Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

Specifications

Type: Closed, dynamic / **Driver unit:** 30 mm, dome type (CCA W Voice Coil) / **Power handling capacity:** 1,000 mW (IEC*) / **Impedance:** 24 Ω at 1 kHz / **Sensitivity:** 98 dB/mW / **Frequency response:** 10 Hz - 24,000 Hz / **Cord:** 1.2 m (Y-type) / **Plug:** Gold-plated L-shaped stereo mini plug / **Mass:** Approx. 125 g without cord

* IEC = International Electrotechnical Commission

Design and specifications are subject to change without notice.

Precautions



High volume may affect your hearing.
For traffic safety, do not use while driving or cycling.

Optional replacement earpads can be ordered from your nearest Sony dealer.

주요 제한

종류: 폐쇄형, 다이내믹 / **드라이버 장치:** 30 mm, 돔 형식(CCA W 보이스 코일) / **전원 용량:** 1,000 mW(IEC*) / **임피던스:** 1 kHz에서 24 Ω / **감도:** 98 dB/mW / **주파수 응답:** 10 Hz - 24,000 Hz / **코드:** 1.2 m(Y형) / **플러그:** L형 금도금 스테레오 미니 플러그 / **무게:** 약 125 g(코드 제외)

* IEC = 국제 전기 표준 회의

디자인 및 주요 제한은 사전 통보 없이 변경될 수 있습니다.

주의사항



높은 볼륨으로 들으면 청각에 영향을 미칠 수 있습니다. 교통 안전을 위해 운전 중이거나 자전거를 타는 중에는 사용하지 마십시오.

規格

型式: 封閉式, 動態 / **激勵單元:** 30 mm, 圓頂型 (CCA W 音圈) / **功率處理容量:** 1000 mW (IEC*) / **阻抗:** 1 kHz 時 24 Ω / **靈敏度:** 98 dB/mW / **頻率響應:** 10 Hz - 24000 Hz / **導線:** 1.2 m (Y 式) / **插頭:** 鍍金 L 型立體聲迷你插頭 / **質量:** 約 125 g (不含導線)

* IEC = 國際電工委員會

設計和規格如有變更, 恕不另行通知。

注意事項



高音量可能會影響您的聽力。為了交通安全, 切勿在駕車或騎車時使用耳機。

可向附近的 Sony 經銷商訂購選購的替換耳墊。

교체용 이어 패드는 가까운 Sony 대리점에서 주문할 수 있습니다.