




* 4 5 6 7 2 6 8 1 2 * (1)

About the AM tuning interval setting

The AM tuning interval of this radio can be set to 9 kHz or 10 kHz to match the frequency allocation system, which is different depending on the countries/regions.

By default, the AM tuning interval is set to 9 kHz. If necessary, change the setting using the following procedure before listening to AM radio.

- 1 Press **I/⏻** to turn off the radio.
- 2 Press and hold **AUTO OFF** for more than 4 seconds while holding down the preset button 1.



The AM tuning interval is changed with a beep and the new setting (9 kHz or 10 kHz) appears on the display.

Each time you press and hold the buttons, AM tuning interval changes cyclically.

Changing tuning interval erases all the AM preset stations stored in the unit. Preset the stations again, after changing the tuning interval.

Note

The AM tuning interval can be changed only when the radio is turned off. Be sure to turn off the radio beforehand.