





# 1





# 2









NW-WS625



# 3





**Windows**  
 Music Center for PC  
<http://www.sony.net/smc4pc/>

**Mac**  
 Content Transfer for Mac  
<http://www.sony.net/ct-mac/>

**i**

[http://rd1.sony.net/help/dmp/nwws620/h\\_ww/](http://rd1.sony.net/help/dmp/nwws620/h_ww/)