





# 1














# 2

WI-C400



# 3





[http://rd1.sony.net/help/mdr/wic400/h\\_zz/](http://rd1.sony.net/help/mdr/wic400/h_zz/)