

SONY[®]

Wireless Speaker

Precautions/Specifications

GB

SRS-RA5000

WARNING

Do not install the Wireless Speaker in a confined space, such as a bookcase or built-in cabinet.

To reduce the risk of fire, do not cover the ventilation opening of the Wireless Speaker with newspapers, tablecloths, curtains, etc.

Do not expose the Wireless Speaker to naked flame sources (for example, lighted candles).

To reduce the risk of fire or electric shock, do not expose this Wireless Speaker to dripping or splashing, and do not place objects filled with liquids, such as vases, on the Wireless Speaker.

The AC adapter is not disconnected from the mains as long as it is connected to the AC outlet, even if the Wireless Speaker itself has been turned off.

As the main plug of power adapter is used to disconnect the AC power adapter from the mains, connect it to an easily accessible AC outlet. Should you notice an abnormality in it, disconnect it from the AC outlet immediately.

Do not place this product close to medical devices

This product (including accessories) has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

Indoor use only.

Recommended cables

Properly shielded and grounded cables and connectors must be used for connection to host computers and/or peripherals.

For the Wireless Speaker

The nameplate is located on the bottom of the Wireless Speaker.

For the AC adapter

Labels for AC adapter Model No. and Serial No. are located at the bottom of AC adapter.

This equipment has been tested and found to comply with the limits set out in the EMC regulation using a connection cable shorter than 3 meters.

Precautions

On safety

Should any solid object or liquid fall into the product, unplug it and have it checked by qualified personnel before operating it any further.

On power sources

- Before operating the product, check that the operating voltage is identical with your local power supply.
The operating voltage is indicated on the nameplate on the bottom of the product.
- The product is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the product itself has been turned off.
- If you are not going to use the product for a long time, be sure to disconnect it from the wall outlet. To disconnect the AC power cord, grasp the plug itself; never pull the cord.

On placement

- Do not set the product in an inclined position.
- Place the product in a location with adequate ventilation to prevent heat buildup and prolong the life of the product.
- Do not place the product near heat sources, or in a place subject to direct sunlight, excessive dust, or mechanical shock.
- Do not place anything on top of the product that might cause malfunctions.
- Use caution when placing the product on surfaces that have been specially treated (with wax, oil, polish, etc.) as staining or discoloration of the surface may result.

On operation

Before connecting other equipment, be sure to turn off and unplug the product.

On cleaning

Clean this product with a soft cloth slightly moistened with a mild detergent solution. Do not use any type of abrasive pads, scouring powder, or solvents, such as thinner, benzene, or alcohol.

If you have any questions or problems concerning this product, please consult your nearest Sony dealer.

Notes on the update

The software of this product will be automatically updated to the latest software while connected to the Internet via a Wi-Fi® network. The software update will be delivered from time to time when, for example, a new feature becomes available or the update is required for stable use.

Such automatic software feature may not be disabled. Also, previous versions of the software cannot be retrievable.

Do not turn off power of this product while updating. The product may not be operational while updating.

To use this product, a Wi-Fi environment and Google Account are necessary, as well as your consent to Google Terms of Use and/or Privacy Policy. By using this product, you agree to Sony's EULA. Software for this product is automatically updated from time to time and you cannot choose or refuse to load such automatic software.

Notes on the License

This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software. Please access the following URL and read the contents of the license.
<https://rd1.sony.net/help/speaker/sl/20ra/>



Notice on GNU GPL/LGPL applied software

This product contains software that is subject to the following GNU General Public License (hereinafter referred to as "GPL") or GNU Lesser General Public License (hereinafter referred to as "LGPL"). These establish that customers have the right to acquire, modify, and redistribute the source code of said software in accordance with the terms of the GPL or LGPL supplied. The source code for the above-listed software is available on the Web.

To download, please access the following URL then select the model name "SRS-RA5000".

URL: <http://oss.sony.net/Products/Linux/>

Please note that Sony cannot answer or respond to any inquiries regarding the content of the source code.

Disclaimer regarding services offered by third parties

Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Specifications

Up-firing/Mid speaker section

Speaker system
Full Range Speaker system, Acoustic Suspension
Speaker diameter (approx.)
46 mm × 3 / 46 mm × 3

Subwoofer speaker section

Speaker system
Subwoofer Speaker system, Bass Reflex
Speaker diameter (approx.)
70 mm × 1

Input terminal section

Analog In

Wi-Fi section

Compatible standards
IEEE802.11 a/b/g/n
Radio frequency
2.4/5 GHz band

BLUETOOTH® section

Communication system

BLUETOOTH Specification version 4.2

Output

BLUETOOTH Specification Power Class 1

Maximum communication range

Line of sight approx. 30 m*¹

Frequency band

2.4 GHz band (2.4000 GHz - 2.4835 GHz)

Modulation method

FHSS

Compatible BLUETOOTH profiles*²

A2DP (Advanced Audio Distribution Profile)

AVRCP (Audio Video Remote Control Profile)

Supported Codec*³

SBC*⁴, AAC*⁵

Transmission range (A2DP)

20 Hz - 20,000 Hz (Sampling frequency 44.1 kHz)

*¹ The actual range will vary depending on factors such as obstacles between the product and the device, magnetic fields around a microwave oven, static electricity, reception sensitivity, antenna's performance, operating system, software application, etc.

*² BLUETOOTH standard profiles indicate the purpose of BLUETOOTH communication between devices.

*³ Codec: Audio signal compression and conversion format

*⁴ Subband Codec

*⁵ Advanced Audio Coding

General

Power requirements

DC 19.5 V

(using the supplied AC adapter connected to AC 100 V - 240 V, 50 Hz/60 Hz power supply)

Power consumption

On: 55 W

Standby mode: 0.5 W or less (Power Saving mode)

(When BLUETOOTH/Network standby mode are set to off)

Standby mode: 2 W or less*⁶

(When BLUETOOTH/Network standby mode are set to on)

Dimensions*⁷ (approx.) (w/h/d)

235 mm × 329 mm × 225 mm

Mass (approx.)

4.9 kg

*⁶ The product will automatically enter Power saving mode when there is no BLUETOOTH pairing history.

*⁷ Not including projection portion

Design and specifications are subject to change without notice.

GB

Compatible iPhone/iPod models

The compatible iPhone/iPod models are as follows. Update your iPhone/iPod with the latest software before using with the product.

Made for:

iPhone X/iPhone 8 Plus/iPhone 8/iPhone 7 Plus/iPhone 7/iPhone SE/
iPhone 6s Plus/iPhone 6s/iPhone 6 Plus/iPhone 6/iPhone 5s/
iPod touch (6th generation)

Note

Sony cannot accept responsibility in the event that data recorded to iPhone/iPod is lost or damaged when using your iPhone/iPod connected to this product.

How to Use Spotify Connect

Use your phone, tablet or computer as a remote control for Spotify. Go to spotify.com/connect to learn how.

Copyrights and Trademarks

- Apple, iPhone, iPod, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
- Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- The N-Mark is a trademark or registered trademark of NFC Forum, Inc. in the United States and in other countries.
- The BLUETOOTH® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Corporation is under license.
- Wi-Fi® and Wi-Fi Alliance® are registered trademarks of Wi-Fi Alliance®.
- Wi-Fi CERTIFIED™ is a trademark of Wi-Fi Alliance®.
- The Wi-Fi CERTIFIED™ Logo is a certification mark of Wi-Fi Alliance®.
- Google, Google Play, Chromecast built-in and other related marks and logos are trademarks of Google LLC.
- The Spotify Software is subject to third party licenses found here: <https://www.spotify.com/connect/third-party-licenses>
- Spotify and Spotify logos are trademarks of the Spotify Group.*
* Depending on the country and region, this function may not be available.
- Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.
- Other trademarks and trade names are those of their respective owners.

END USER LICENSE AGREEMENT

IMPORTANT:

BEFORE USING THIS DEVICE, PLEASE READ THIS END USER LICENSE AGREEMENT (“EULA”) CAREFULLY. BY USING THIS DEVICE YOU ARE ACCEPTING THE TERMS OF THIS EULA. IF YOU DO NOT ACCEPT THE TERMS OF THIS EULA, YOU MAY NOT USE THIS DEVICE.

This EULA is a legal agreement between you and Sony Home Entertainment & Sound Products Inc. (“SONY”). This EULA governs your rights and obligations regarding the software of SONY and/or its third party licensors (including SONY’s affiliates) and their respective affiliates (collectively, the “THIRD-PARTY SUPPLIERS”) for this device (SONY’s audio device, this “DEVICE”), together with any updates/ upgrades provided by SONY, any printed, on-line or other electronic documentation for such software, and any data files created by operation of such software (collectively, the “SOFTWARE”).

Notwithstanding the foregoing, any software in the SOFTWARE having a separate end user license agreement (including, but not limited to, GNU General Public License and Lesser/Library General Public License) shall be covered by such applicable separate end user license agreement in lieu of the terms of this EULA to the extent required by such separate end user license agreement (“EXCLUDED SOFTWARE”).

SOFTWARE LICENSE

The SOFTWARE is licensed, not sold. The SOFTWARE is protected by copyright and other intellectual property laws and international treaties.

COPYRIGHT

All right and title in and to the SOFTWARE (including, but not limited to, any images, photographs, animation, video, audio, music, text and “applets” incorporated into the SOFTWARE) is owned by SONY or one or more of the THIRD-PARTY SUPPLIERS.

GRANT OF LICENSE

SONY grants you a limited license to use the SOFTWARE solely in connection with this DEVICE and only for your individual, non-commercial use. SONY and the THIRD-PARTY SUPPLIERS expressly reserve all rights, title and interest (including, but not limited to, all intellectual property rights) in and to the SOFTWARE that this EULA does not specifically grant to you.

REQUIREMENTS AND LIMITATIONS

You may not copy, publish, adapt, redistribute, attempt to derive source code, modify, reverse engineer, decompile, or disassemble any of the SOFTWARE, whether in whole or in part, or create any derivative works from or of the SOFTWARE unless such derivative works are intentionally facilitated by the SOFTWARE. You may not modify or tamper with any digital rights management functionality of the SOFTWARE. You may not bypass, modify, defeat or circumvent any of the functions or protections of the SOFTWARE or any mechanisms operatively linked to the SOFTWARE. You may not separate any individual component of the SOFTWARE for use on more than one DEVICE unless expressly authorized to do so by SONY. You may not remove, alter, cover or deface any trademarks or notices on the SOFTWARE. You may not share, distribute, rent, lease, sublicense, assign, transfer or sell the SOFTWARE. The software, network services or other products other than SOFTWARE upon which the SOFTWARE’S performance depends might be interrupted or discontinued at the discretion of the suppliers (software suppliers, service suppliers, or SONY). SONY and such suppliers do not warrant that the SOFTWARE, network services or other products will continue to be available, or will operate without interruption or modification.

EXCLUDED SOFTWARE AND OPEN SOURCE COMPONENTS

Notwithstanding the foregoing limited license grant, you acknowledge that the SOFTWARE may include EXCLUDED SOFTWARE. Certain EXCLUDED SOFTWARE may be covered by open source software licenses (“Open Source Components”), which means any software licenses

approved as open source licenses by the Open Source Initiative or any substantially similar licenses, including but not limited to any license that, as a condition of distribution of the software licensed under such license, requires that the distributor make the software available in source code format. If and to the extent disclosure is required, please visit www.sony.net/Products/Linux or other SONY-designated web site for a list of applicable OPEN SOURCE COMPONENTS included in the SOFTWARE from time to time, and the applicable terms and conditions governing its use. Such terms and conditions may be changed by the applicable third party at any time without liability to you. To the extent required by the licenses covering EXCLUDED SOFTWARE, the terms of such licenses will apply in lieu of the terms of this EULA. To the extent the terms of the licenses applicable to EXCLUDED SOFTWARE prohibit any of the restrictions in this EULA with respect to such EXCLUDED SOFTWARE, such restrictions will not apply to such EXCLUDED SOFTWARE. To the extent the terms of the licenses applicable to Open Source Components require SONY to make an offer to provide source code in connection with the SOFTWARE, such offer is hereby made.

USE OF SOFTWARE WITH COPYRIGHTED MATERIALS

The SOFTWARE may be capable of being used by you to view, store, process and/or use content created by you and/or third parties. Such content may be protected by copyright, other intellectual property laws, and/or agreements. You agree to use the SOFTWARE only in compliance with all such laws and agreements that apply to such content. You acknowledge and agree that SONY may take appropriate measures to protect the copyright of content stored, processed or used by the SOFTWARE. Such measures include, but are not limited to, counting the frequency of your backup and restoration through certain SOFTWARE features, refusal to accept your request to enable restoration of data, and termination of this EULA in the event of your illegitimate use of the SOFTWARE.

CONTENT SERVICE

PLEASE ALSO NOTE THAT THE SOFTWARE MAY BE DESIGNED TO BE USED WITH CONTENT AVAILABLE THROUGH ONE OR MORE CONTENT SERVICES ("CONTENT SERVICE"). USE OF THE SERVICE AND THAT CONTENT IS SUBJECT TO THE TERMS OF SERVICE OF THAT CONTENT SERVICE. IF YOU DECLINE TO ACCEPT THOSE TERMS, YOUR USE OF THE SOFTWARE WILL BE LIMITED. YOU ACKNOWLEDGE AND AGREE THAT CERTAIN CONTENT AND SERVICES AVAILABLE THROUGH THE SOFTWARE MAY BE PROVIDED BY THIRD PARTIES ("THIRD PARTY SERVICE PROVIDERS") OVER WHICH SONY HAS NO CONTROL. USE OF THE CONTENT SERVICE REQUIRES AN INTERNET CONNECTION. THE CONTENT SERVICE MAY BE DISCONTINUED AT ANY TIME.

INTERNET CONNECTIVITY AND THIRD PARTY SERVICES

You acknowledge and agree that access to certain SOFTWARE features may require an Internet connection for which you are solely responsible. Further, you are solely responsible for payment of any third party fees associated with your Internet connection, including but not limited to Internet service provider or airtime charges. Operation of the SOFTWARE may be limited or restricted depending on the capabilities, bandwidth or technical limitations of your Internet connection and service. The provision, quality and security of such Internet connectivity are the sole responsibility of the third party providing such service.

EXPORT AND OTHER REGULATIONS

You agree to comply with all applicable export and re-export restrictions and regulations of the area or country in which you reside and authorities, and not to transfer, or authorize the transfer, of the SOFTWARE to a prohibited country or otherwise in violation of any such restrictions or regulations.

HIGH RISK ACTIVITIES

The SOFTWARE is not fault-tolerant and is not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air

traffic control, direct life support machines, or weapons systems, in which the failure of the SOFTWARE could lead to death, personal injury, or severe physical or environmental damage (“HIGH RISK ACTIVITIES”). SONY, each of the THIRD-PARTY SUPPLIERS, and each of their respective affiliates specifically disclaim any express or implied warranty, duty or condition of fitness for HIGH RISK ACTIVITIES.

EXCLUSION OF WARRANTY ON SOFTWARE

You acknowledge and agree that use of the SOFTWARE is at your sole risk and that you are responsible for use of the SOFTWARE. The SOFTWARE is provided “AS IS,” without warranty, duty or condition of any kind.

SONY AND EACH OF THE THIRD-PARTY SUPPLIERS (for purposes of this Section, SONY and each of the THIRD-PARTY SUPPLIERS shall be collectively referred to as “SONY”) EXPRESSLY DISCLAIM ALL WARRANTIES, DUTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NONINFRINGEMENT AND FITNESS FOR A PARTICULAR PURPOSE. SONY DOES NOT WARRANT OR MAKE ANY CONDITIONS OR REPRESENTATIONS (A) THAT THE FUNCTIONS CONTAINED IN ANY OF THE SOFTWARE WILL MEET YOUR REQUIREMENTS OR THAT THEY WILL BE UPDATED, (B) THAT THE OPERATION OF ANY OF THE SOFTWARE WILL BE CORRECT OR ERROR-FREE OR THAT ANY DEFECTS WILL BE CORRECTED, (C) THAT THE SOFTWARE WILL NOT DAMAGE ANY OTHER SOFTWARE, HARDWARE OR DATA, (D) THAT ANY SOFTWARE, NETWORK SERVICES (INCLUDING THE INTERNET) OR PRODUCTS (OTHER THAN THE SOFTWARE) UPON WHICH THE SOFTWARE’S PERFORMANCE DEPENDS WILL CONTINUE TO BE AVAILABLE, UNINTERRUPTED OR UNMODIFIED, AND (E) REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE IN TERMS OF ITS CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE.

NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SONY OR AN AUTHORIZED REPRESENTATIVE OF SONY SHALL CREATE A WARRANTY, DUTY OR CONDITION OR IN ANY WAY INCREASE THE SCOPE

OF THIS WARRANTY. SHOULD THE SOFTWARE PROVE DEFECTIVE YOU ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THESE EXCLUSIONS MAY NOT APPLY TO YOU.

LIMITATION OF LIABILITY

SONY AND EACH OF THE THIRD-PARTY SUPPLIERS (for purposes of this Section, SONY and each of the THIRD-PARTY SUPPLIERS shall be collectively referred to as “SONY”) SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY OR UNDER ANY OTHER LEGAL THEORY RELATED TO THE SOFTWARE, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES ARISING OUT OF LOSS OF PROFITS, LOSS OF REVENUE, LOSS OF DATA, LOSS OF USE OF THE SOFTWARE OR ANY ASSOCIATED HARDWARE, DOWN TIME AND USER’S TIME, EVEN IF ANY OF THEM HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN ANY CASE, EACH AND ALL OF THEIR AGGREGATE LIABILITY UNDER ANY PROVISION OF THIS EULA SHALL BE LIMITED TO THE AMOUNT ACTUALLY PAID FOR THIS DEVICE. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU.

CONSENT TO USE OF CERTAIN INFORMATION, LOCATION DATA, DATA SECURITY

SONY and its affiliates, partners and agents may use your IP address to connect your DEVICE to the Internet for the purpose of SOFTWARE updates. You acknowledge that THIRD PARTY SERVICE PROVIDERS may read, collect, transfer, process and store certain information collected from the SOFTWARE, including but not limited to information about (i) the SOFTWARE and (ii) the software applications, contents and peripheral devices that interact with your DEVICE and the SOFTWARE (“Information”). Information includes, but is not limited to: (1) unique identifiers relating to your DEVICE and its components; (2) performance of the DEVICE, the SOFTWARE and their components; (3) configurations of your DEVICE, the SOFTWARE and the software applications, contents

and peripheral devices that interact with the DEVICE and the SOFTWARE; (4) use and frequency of use of the functions of (x) the SOFTWARE, and (y) the software applications, contents and peripheral devices that interact with the SOFTWARE; and (5) location data, as indicated below. THIRD PARTY SERVICE PROVIDERS may use and disclose Information subject to applicable laws in order to improve its products and services or to provide products or services to you. Such uses include, but are not limited to: (a) administering the functionalities of the SOFTWARE; (b) to improve, service, update or upgrade the SOFTWARE; (c) improving, developing and enhancing the current and future products and services of THIRD PARTY SERVICE PROVIDERS and other parties; (d) to provide you with information about the products and services offered by THIRD PARTY SERVICE PROVIDERS and other parties; (e) complying with applicable laws or regulations; and (f) to the extent offered, providing you with location-based services of THIRD PARTY SERVICE PROVIDERS and other parties, as indicated below. In addition, THIRD PARTY SERVICE PROVIDERS may retain the right to use Information to protect themselves and third parties from illegal, criminal or harmful conduct.

Certain services available through the SOFTWARE may rely upon location information, including, but not limited to, the geographic location of the DEVICE. You acknowledge that for the purpose of providing such services, the THIRD-PARTY SUPPLIERS, THIRD PARTY SERVICE PROVIDERS or their partners may collect, archive, process and use such location data, and that such services are governed by the privacy policies of such third party. By using any such services, you agree that you have reviewed the privacy policies applicable to such services and consent to such activities.

SONY, its affiliates, partners and agents will not intentionally use Information to personally identify the owner or user of the SOFTWARE without your knowledge or consent. Any use of Information will be in accordance with the privacy policies of SONY or such third party. Please contact applicable contact address of each area or country for SONY's current privacy policy. This can be found on your country's website

which can be chosen by visiting: <https://www.sony.com/locale-selector>. Please contact applicable third parties for privacy policies relating to personally identifiable and other information you provide when you use or access third party software or services.

Information may be processed, stored or transferred to SONY, its affiliates or agents which are located in countries outside of your country of residence. Data protection and information privacy laws in certain countries may not offer the same level of protection as your country of residence and you may have fewer legal rights in relation to Information processed and stored in, or transferred to, such countries. SONY will use reasonable efforts to take appropriate technical and organizational steps to prevent unauthorized access to or disclosure of Information, but does not warrant it will eliminate all risk of misuse of such Information.

AUTOMATIC UPDATE FEATURE

From time to time, SONY, the THIRD-PARTY SUPPLIERS or THIRD PARTY SERVICE PROVIDERS may automatically update or otherwise modify the SOFTWARE, including, but not limited to, for purposes of enhancement of security functions, error correction and improvement of functions, at such time as you interact this DEVICE with SONY's or third parties' servers, or otherwise. Such updates or modifications may delete or change the nature of features or other aspects of the SOFTWARE, including, but not limited to, functions you may rely upon. You acknowledge and agree that such activities may occur at SONY's sole discretion and that SONY may condition continued use of the SOFTWARE upon your complete installation or acceptance of such update or modifications. Any updates/modifications shall be deemed to be, and shall constitute part of, the SOFTWARE for purposes of this EULA. By acceptance of this EULA, you consent to such update/modification.

ENTIRE AGREEMENT, WAIVER, SEVERABILITY

This EULA and SONY's privacy policy, each as amended and modified from time to time, together constitute the entire agreement between

you and SONY with respect to the SOFTWARE. The failure of SONY to exercise or enforce any right or provision of this EULA shall not constitute a waiver of such right or provision. If any part of this EULA is held invalid, illegal, or unenforceable, that provision shall be enforced to the maximum extent permissible so as to maintain the intent of this EULA, and the other parts will remain in full force and effect.

GOVERNING LAW AND JURISDICTION

The United Nations Convention on Contracts for the International Sale of Goods shall not apply to this EULA. This EULA shall be governed by the laws of Japan, without regards to conflict of laws provisions. Any dispute arising out of this EULA shall be subject to the exclusive venue of the Tokyo District Court in Japan, and the parties hereby consent to the venue and jurisdiction of such courts.

EQUITABLE REMEDIES

Notwithstanding anything contained in this EULA to the contrary, you acknowledge and agree that any violation of or non-compliance with this EULA by you will cause irreparable harm to SONY, for which monetary damages would be inadequate, and you consent to SONY obtaining any injunctive or equitable relief that SONY deems necessary or appropriate in such circumstances. SONY may also take any legal and technical remedies to prevent violation of and/or to enforce this EULA, including, but not limited to, immediate termination of your use of the SOFTWARE, if SONY believes in its sole discretion that you are violating or intend to violate this EULA. These remedies are in addition to any other remedies SONY may have at law, in equity or under contract.

TERMINATION

Without prejudice to any of its other rights, SONY may terminate this EULA if you fail to comply with any of its terms. In case of such termination, you must: (i) cease all use, and destroy any copies, of the SOFTWARE; (ii) comply with the requirements in the section below entitled "Your Account Responsibilities".

AMENDMENT

SONY RESERVES THE RIGHT TO AMEND ANY OF THE TERMS OF THIS EULA AT ITS SOLE DISCRETION BY POSTING NOTICE ON A SONY DESIGNATED WEB SITE, BY EMAIL NOTIFICATION TO AN EMAIL ADDRESS PROVIDED BY YOU, BY PROVIDING NOTICE AS PART OF THE PROCESS IN WHICH YOU OBTAIN UPGRADES/UPDATES OR BY ANY OTHER LEGALLY RECOGNIZABLE FORM OF NOTICE. If you do not agree to the amendment, you should promptly contact SONY for instructions. Your continued use of the SOFTWARE after the effective date of any such notice shall be deemed your agreement to be bound by such amendment.

THIRD-PARTY BENEFICIARIES

Each THIRD-PARTY SUPPLIER is an express intended third-party beneficiary of, and shall have the right to enforce, each provision of this EULA with respect to the SOFTWARE of such party.

YOUR ACCOUNT RESPONSIBILITIES

Should you return your DEVICE to its place of purchase, sell or otherwise transfer your DEVICE, or if this EULA is terminated, you are responsible for and must delete any and all accounts you may have established on DEVICE or are accessible through this DEVICE. You are solely responsible for maintaining the confidentiality of any accounts you have with SONY or third parties and any usernames and passwords associated with your use of the DEVICE.

Should you have any questions concerning this EULA, you may contact SONY by writing to SONY at: applicable contact address of each area or country. This can be found on your country's website which can be chosen by visiting: <https://www.sony.com/locale-selector>.

Copyright © 2020 Sony Home Entertainment & Sound Products Inc. All rights reserved.

يعوض لـ SONY، الذي لن تكون التعويضات المالية كافية له، وأنت توافق على حصول SONY على أي إعانة بأمر قضائي أو منصفة تعتبرها SONY ضرورية أو مناسبة في هذه الظروف. ويجوز أن تتخذ SONY أيضا أي تدابير لمنع مخالفة اتفاقية رخصة المستخدم النهائي و/أو تطبيقها، بما يشمل ولا يقتصر على، الإنهاء الفوري لاستخدامك للبرنامج، إذا اعتقدت SONY وفقا لتقديرها وحدها أنك تخرق أو تتزعم مخالفة اتفاقية رخصة المستخدم النهائي هذه. وتكون هذه التدابير بالإضافة إلى أي تدابير أخرى يجوز أن تتخذها SONY بموجب القانون، أو العدالة المطلقة أو بموجب عقد.

الإنهاء

يجوز أن تنتهي SONY، بدون الإضرار بأي من حقوقها، اتفاقية رخصة المستخدم النهائي هذه إذا لم تلتزم بأي من شروطها. وفي حالة هذا الإنهاء، يجب عليك: (i) التوقف عن الاستخدام تماما، وإتلاف نسخ من البرنامج؛ (ii) الالتزام بالاشتراطات في البند أدناه المسمى «مسؤوليات حسابك».

التعديل

تحتفظ SONY بحق تعديل أي من شروط اتفاقية رخصة المستخدم النهائي هذه وفقا لتقديرها وحدها وذلك بنشر إشعار على موقع ويب مخصص لـ SONY، أو بإخطار بواسطة البريد الإلكتروني إلى عنوان البريد الإلكتروني الذي قدمته، أو بتقديم إشعار في إطار العملية التي تحصل بها على الترقية/التحديثات أو بأي صيغة إشعار أخرى معترف بها قانونا. وإذا كنت لا توافق على التعديل، يجب عليك الاتصال سريعا بـ SONY لمعرفة التعليمات. ومواصلة استخدامك للبرنامج بعد تاريخ سريان مفعول أي إشعار مثل ذلك يعتبر موافقة منك على الالتزام بهذا التعديل.

المستفيدون من الأطراف الثالثة

كل مورد من الأطراف الثالثة هو مستفيد طرف ثالث مقصود صريح، وله الحق في تطبيق، كل بند في اتفاقية رخصة المستخدم النهائي هذه فيما يخص برنامج هذا الطرف.

مسؤوليات حسابك

في حالة إرجاع جهازك إلى مكان الشراء، أو بيعه أو بطريقة أخرى نقل جهازك، أو في حالة إنهاء اتفاقية رخصة المستخدم النهائي هذه، تكون مسؤولا عن ويجب عليك حذف أي وجميع الحسابات التي ربما تكون أنشأتها على الجهاز أو يمكن الوصول إليها من خلال هذا الجهاز. وأنت مسؤول وحده عن الحفاظ على سرية أي حسابات لديك مع SONY أو أطراف ثالثة وأي أسماء مستخدمين أو كلمات مرور مرتبطة باستخدامك للجهاز.

وفي حالة أن كان لديك أي أسئلة بخصوص اتفاقية رخصة المستخدم النهائي هذه، يمكن أن تتصل بـ SONY بالكتابة إلى SONY على: عنوان الاتصال المناسب لكل منطقة أو بلد. ويمكن العثور على العنوان على موقع ويب بلدك الذي يمكن اختياره بزيارة:

<https://www.sony.com/locale-selector>

© Copyright 2020 Sony Home Entertainment & Sound Products Inc.

جميع الحقوق محفوظة.

الموافقة على استخدام معلومات معينة، وبيانات الموقع، وأمن البيانات

يجوز أن تستخدم SONY والشركات التابعة لها وشركاءها عنوان IP الخاص بك لتوصيل جهازك بالإنترنت لغرض تحديثات البرنامج. وأنت تقر بأن مقدمي الخدمة من الأطراف الثالثة يجوز لهم قراءة أو جمع أو نقل أو معالجة وتخزين معلومات معينة تم جمعها من البرنامج، تشمل ولكن لا تقتصر على معلومات عن (i) البرنامج و(ii) تطبيقات البرنامج والمحتويات والأجهزة الطرفية التي تتفاعل مع جهازك وبرنامجك («المعلومات»). وتشمل المعلومات، على سبيل الذكر لا الحصر: (1) المعارف الفريدة المرتبطة بجهازك ومكوناته؛ (2) أداء الجهاز، والبرنامج ومكوناته؛ (3) تكوينات جهازك، والبرنامج وتطبيقات البرنامج، والمحتويات والأجهزة الطرفية التي تتفاعل مع الجهاز والبرنامج؛ (4) استخدام وتكرار استخدام وظائف (x) البرنامج، و(y) تطبيقات البرنامج، والمحتويات والأجهزة الطرفية التي تتفاعل مع البرنامج؛ و(5) بيانات الموقع، كما هو مبين أدناه. ويجوز لمزودي الخدمة من الأطراف الثالثة استخدام وكشف المعلومات الخاضعة للقوانين المعمول بها من أجل تحسين منتجاتهم وخدماتهم أو تقديم منتجات أو خدمات لك. وتشمل هذه الاستخدامات، لكن لا تقتصر على: (أ) إدارة وظائف البرنامج؛ (ب) تحسين أو خدمة أو تحديث أو ترقية البرنامج؛ (ج) تحسين أو تطوير أو تعزيز المنتجات والخدمات الحالية والمستقبلية لمزودي الخدمة من الأطراف الثالثة وأطراف أخرى؛ (د) لتزويدك بمعلومات عن المنتجات والخدمات المقدمة من مزودي الخدمة من الأطراف الثالثة وأطراف أخرى؛ (هـ) الامتثال للقوانين أو الضوابط المعمول بها؛ و(و) إلى المدى المقدم، تزويدك بخدمات تعتمد على الموقع من مزودي الخدمة من الأطراف الثالثة وأطراف أخرى، كما هو مبين أدناه. بالإضافة إلى ذلك، يجوز لمزودي الخدمة من الأطراف الثالثة الاحتفاظ بحق استخدام المعلومات لحماية أنفسهم والأطراف الثالثة من سلوك غير قانوني أو جنائي أو ضار.

وقد تعتمد بعض الخدمات التي نتاح من خلال البرنامج على معلومات الموقع، التي تشمل، لكن لا تقتصر على، الموقع الجغرافي للجهاز. وأنت تقر بأنه لغرض تقديم مثل هذه الخدمات، يجوز للمزودين من الأطراف الثالثة ومزودي الخدمات من الأطراف الثالثة أو شركائهم جمع وأرشفة ومعالجة واستخدام بيانات الموقع هذه، وأن هذه الخدمات تحكمها سياسات الخصوصية لهذا الطرف الثالث. وباستخدام أي من هذه الخدمات، أنت توافق على أنك اطلعت على سياسة الخصوصية المطبقة لهذه الخدمات وتوافق على هذه الأنشطة.

لن تستخدم SONY وفروعها أو شركاءها وكلاءها عمدا المعلومات للتعرف على شخصية مالك أو مستخدم البرنامج بدون معرفتك أو موافقتك. وأي استخدام للمعلومات سيكون وفقا لسياسة خصوصية SONY أو هذا الطرف الثالث. يرجى الاتصال بعنوان الاتصال المناسب لكل منطقة أو بلد من أجل سياسة خصوصية SONY الحالية. ويمكن العثور على العنوان على موقع ويب بلدك الذي يمكن اختياره بزيارة: <https://www.sony.com/locale-selector>.

يرجى الاتصال بالأطراف الثالثة المناسبة من أجل سياسة الخصوصية المرتبطة بمعلومات كشف الشخصية وغيرها من المعلومات التي تقدمها عندما تستخدم أو تصل إلى برامج أو خدمات أطراف

ثالثة.

8AR

يجوز معالجة المعلومات المخزنة أو المنقولة إلى SONY أو فروعها أو وكلائها الموجودين خارج بلد إقامتك. وفي بلاد معينة قد لا تقدم قوانين حماية البيانات وخصوصية المعلومات نفس مستوى الحماية كما في بلد إقامتك وقد يكون لديك حقوق قانونية أقل فيما يخص المعلومات المعالجة أو المخزنة في أو المنقولة إلى هذه البلاد. وستبذل SONY جهودا معقولة لاتخاذ خطوات تقنية وتنظيمية مناسبة لمنع الوصول غير المسموح به إلى المعلومات أو الكشف عنها، لكن لا تضمن أنها ستزيل تماما خطر إساءة استخدام هذه المعلومات.

ميزة التحديث التلقائي

من وقت لآخر، يمكن أن تحدث SONY والموردين من الأطراف الثالثة أو موردي الخدمات من الأطراف الثالثة تلقائيا البرنامج أو بطريقة أخرى تعده، على سبيل الذكر لا الحصر، لأغراض تعزيز وظائف الحماية وتصحيح الأخطاء وتحسين الوظائف في الوقت الذي تستخدم فيه هذا الجهاز مع خوادم SONY أو أطراف ثالثة، أو غير ذلك. وهذه التحديثات أو التعديلات يمكن أن تحذف أو تغير طبيعة ميزات أو جوانب أخرى للبرنامج، تشمل ولا تقتصر على، الوظائف التي ربما تعتمد عليها. وأنت تقر وتوافق على أن هذه الأنشطة قد تحدث وفقا لتقدير SONY وحدها وأن SONY يجوز لها أن تستمر مواصلة استخدام البرنامج بعدما تكمل تثبيت هذا التحديث أو التعديلات أو تقبلها. وأي تحديثات/تعديلات تعتبر وتشكل جزءا من البرنامج لأغراض اتفاقية رخصة المستخدم النهائي هذه. وبقبول اتفاقية رخصة المستخدم النهائي هذه، أنت توافق على هذا التحديث/التعديل.

الاتفاقية الكاملة، التنازل، قابلية الانفعال

اتفاقية رخصة المستخدم النهائي هذه وسياسة خصوصية SONY، كل منهما بصيغتها المنقحة والمعدلة من وقت لآخر، معا يشكلان الاتفاقية الكاملة بينك وSONY فيما يخص البرنامج. وإخفاق SONY في استعمال أو تطبيق أي حق أو بند في اتفاقية رخصة المستخدم النهائي هذه لن يشكل تنازلا عن هذا الحق أو البند. وإذا اعتبر أي جزء من اتفاقية رخصة المستخدم النهائي هذه غير قانوني أو غير نافذ المفعول، فإن هذا البند يكون نافذ المفعول إلى أقصى حد مسموح من أجل الحفاظ على غرض اتفاقية رخصة المستخدم النهائي هذه، وستظل الأجزاء الأخرى سارية المفعول والأثر.

القانون والسلطة القضائية الحاكمان

لن تنطبق اتفاقية الأمم المتحدة بشأن عقود البيع الدولي للبضائع على اتفاقية رخصة المستخدم النهائي هذه. ويحكم اتفاقية رخصة المستخدم النهائي هذه قوانين اليابان، فيما يخص تضارب أحكام القوانين. وأي نزاع ينشأ عن اتفاقية رخصة المستخدم النهائي هذه يخضع للاختصاص المكاني الحضري لمحكمة مقاطعة طوكيو في اليابان، ويوافق الأطراف بموجب هذا على المكان والاختصاص القضائي لهذه المحاكم.

التعويضات القانونية المنصبة

على الرغم من أي شيء مشمول في اتفاقية رخصة المستخدم النهائي هذه بما يفيد العكس، أنت تقر وتوافق على أن أي خرق لك أو عدم التزام باتفاقية رخصة المستخدم النهائي هذه سيسبب ضررا لا

أخرى، و/أو اتفاقيات. وأنت توافق على استخدام البرنامج فقط مع الامتثال لجميع هذه القوانين والاتفاقيات التي تنطبق على هذا المحتوى. وأنت تقر وتوافق على أن SONY يمكنها اتخاذ الإجراءات المناسبة لحماية حقوق نشر المحتوى الذي يخزنه أو يعالجه أو يستخدمه البرنامج. وتشمل هذه الإجراءات، على سبيل الذكر لا الحصر، عد مرات النسخ الاحتياطي أو الاستعادة التي قمت بها من خلال ميزات معينة للبرنامج، ورفض قبول طلبك لتمكين استعادة البيانات، وإنهاء اتفاقية رخصة المستخدم النهائي هذه في حالة استخدامك غير الشرعي للبرنامج.

خدمة المحتوى

يرجى ملاحظة أن البرنامج يمكن أن يكون مصمما لاستخدامه مع محتوى متاح من خلال خدمة محتوى واحدة أو أكثر («خدمة المحتوى»). ويخضع استخدام الخدمة وذلك المحتوى لشروط الخدمة الخاصة بخدمة المحتوى هذه. وإذا رفضت قبول تلك الشروط، فإن استخدامك للبرنامج سيكون محدودا. وأنت تقر وتوافق على أن بعض المحتوى والخدمات المتاحة من خلال البرنامج يمكن أن تقدمها أطراف ثالثة («مقدمو الخدمات من الأطراف الثالثة») ليس لـ SONY سيطرة عليهم. ويتطلب استخدام خدمة المحتوى اتصال إنترنت. ويمكن إيقاف خدمة المحتوى في أي وقت.

اتصال الإنترنت وخدمات الأطراف الثالثة

أنت تقر وتوافق على أن الوصول إلى بعض ميزات البرنامج يمكن أن يتطلب اتصال إنترنت تكون أنت وحدك مسؤولا عنه. بالإضافة إلى ذلك، أنت وحدك مسؤول عن سداد أي رسوم لأطراف ثالثة مرتبطة باتصال الإنترنت، تشمل ولا تقتصر على مزود خدمة الإنترنت أو رسوم الاشتراك في الإنترنت. وقد يكون تشغيل البرنامج مقيدا أو محظورا اعتمادا على القدرات وعرض النطاق أو القيود التقنية للاتصال الإنترنت والخدمة. وتزويد اتصال الإنترنت هذا وجودته وأمنه تكون مسؤولية الطرف الثالث مزود هذه الخدمة وحده.

التصدير والضوابط الأخرى

أنت توافق على الامتثال لجميع قيود التصدير وإعادة التصدير وقوانين المنطقة أو البلد الذي تقيم به والسلطات، وعدم نقل أو إجازة نقل البرنامج إلى بلد محظور أو بطريقة أخرى بما يخالف أي من هذه القيود أو الضوابط.

الأنشطة عالية الخطورة

البرنامج غير مصمم لتحمل الخلل ومواصلة العمل وغير مصمم أو مصنع أو الغرض منه الاستخدام أو إعادة البيع كجهاز يمكن التحكم به عن طريق الإنترنت في البيئات الخطرة التي تتطلب أداءا آمنا من الأعطال، مثل في تشغيل المنشآت النووية وأنظمة ملاحية أو اتصالات الطائرة ومراقبة الحركة الجوية وأجهزة الدعم المباشر للحياة، التي يمكن أن يؤدي عطل البرنامج فيها إلى الوفاة أو إصابة شخصية أو ضرر بالغ مادي أو بيئي («أنشطة عالية الخطورة»). وتخلي SONY، وكل من موردي الأطراف الثالثة، وكل من فروعهم كل بما يخصه تحديدا مسؤوليتهم عن أي ضمان صريح أو ضمني أو واجب أو شرط كفاءة للأنشطة عالية الخطورة.

استثناء الضمان على البرنامج

أنت تقر وتوافق على أن استخدام البرنامج يكون على مسؤوليتك وحدك وأنت مسؤول عن استخدام البرنامج. يتم تقديم البرنامج «كما هو»، بدون ضمان، أو واجب أو شرط من أي نوع.

تخلي SONY وكل من مورديها من الأطراف الثالثة (لأغراض هذا البند، سيشار إلى SONY وكل من الموردين من الأطراف الثالثة إجمالا على أنهم "SONY") صراحة مسؤوليتهم عن جميع الضمانات أو الواجبات أو الشروط، الصريحة أو الضمنية، على سبيل المثال وليس الحصر، الضمانات الضمنية لصلاحيته بيعه وعدم انتهاك براءة الاختراع والملائمة لغرض معين. ولا تضمن SONY أو تقدم أي شروط أو ادعاءات بخصوص (أ) أن الوظائف المتضمنة في أي جزء من البرنامج ستلبي متطلباتك أو أنها ستكون محدثة، (ب) أن تشغيل أي جزء من البرنامج سيكون صحيحا أو خاليا من الأخطاء أو أن أي عيوب سيتم تصحيحها، (ج) أن البرنامج لن يتلف أي برنامج آخر أو جهاز أو بيانات، (د) أن أي برنامج أو خدمات شبكة (بما في ذلك الإنترنت) أو منتجات (بخلاف البرنامج) التي يعتمد عليها أداء البرنامج ستستمر متاحة، غير منقطعة أو غير معدلة (وه) فيما يتعلق باستخدام أو نتائج استخدام البرنامج من حيث صحته أو دقته أو اعتماديته أو خلاف ذلك.

لن تنشئ أي معلومات شفوية أو كتابية أو استشارة قدمتها SONY أو وكيل معتمد لـ SONY ضمانا أو واجبا أو شرطا أو بأي حال من الأحوال تزيد مجال هذا الضمان. وفي حالة أن ثبت أن البرنامج به خلل فإنك تتحمل كامل التكلفة لجميع الخدمات والإصلاح والتصحيح الضروري. وبعض السلطات القضائية لا تسمح باستثناء الضمانات الضمنية، لذلك فإن هذه الاستثناءات قد لا تنطبق عليك.

حدود المسؤولية

لن تكون SONY وكل من مورديها من الأطراف الثالثة (لأغراض هذا البند، يشار إلى SONY وكل من موردي الأطراف الثالثة إجمالا على أنهم "SONY") مسؤولين عن أي أضرار عرضية أو تبعية لخرق أي ضمان صريح أو ضمني، أو خرق عقد أو إهمال أو مسؤولية صارمة أو بموجب أي نظرية قانونية أخرى مرتبطة بالبرنامج، على سبيل الذكر لا الحصر، أي أضرار تنشأ عن خسارة الأرباح أو خسارة العوائد أو فقد البيانات أو فقد استخدام البرنامج أو أي أجهزة مرتبطة به ووقت التعطل ووقت المستخدم، حتى إذا كان أي من هذه الأضرار قد تم التنبيه إلى إمكانية حدوثها. وفي أي حال، كل وجميع مسؤوليتهم الجمعية بموجب أي بند في اتفاقية رخصة المستخدم النهائي هذه ستقتصر على المبلغ الذي تم سداه فعليا لهذا الجهاز. وبعض السلطات القضائية لا تسمح باستثناء أو تقييد الأضرار العرضية أو التبعية، لذلك قد لا ينطبق الاستثناء أو التقييد أعلاه عليك.

اتفاقية رخصة المستخدم النهائي

مهم:

قبل استخدام هذا الجهاز، يرجى قراءة اتفاقية رخصة المستخدم النهائي هذه بعناية. باستخدام هذا الجهاز أنت تقبل شروط اتفاقية رخصة المستخدم النهائي هذه. إذا كنت لا تقبل شروط اتفاقية رخصة المستخدم النهائي هذه، فلا يجوز لك استخدام هذا الجهاز.

اتفاقية ترخيص المستخدم النهائي هذه هي اتفاقية قانونية بينك

و("SONY") Sony Home Entertainment & Sound Products Inc. تحكم اتفاقية رخصة المستخدم النهائي هذه حقوقك والتزاماتك بخصوص برنامج SONY و/أو من ترخص لهم من الأطراف الثالثة (بما في ذلك فروع SONY) وفروعههم كل بما يخصه (إجمالاً، «الموردون من الأطراف الثالثة») لهذا الجهاز (جهاز صوت SONY، هذا «الجهاز»). معاً مع أي تحديثات/ترقيات تقدمها SONY، وأي وثائق مطبوعة أو على الإنترنت أو وثائق إلكترونية أخرى لهذا البرنامج، وأي ملفات بيانات ينشئها تشغيل هذا البرنامج (إجمالاً، «البرنامج»).

على الرغم مما سبق، أي برنامج في البرنامج يكون له اتفاقية رخصة مستخدم نهائي منفصلة (بما في ذلك على سبيل المثال لا الحصر، Lesser/Library General Public License) يجب أن يطغيه اتفاقية رخصة المستخدم النهائي المنفصلة السارية هذه بدلاً من شروط رخصة المستخدم النهائي هذه إلى أقصى حد تتطلبه اتفاقية رخصة المستخدم النهائي المنفصلة هذه («برنامج مستثنى»).

رخصة البرنامج

البرنامج مرخص، وليس مباعاً. والبرنامج محمي بموجب حقوق نشر وقوانين ملكية فكرية ومعاهدات دولية أخرى.

حقوق النشر

جميع الحقوق وحقوق الملكية في البرنامج واستخدامه (على سبيل الذكر لا الحصر، أي صور وصور فوتوغرافية وصور متحركة وفيديو وصوت وموسيقى ونص و«تطبيقات صغيرة» مدمجة في البرنامج) تكون مملوكة لـ SONY أو واحد أو أكثر من الموردین من الأطراف الثالثة.

منح الرخصة

تمنحك SONY رخصة محدودة لاستخدام البرنامج فقط فيما يتعلق بهذا الجهاز فقط لاستخدامك الشخصي وليس للاستخدام التجاري. وتحتفظ SONY والأطراف الثالثة صراحة بجميع الحقوق وحقوق الملكية والانتفاع (على سبيل الذكر لا الحصر، جميع حقوق الملكية الفكرية) في البرنامج واستخدامه التي لا تمنحها اتفاقية رخصة المستخدم النهائي تحديداً لك.

الاشتراطات والقيود

لا يجوز لك نسخ أو نشر أو تكييف أو إعادة توزيع أو محاولة استخراج الكود المصدر أو الهندسة العكسية أو تعديل أو إلغاء التحويل البرمجي أو تفكيك أي من البرنامج سواء كله أو جزء منه، أو إنشاء أي أعمال مشتقة من البرنامج أو له إلا إذا كانت هذه الأعمال المشتقة يسرها عن قصد البرنامج. ولا يجوز لك تعديل أو التلاعب بأي وظيفة لإدارة الحقوق الرقمية للبرنامج. ولا يجوز لك تجاوز أو تعديل أو إبطاء أو التحايل على أي من وظائف أو حمايات البرنامج أو أي آليات مرتبطة بفعالية البرنامج. ولا يجوز لك فصل أي مكون فردي للبرنامج لاستخدامه على أكثر من جهاز واحد إلا إذا كان ذلك مرخصاً صراحة من SONY. ولا يجوز لك إزالة أو تعديل أو تغطية أو تشويه أي علامات تجارية أو إشارات عن البرنامج، ولا يجوز لك مشاركة أو توزيع أو تأجير لفترة قصيرة أو طويلة أو ترخيص من الباطن أو التنازل عن أو نقل ملكية أو بيع البرنامج. ومن الممكن مقاطعة أو وقف البرنامج أو خدمات الشبكة أو منتجات أخرى غير البرنامج التي يعتمد عليها أداء البرنامج وفقاً لتقدير الموردین (موردو البرامج أو موردو الخدمات، أو SONY). ولا تضمن SONY وهؤلاء الموردون استمرار إتاحة البرنامج أو خدمات الشبكة أو المنتجات الأخرى، أو أنها ستعمل بدون مقاطعة أو تعديل.

البرنامج ومكونات المصدر المفتوح المستنثة

على الرغم من منح الرخصة المحدودة السابقة، أنت تدرك أن البرنامج يمكن أن يتضمن برامج مستنثة. وبعض البرامج المستنثة يمكن أن تغطيها رخص برامج المصدر المفتوح («مكونات المصدر المفتوح»). مما يعني أن أي رخص برامج معتمدة كرخص مصدر مفتوح بموجب مبادرة المصدر المفتوح أو أي رخص مماثلة فعلياً، تشمل على سبيل الذكر لا الحصر أي رخصة تشترط، كشرط لتوزيع البرنامج مرخصاً بموجب هذه الرخصة، أن يجعل الموزع البرنامج متاحاً بتنسيق الكود المصدر. وإذا كان الإفصاح مطلوباً وإلى الحد الأقصى، يرجى زيارة موقع الويب www.sony.net/Products/Linux أو موقع ويب آخر لـ SONY مخصص لقائمة بمكونات المصدر المفتوح السارية المشمولة في البرنامج من وقت لآخر، والشروط والأحكام السارية التي تحكم استخدامه. وهذه الشروط والأحكام يمكن تغييرها بواسطة الطرف الثالث المناسب في أي وقت دون مسؤولية تجاهك، وإلى أقصى حد تتطلبه الرخص التي تغطي البرامج المستنثة، ستطبق شروط هذه الرخص بدلاً من اتفاقية ترخيص المستخدم النهائي هذه. وإلى حد منع شروط الرخص المنطبقة على البرامج المستنثة لأي من القيود في اتفاقية ترخيص المستخدم النهائي هذه بخصوص هذه البرامج المستنثة، لن تنطبق هذه القيود على هذه البرامج المستنثة. وإلى الحد الذي تقتضيه شروط الرخص المنطبقة على مكونات المصدر المفتوح لكي تقدم SONY عرضاً لتوفير كود مصدر فيما يتعلق بالبرامج، يكون هذا العرض بموجب ذلك قد تم.

استخدام البرنامج مع مواد محفوظة الحقوق

قد يكون البرنامج قابلاً لكي تستخدمه لعرض أو تخزين أو معالجة و/أو استخدام المحتوى الذي تنشئه أنت و/أو أطراف ثالثة. وهذا المحتوى يمكن أن يكون محمياً بحقوق نشر، وقوانين ملكية فكرية

حقوق النشر والعلامات التجارية

- تعد Apple و iPod و iPod touch و iPhone علامات تجارية لشركة Apple Inc. مسجلة في الولايات المتحدة الأمريكية وبلدان أخرى. App Store هو علامة خدمة لشركة Apple Inc.
- استخدام شعار صنع من أجل Apple يعني أنه قد تم تصميم أحد الملحقات ليتصل بشكل خاص بمنتج (منتجات) Apple التي تم تحديدها في الشعار، وأنه قد تم اعتماده من قِبل المطور ليلبي معايير أداء Apple. لا تعد Apple مسؤولة عن تشغيل هذا الجهاز أو امتثاله لمعايير السلامة والتنظيم.
- علامة N هي علامة تجارية أو علامة تجارية مسجلة تملكها NFC Forum, Inc. في الولايات المتحدة الأمريكية وبلاد أخرى.
- علامة الكلمة® BLUETOOTH والشعارات هي علامات تجارية مسجلة تملكها شركة Bluetooth SIG, Inc. واي استعمال لهذه العلامات بواسطة شركة Sony Corporation هو تحت ترخيص.
- Wi-Fi® و Wi-Fi Alliance® علامتان تجاريتان مسجلتان تملكهما Wi-Fi Alliance®.
- Wi-Fi CERTIFIED™ هي علامة تجارية تملكها Wi-Fi Alliance®.
- شعار Wi-Fi CERTIFIED™ هو علامة شهادة تملكها Wi-Fi Alliance®.
- Google Play, Google و Chromecast built-in وغيرها من العلامات والشعارات ذات الصلة هي علامات تجارية خاصة ب Google LLC.
- يخضع برنامج Spotify لتراخيص الطرف الثالث الموجودة هنا: <https://www.spotify.com/connect/third-party-licenses>
- Spotify وشعارات Spotify هي علامات تجارية لشركة Spotify Group.*
* قد لا تكون هذه الوظيفة متوفرة وفقاً للدولة والمنطقة.
- Amazon و Alexa وجميع الشعارات المرتبطة بهما هي علامات تجارية تملكها Amazon.com, Inc. أو الشركات التابعة لها.
- العلامات التجارية والأسماء التجارية الأخرى تكون لمالكها كل بما يخصه.

موديلات iPhone/iPod المتوافقة

موديلات iPhone/iPod المتوافقة تكون كالآتي. حدث iPhone/iPod بأحدث برنامج قبل استخدامه مع المنتج.

صنع من أجل:

iPhone X و iPhone 8 Plus و iPhone 8 و iPhone 7 Plus و iPhone 7 و iPhone SE و iPod touch (الجيل السادس)

ملاحظة

لا تقبل Sony تحمل المسؤولية في حالة فقدان بيانات مسجلة على iPhone/iPod أو تلفها عند استخدام جهازك iPhone/iPod مع هذا الجهاز.

كيفية استخدام Spotify Connect

استخدم هاتفك أو الكمبيوتر اللوحي أو جهاز الكمبيوتر كوحدة تحكم عن بُعد ل Spotify. انتقل إلى spotify.com/connect للتعرف على كيفية القيام بذلك.

المواصفات

قسم مكبر الصوت متوسط المدى/الصوت المتجه لأعلى

نظام مكبر الصوت

نظام مكبر الصوت كامل المدى، التعليق الصوتي

قطر مكبر الصوت (تقريباً)

46 مم × 46 / 3 مم × 46

قسم مكبر صوت النغمات منخفضة التردد

نظام مكبر الصوت

نظام مكبر صوت النغمات منخفضة التردد، عاكس الجهير

قطر مكبر الصوت (تقريباً)

70 مم × 1

قسم طرف توصيل الدخل

دخل تناظري

قسم Wi-Fi

المعايير المتوافقة

IEEE802.11 a/b/g/n

التردد اللاسلكي

نطاق 5/2.4 جيجا هرتز

قسم BLUETOOTH®

نظام الاتصال

مواصفات BLUETOOTH الإصدار 4.2

الخرج

مواصفة BLUETOOTH الفئة 1 للطاقة

نطاق الاتصال الأقصى

خط البصر تقريباً 30 متراً*1

نطاق التردد

نطاق 2.4 جيجا هرتز (2.4000 جيجا هرتز - 2.4835 جيجا هرتز)

طريقة التضمين

FHSS

ملفات تعريف BLUETOOTH المتوافقة*2

(Advanced Audio Distribution Profile) A2DP
(Audio Video Remote Control Profile) AVRCP

برنامج الترميز المدعوم*3

4*SBC و 5*AAC

مدى الإرسال (A2DP)

20 هرتز - 20,000 هرتز (تردد أخذ العينات 44.1 كيلو هرتز)

1* سيختلف النطاق الفعلي اعتماداً على عوامل مثل العوائق بين المنتج والجهاز، والحقول المغناطيسية حول فرن ميكروويف، والكهرباء الساكنة، وحساسية الاستقبال، وأداء الهوائي، ونظام التشغيل، وتطبيق البرنامج، إلخ.

2* تدل ملفات تعريف معيار BLUETOOTH على غرض اتصال BLUETOOTH بين الأجهزة.

3* برنامج الترميز: تنسيق ضغط وتحويل إشارة الصوت

4* برنامج ترميز النطاق التناوي

5* ترميز الصوت المتقدم

عام

متطلبات الطاقة

تيار مباشر 19.5 فولت

(باستخدام مهاتي AC المرفق موصل بإمداد طاقة AC بقدر 100 فولت - 240 فولت،

50 هرتز/60 هرتز)

استهلاك الطاقة

التشغيل: 55 وات

وضع الاستعداد: 0.5 وات أو أقل (وضع توفير الطاقة)

(عندما يكون وضع BLUETOOTH/استعداد الشبكة معداً على إيقاف)

وضع الاستعداد: 2 وات أو أقل*6

(عندما يكون وضع BLUETOOTH/استعداد الشبكة معداً على تشغيل)

الأبعاد*7 (تقريباً) (عرض/ارتفاع/عمق)

235 مم × 329 مم × 225 مم

الكتلة (تقريباً)

4.9 كجم

6* سيدخل المنتج تلقائياً في وضع توفير الطاقة عند عدم وجود سجل لاقتزان BLUETOOTH.

7* لا يشمل جزء البروز

التصميم والمواصفات عرضة للتغيير بدون إشعار.

عن التشغيل

قبل توصيل أجهزة أخرى، تأكد من إيقاف تشغيل المنتج وفصله من الكهرباء.

عن التنظيف

نظف المنتج بقطعة قماش ناعمة مبللة قليلاً بمحلول تنظيف لطيف. لا تستخدم أي نوع من لبادات التنظيف الحادة أو المسحوق المزيل للأوساخ أو المذيبات، مثل التتر أو البنزين أو الكحول.

إذا كان لديك أي أسئلة أو مشاكل تتعلق بهذا المنتج، يرجى الاتصال بأقرب وكيل Sony لديك.

ملاحظات حول الترخيص

يحتوي هذا المنتج على برنامج تستخدمه شركة Sony بموجب اتفاقية ترخيص مع مالك حقوق النشر الخاصة به. نحن ملزمون بالإعلان عن محتويات الاتفاقية للعملاء إذعائاً بموجب متطلب من مالك حقوق نشر البرنامج.

يُرجى الوصول إلى عنوان URL التالي وقراءة محتويات الترخيص.

<https://rd1.sony.net/help/speaker/sl/20ra/>



إشعار حول البرنامج المطبق عليه GNU GPL/LGPL

يحتوي هذا المنتج على برنامج خاضع لرخصة GNU العمومية العامة (المشار إليها هنا باسم "GPL") أو رخصة GNU العمومية العامة الصغرى (المشار إليها هنا باسم "LGPL"). وهذا يؤكد أن للعملاء الحق في الحصول على رمز المصدر للبرنامج المذكور وتعديله وإعادة توزيعه بما يتوافق مع شروط GPL أو LGPL المرفق. ورمز مصدر البرنامج المدرج أعلاه متاح على الويب.

لتنزيله، يرجى الوصول إلى عنوان URL التالي ثم تحديد اسم الطراز "SRS-RA5000".

عنوان URL: <http://oss.sony.net/Products/Linux/>

يرجى ملاحظة أن شركة Sony لا يمكنها الرد على أية استفسارات متعلقة بمحتوى رمز المصدر أو الاستجابة لأي من هذه الاستفسارات.

إخلاء المسؤولية بشأن الخدمات التي تقدمها الأطراف الخارجية

قد يتم تغيير الخدمات التي تقدمها أطراف خارجية أو تعليقها أو إنهاؤها دون إشعار مسبق. ولا تتحمل Sony أية مسؤولية تجاه هذا النوع من الحالات.

ملاحظات عن التحديث

سيتم تحديث برنامج هذا المنتج تلقائياً إلى أحدث برنامج بينما يكون متصلاً بالإنترنت عن طريق شبكة Wi-Fi®.

سيتم تقديم تحديث البرنامج من وقت لآخر عندما، مثلاً، تتاح ميزة جديدة أو يكون التحديث مطلوباً للاستخدام المستقر.

ولا يمكن تعطيل ميزة هذا التحديث التلقائي. أيضاً، لا يمكن استرجاع النسخ السابقة للبرنامج. لا تفصل الطاقة عن هذا المنتج أثناء التحديث. لا يمكن تشغيل المنتج أثناء التحديث.

لاستخدام هذا المنتج، يلزم بيئة Wi-Fi وحساب Google. وأيضاً موافقتك على شروط استخدام و/أو سياسة خصوصية Google. باستخدام هذا المنتج، أنت توافق على اتفاقية رخصة المستخدم النهائي من Sony. يتم تحديث برنامج هذا المنتج تلقائياً من وقت لآخر ولا يمكنك اختيار أو رفض تحميل هذا البرنامج التلقائي.

لا تركيب مكبر الصوت اللاسلكي في مكان محصور، مثل خزانة كتب أو خزانة أرفف مثبتة بالجدار.

للحد من خطر نشوب حريق، لا تغط فتحة تهوية مكبر الصوت اللاسلكي بصحف أو أغطية مائدة أو ستائر، إلخ. ولا تعرض مكبر الصوت اللاسلكي الى مصادر لهب مكشوف (مثلا، شموع مشتعلة).

للحد من خطر نشوب حريق أو صدمة كهربائية، لا تعرض مكبر الصوت اللاسلكي لسقوط قطرات سوائل أو رش سوائل عليه، ولا تضع أغراضا مملوءة بالسوائل، مثل المزهريات، على مكبر الصوت اللاسلكي.

لا يكون مهائئ AC مفصولا من مأخذ الطاقة طالما كان موصلا بمقبس AC، حتى إذا كان مكبر الصوت اللاسلكي نفسه في وضع إيقاف تشغيل.

نظرا لاستخدام قابس مأخذ الطاقة لمهائئ طاقة AC لفصل المهائئ من مأخذ الطاقة، وصله بمقبس AC يسهل الوصول إليه. في حالة ملاحظة أي تشوه فيه، افصله من مقبس AC فورا.

لا تضع هذا المنتج بالقرب من الأجهزة الطبية

يحتوي هذا المنتج (بما في ذلك الملحقات) على مغناطيس (مغناطيسات) والتي قد تتداخل مع أجهزة تنظيم ضربات القلب، صمامات التحويلة القابلة للبرمجة لعلاج استسقاء الرأس، أو الأجهزة الطبية الأخرى. لا تضع هذا المنتج بالقرب من الأشخاص الذين يستخدمون مثل هذه الأجهزة الطبية. استشتر طبيبك قبل استخدام هذا المنتج إذا كنت تستخدم أي من مثل هذه الأجهزة الطبية.

لاستخدام في الأماكن المغلقة فقط.

الكابلات الموصى بها

يجب استخدام كابلات وموصلات محمية ومؤرزة بشكل جيد للتوصيل بأجهزة الكمبيوتر المضيفة و/ أو الأجهزة الطرفية.

بالنسبة لمكبر الصوت اللاسلكي

توجد لوحة الاسم بالجزء السفلي من مكبر الصوت اللاسلكي.

بالنسبة لمهائئ AC

توجد ملصقات رقم الموديل والرقم المسلسل لمهائئ AC في الجزء السفلي لمهائئ AC.

تم اختبار هذا الجهاز باستخدام كابل توصيل أقل من 3 متر، وتم التأكد من مطابقة الجهاز للقيود المنصوص عليها في لائحة EMC.

التدابير الوقائية

عن السلامة

في حالة سقوط أي جسم صلب أو سائل في المنتج، افصله من الكهرباء وافحصه بواسطة فني مؤهل قبل تشغيله مرة أخرى.

عن مصادر الطاقة

- قبل تشغيل المنتج، تحقق من أن فولتية التشغيل تكون مطابقة لإمداد الطاقة المحلي لديك.
- فولتية التشغيل تكون مذكورة في لوحة الاسم في الجزء السفلي للمنتج.
- لا يكون المنتج مفصولا من مصدر طاقة AC (المأخذ الرئيسي) طالما كان موصلا بمقبس الجدار، حتى إذا كان المنتج نفسه في وضع إيقاف التشغيل.
- إذا لن تستخدم المنتج لوقت طويل، تأكد من فصله من مقبس الجدار. لفصل سلك طاقة التيار المتردد، امسك القابس نفسه، ولا تحسب السلك أبدا.

عن طريقة وضع مكبر الصوت

- لا تضع المنتج في وضع مائل.
- ضع المنتج في مكان به تهوية كافية لمنع تراكم الحرارة وإطالة عمر المنتج.
- لا تضع المنتج بالقرب من مصادر حرارة، أو في مكان معرض لضوء الشمس المباشر، أو غبار زائد، أو صدمة ميكانيكية.
- لا تضع أي شيء على المنتج ربما يتسبب في حدوث أعطال.
- كن حريصا عند وضع المنتج على أسطح تكون معالجة بطريقة خاصة (بشمع أو زيت أو ملمع، إلخ) حيث يمكن أن يؤدي ذلك إلى اتساخ أو تغيير لون السطح.

SONY®

AR

الاحتياطات/المواصفات

Wireless Speaker

Made for
iPhone | iPod



* 4 7 4 5 1 7 6 7 2 * (1)

4-745-176-72(1)

©2020 Sony Corporation Printed in Malaysia

SRS-RA5000