





EE	Seadistusjuhend	SI	Priročnik za pripravo
LV	Uzsākšanas ceļvedis	KZ	Орнату нұсқаулығы
LT	Nustatymo vadovas	SR	Vodič za podešavanje
HR	Vodič za postavljanje	HE	מדריך הגדרה


Television

# Setup Guide



Өнім атауы: Телевизор





1




1.5 N·m/1,5 N·m  
{15 kgf·cm}




2




3




4



5




6



\* Ainult teatud piirkondades/riikides/telerimudelitel. / Tikai dažos reģionos/valstīs/dažiem televizoru modeļiem. / Tik kai kuriuose regionuose/šalyse/TV modeliuose. / Odnosi se samo na određene regije/zemlje/modele TV-a. / Samo za određena područja/države/modele televizorja. / Тек шектелген аймақта/ елде/ТД үлгісі. / Samo za ograničeni region/zemlju/TV model. / באזורים/במדינות/בדגמי טלוויזיה מסוימים בלבד. /


7




**Ühendused** Lisateabe saamiseks ühenduse kohta vaadake teatmikku.  
**Savienojumi** Plašāku informāciju par savienojumiem skatiet Atsauces ceļvedī.  
**Рушіяі** Papildomas informācijas apie prijungimą žr. trumpajame vadove.  
**Прикључџи** Pogledajte Referentni vodič za dodatne informacije o priključivanju.  
**Ровеzавe** Za dodatne informacije o povezovanju glejte Referenčni priručnik.  
**Байланыстар** Қосымша қосылым ақпаратын алу үшін Анықтама нұсқаулығы бөлімін қараңыз.  
**Веze** Pogledajte Referentni vodič za dodatne informacije o povezivanju.

חיבורים ראה מדריך עיון למידע חיבור נוסף.


8




9




10



11



i



Spikker / Palīdzība / Žinynas / Pomoć /  
 Помоћ / Анықтама / Pomoć / מודע

<http://www.sony.net/tv-how-to-videos>

Näpunäited / Padomi / Patarimai / Savjeti /  
 Nasveti / Кеңестер / Saveti / טיפים