



# Setup Guide

Téléviseur  
Telesor digital a color con pantalla de cristal líquido  
Telesor



US	Setup Guide
FR	Manuel de configuration
ES	Guía de configuración
PT	Guia de Configuração

Sony Customer Support  
U.S.A.:  
<http://www.sony.com/tvsupport>  
Canada:  
<http://www.sony.ca/support>  
United States 1.800.222.SONY  
Canada 1.877.899.SONY  
Please Do Not Return the Product to the Store

Service à la clientèle Sony  
Canada:  
<http://www.sony.ca/support>  
États-Unis:  
<http://www.sony.com/tvsupport>  
Canada 1.877.899.SONY  
États-Unis 1.800.222.SONY  
Ne retournez pas le produit au magasin

Lea este manual antes de usar el producto

Centro de Asistencia de Sony  
<http://esupport.sony.com/ES/LA/>  
Llame al número telefónico que aparece en su póliza de garantía.  
Por favor no devuelva el producto a la tienda donde adquirió el producto.

Suporte ao Cliente Sony  
<https://www.sony.com.br/electronics/support>  
Por favor, não devolva o produto à loja

XBR-75X955H / 75X950H  
XBR-65X955H / 65X950H  
XBR-55X950H

**1**

SB1 SB2 IM VS CL  
75 65 55  
M4L8 M5L6 M5L14  
SN

1.5 N-m/1,5 N-m (15 kgf-cm)

75  
65  
55

**2**

\*2

1 2

**3** 75

1 2  
SN M5L14 M4L8

**65**  
**55**

1 2  
SN M5L6 M5L14

**4**

1 2 \*2

x 6

**5**

1 2  
75 55 65  
SB2 SB1


1 2  
75 55 65  
SB1 SB2

\*1 Refer Reference Guide / Reportez-vous au Manuel de référence / Consulte la Guía de referencia / Consulte o manual de instruções


\*2 Only on limited region/country/TV model. / Uniquement pour certaines régions/pays/modèles de téléviseurs. / Solo en regiones/paises limitados/Modelo de TV. / Somente para determinadas regiões/paises/modelos de TV.




6




7





8



9



10



Help / Aide / Ayuda / Ajuda



<http://www.sony.net/tv-how-to-videos>

Tips / Conseils / Consejos / Dicas