






GB	Setup Guide	RU	Руководство по установке
CS	設定指南	TH	คู่มือการติดตั้ง
CT	安裝指南	ID	Panduan Penyetelan
VN	Hướng dẫn cài đặt	AR	دليل الإعداد
FR	Guide d'installation	PR	راهنمای نصب





1




1.5 N-m/1,5 N-m  
(15 kgf-cm)




2




3




4



5



6







★1 Only on limited region/country/TV model. / 仅针对有限的地区/国家/电视机型号。 / 僅限於限定地區/國家/電視機機型。 / Chỉ có ở khu vực/quốc gia giới hạn/model TV. / Uniquement dans certains pays ou certaines régions/modèle de téléviseur. / Только в определенных регионах/странах/модели телевизора. / มีเฉพาะในบางภูมิภาค/ประเทศ/รุ่นที่จำกัด / Hanya untuk kawasan/negara/model TV tertentu. /

فقط در منطقه کشور محدود شده/منطقه شما فرق داشته باش. / في منطقة/بلد محدودة فقط/موديل التلفزيون.




7




\*2 < 14 (mm)  \*3 < 21 (mm)  \*4 3.5/3.5 (mm)  1: L / 左 / Левый 2: Video / 视频 / 視訊 / Vidéo / Видео / الفيديو / ويدئو (mm) / (毫米) / (MM) / (ملليمتر) / (میلی متر) 3: GND 4: R / 右 / Правый

8





\*5 Wood screw / 木螺丝 / 木螺絲 / Vít gỗ / Vis à bois / Деревянный винт / ឥដ្ឋ / Sekrup kayu / پیچ چوبی / برغي الخشب


9





10



11



12



Help / 帮助 / 說明 / Trợ giúp / Aide / Справка / ช่วยเหลือ / Bantuan / راهنما / المساعدة



<http://www.sony.net/tv-how-to-videos>

Tips / 技巧 / 提示 / Mẹo / Conseils / Подсказка / ការព្រឹត្តិការណ៍ / Tips / إرشادات / راهنمایی / المساعدة