



Setup Guide



5-024-559-11(1)




GB	Setup Guide	RU	Руководство по установке
CS	設定指南	TH	คู่มือการติดตั้ง
CT	安裝指南	ID	Panduan Penyetelan
VN	Hướng dẫn cài đặt	AR	دليل الإعداد
FR	Guide d'installation	PR	راهنمای نصب




1




2






3




4



5



6




*1 Only on limited region/country/TV model. / 仅针对有限的地区/国家/电视机型号。 / 僅限於限定地區/國家/電視機機型。 / Chỉ có ở khu vực/quốc gia giới hạn/model TV. / Uniquement dans certains pays ou certaines régions/modèle de téléviseur. / Только в определенных регионах/странах/модели


телевизора. / มีเฉพาะในบางภูมิภาค/ประเทศ/รุ่นที่จำหน่าย / Hanya untuk kawasan/negara/model TV tertentu. / فقط در بعضی مناطق/کشورها/مدل های تلویزیون محدود. / في منطقة/بلد محدودة فقط/موديل التلفزيون.




7





8



11



12



Help / 帮助 / 說明 / Trợ giúp /
Aide / Справка / ช่วยเหลือ / Bantuan /
راهنما / المساعدة