

# Setup Guide



5-037-351-11(1)



|    |                      |    |                          |
|----|----------------------|----|--------------------------|
| GB | Setup Guide          | RU | Руководство по установке |
| CS | 設定指南                 | TH | คู่มือการติดตั้ง         |
| CT | 安裝指南                 | ID | Panduan Penyetelan       |
| VN | Hướng dẫn cài đặt    | AR | دليل الإعداد             |
| FR | Guide d'installation | PR | راهنمای نصب              |

## BRAVIA

KD-75X80SK / 75X80K / 75X80BK  
 KD-65X81DK / 65X80K / 65X80BK  
 KD-55X81DK / 55X80K / 55X80BK



**1**


★2

★1

★2

75  
65  
55

★2 1.5 N-m/1.5 N-m (15 kgf-cm)



**3**

★2

①

②★2

**4**

65  
55

②

③

**5**

75

65

55

①

②

SB1

SB2

**6**

65

55

②

③

75

65


55

②

①

SB2

SB1




★1 Refer Reference Guide / 参阅参考指南 / 参阅参考指南 / Tham khảo Hướng dẫn Tham khảo / Consultez le Guide de référence / См. "Справочник" / โปรดอ้างอิงจากคู่มืออ้างอิง / Lihat Panduan Referensi / به راهنمای مرجع مراجعه کنید / يرجى الرجوع إلى الدليل المرجعي

★2 Only for limited region/country/model. / 仅针对有限的地区/国家/型号。 / 僅限用於有限區域/國家/型號。 / Chỉ dành cho một số khu vực/quốc gia/model. / Uniquement pour certaines régions, certains pays ou certains modèles. / Только для определенных регионов/стран/моделей. / สำหรับบางภูมิภาคประเทศรุ่นเท่านั้น / Hanya untuk kawasan/negara/model tertentu. /


فقط برای بعضی مناطق/کشورها/مدلها. / لمنطق/بلدان/موديلات محددة فقط.




8




9







10



11



12



<https://www.sony-asia.com/support>