










Setup Guide



GB	Setup Guide
FR	Guide d'installation
ES	Guía de configuración
NL	Installatiehandleiding
DE	Einrichtungshandbuch
PT	Guia de configuração
IT	Guida di installazione
SE	Startguide


DK	Installationsvejledning
FI	Asetusopas
NO	Innstillingsveiledning
PL	Przewodnik ustawień
CZ	Průvodce nastavením
SK	Sprievodca nastavením
HU	Beállítási útmutató
RO	Ghid de configurare

BG	Ръководство за настройка
GR	Οδηγός εγκατάστασης
TR	Kurulum Kılavuzu






*1 Only for limited TV model. / Uniquement pour certains modèles de téléviseur. / Solo para algunos modelos de TV. / Alleen voor bepaalde tv-modellen. / Nur für bestimmte Fernsehmodelle. / Apenas para modelo de televisor limitado. / Solo per modello TV limitato. / Endast för begränsade TV-modeller. / Kun for begrænset tv-model. / Vain tietyille TV-malleille. / Bare for begrenset TV-modell. / Wyłącznie w przypadku niektórych modeli telewizorów. / Pouze pro některé modely televizoru. / Len pre obmedzený model televízneho prijímača. / Csak korlátozott tv-modellek esetén. / Numai pentru un număr limitat de modele de televizoare. / Само за определени модели телевизори. / Μόνο για περιορισμένα μοντέλα τηλεόρασης. / Sadece sınırlı televizyon modelleri için geçerlidir.







*2 < 21 (mm) < 12 (mm)
 *3 < 7 (mm) < 1.5/1.5 (mm)
 *4 < 14 (mm)

(mm) / (MM)



Help / Aide / Ayuda / Help / Hilfe /
 Ajuda / Guida / Hjälp / Hjælp / Ohje /
 Hjälp / Pomoc / Návod / Pomocník /
 Súgó / Ajutor / Помощ / Βοήθεια /
 Yardim



<https://www.sony.eu/support>