



# Setup Guide

Өнім атауы: Теледидар

5-050-130-31(1)













|    |                       |    |                       |
|----|-----------------------|----|-----------------------|
| EE | Seadistusjuhend       | SI | Priložnik za pripravo |
| LV | Uzsākšanas ceļvedis   | KZ | Орнату нұсқаулығы     |
| LT | Nustatymo vadovas     | SR | Vodič za podešavanje  |
| HR | Vodič za postavljanje | HE | מדריך הגדרה           |



**1**

SB1 IM LR03 R03  
SB2 VS CC  
1.5 N·m/1,5 N·m (15 kgf·cm)




\*1 Vt Teatmikku / Skatiet atsauces ceļvedi / Žr. trumpaji vadovā. / Pogledajte Referentni vodič / Glejte referenčni priročnik / Анықтама нұсқаулығын қараңыз / Pogledajte Referentni vodič / עיין במדריך העיון


\*2 Ainult teatud piirkondade/riikide/mudelite jaoks. / Tikai dažiem reģioniem/valstīm/modeliem. / Tik kai kuriuose regionuose / šalyse / modeliuose. / Samo za određenu regiju/zemlju/model. / Samo za omejene regije/države/modele. / Тек шектеулі аймақтарда/елдерде/үлгілерде. / Samo za ograničen region/zemlju/model. / רק באזורים/במדינות/בדגמים מסוימים.




6




7







8



9



10




<https://www.sony.eu/support>

\*3 3.5/3.5 (mm)

- 1: L
- 2: Video / Vaizdo medžiaga / Бейне / וידאו
- 3: GND
- 4: R

\*4



\*5 < 21 (mm) < 12 (mm)

\*6 < 7 (mm) < 1.5/1.5 (mm)

\*7 < 14 (mm)

(mm) / (MM) / (מ״מ)