



7



*3 3.5/3.5 (mm) 1234
 1: L / Левый
 2: Video / Vidéo / Video / Video / Видео / Відео / Видео / Видео
 3: GND
 4: R / P / Правый


*4 < 21 (mm) < 12 (mm)

*5 < 7 (mm) < 1.5/1.5 (mm)


*6 < 14 (mm)

(mm) / (mm)



8



9



10



<http://www.sony.net/tv-how-to-videos>

Help / Aide / Ayuda / Help / Hilfe / Ajuda / Guida / Hjälp / Hjælp / Ohje / Hjelpe / Pomoc / Nárovněda / Pomocnik / Σύγο / Ajutor / Помощ / Βοήθεια / Yardım / Справка / Довідка

Tips / Conseils / Consejos / Tips / Tips / Sugestões / Guide / Tips / Tips / Ohjeita / Tips / Porady / Tipy / Tipy / Tírpek / Sfaturi / Съвети / Συμβουλές / İpuçları / Подсказка / Поради