




A**B****C**

Unusable
Inutilisable



English

Do not use a disc that has a commercially available accessory attached, such as a label or ring. (A)

Do not use an adapter to convert an 8 cm (3 1/4 in.) disc to standard size. (B)

This system cannot play the following discs: (C)

- A disc that is neither standard nor circular (e.g., card, heart, or star shape).
- A disc with paper or stickers on it.
- A disc that has the adhesive, cellophane tape, or a sticker still left on it.

Français

N'utilisez pas de disque accompagné d'un accessoire disponible dans le commerce, comme une étiquette ou un anneau. (A)

N'utilisez pas d'adaptateur pour convertir un disque de 8 cm (3 1/4 po) au format standard. (B)

Le système n'est pas en mesure de lire les disques suivants: (C)

- les disques qui ne sont pas standard ni de forme circulaire (par exemple, en forme de carte, de cœur ou d'étoile).
- les disques comportant du papier ou des autocollants.
- les disques sur lesquels il reste des traces de bande adhésive ou d'autocollant.