



A




B



C

Unusable / Inutilisable



English

Do not use a disc that has a commercially available accessory attached, such as a label or ring. **(A)**

Do not use an adapter to convert an 8 cm (3 1/4 in.) disc to standard size. **(B)**

This system cannot play the following discs: **(C)**

- A disc that is neither standard nor circular (e.g., card, heart, or star shape).
- A disc with paper or stickers on it.
- A disc that has the adhesive, cellophane tape, or a sticker still left on it.

Français

N'utilisez pas de disque accompagné d'un accessoire disponible dans le commerce, comme une étiquette ou un anneau. **(A)**

N'utilisez pas d'adaptateur pour convertir un disque de 8 cm (3 1/4 po) au format standard. **(B)**

Le système n'est pas en mesure de lire les disques suivants: **(C)**

- les disques qui ne sont pas standard ni de forme circulaire (par exemple, en forme de carte, de cœur ou d'étoile).
- les disques comportant du papier ou des autocollants.
- les disques sur lesquels il reste des traces de bande adhésive ou d'autocollant.