


About the Print Packs

To print an image, you need a color print pack containing print paper and ink ribbon. Please use a Sony optional color print pack designed for the printer. Other types of print packs may cause malfunctions.

The following print packs are available:

SVM-F40P

You can make 40 sheets of post card (4 × 6 inch/10 × 15 cm) size print. (One ink ribbon, 20-sheet-pack × 2)



SVM-F120P

You can make 120 sheets of post card (4 × 6 inch/10 × 15 cm) size print. (Three ink ribbons each for 40 prints, 20-sheet-pack × 6)

