



## Speaker installation

For best performance, we recommend speaker placement as shown.

See the Operating Instructions for more information.

For greater flexibility in the positioning of the speakers, use the optional WS-FV10D floor stand (available only in certain countries).

**A**

### Front speakers

Place on both sides of the TV equal distances apart.

**B**

### Sub woofer

Can be placed anywhere.

**C**

### Center speaker

Place on the top of or below the TV.

**D**

### Surround speakers

Place right beside or slightly behind your listening position, and a little higher than your ears.

