


Before using the recorder/使用錄放隨身聽之前

Slide the BUILT-IN BATTERY switch at the rear of the recorder to ON.

將錄放隨身聽背面的BUILT-IN BATTERY開關滑至ON。



Note on charging the built-in rechargeable battery

for the first time/首次給內建充電式電池充電的注意事項

The built-in rechargeable battery comes charged to some extent when shipping of the MZ-N10. For this reason, the charging time may be faster than normal the first time you charge the battery. In this case, remove the recorder from the USB cradle, start playback and check the battery condition on the display window.

 : The battery level is sufficient.

MZ-N10出廠時，內建充電式電池已經充有一定的電量。因此，首次給電池充電所用的時間可能比平時短。發生這種情況時，請從USB底座上取下錄放隨身聽，進行播放並檢查顯示窗中的電池狀況。

 : 電池電量充足。