SONY®

468955222 (1)
4-689-552-**22**(1)

Sound Bar

Startup Guide

HT-CT290/HT-CT291

Subwoofer
Bar Speaker

Supplied accessories

Remote control (1) R03 (size AAA) batteries (2) Optical digital cable (1)

WALL MOUNT TEMPLATE (1) Speaker pads for the subwoofer (4)
Refer to the supplied Operating Instructions on installing the subwoofer horizontally.

To insert batteries

To mount the Bar Speaker on a wall
Refer to the supplied Operating Instructions.

---

1 Connecting with a TV

TV HDMI input jack with "ARC" label

HDMI OUT
TV (ARC)

High Speed
HDMI cable (not supplied)

TV
HDMI IN
ARC

TV HDMI input jack without "ARC" label

HDMI OUT
TV (ARC)

TV IN
OPTICAL

High Speed
HDMI cable (not supplied)

Optical digital cable (supplied)

TV
HDMI IN   OPTICAL OUT

Note
• Make sure that the HDMI cable is firmly inserted.
• To view the USB content list on the TV screen, make sure you connect the system to the TV using HDMI cable.

Connecting other devices with the TV (optional)

Sound from other devices can be output to the system through the TV .
To connect other devices with your TV, refer to the operating instructions of your TV.

Bar Speaker

Other devices (Blu-ray Disc player, etc.)

TV

---

2 Turning on the system

❶   ❷   ❸

Power

Input indicator   Power indicator (green)

TV

❶ Turn on the TV.
❷ Connect the AC power cords (mains lead).
❸ Press ⏻ (power).
The input indicator lights up.
Confirm that the power indicator of the subwoofer lights up in green.
If not, refer to "Subwoofer wireless sound" of "Troubleshooting" in the supplied Operating Instructions.

---

3 Listening to the sound

INPUT

TV

TV → BT → USB

◁ +/–

SW ◁ +/–

Press INPUT repeatedly until the input indicator for the device you want lights up. Then, press ◁ +/– repeatedly to adjust the volume of the system and press SW ◁ +/– repeatedly to adjust the subwoofer volume.
To listen to TV audio, select the program you want using the TV remote control.

Setup completed! Enjoy! | **Please refer to the supplied Operating Instructions about the sound effects, and other functions.**

Operating Instructions

Listening to music from a BLUETOOTH device (Pairing and connecting)

❁ (pairing)

BLUETOOTH device

BLUETOOTH indicator (blue)

❶ Place the BLUETOOTH device within 1 meter from the Bar Speaker.
❷ Press ❁ (pairing).
BLUETOOTH indicator (blue) flashes quickly (▬).
❸ Turn on BLUETOOTH function and select "HT-CT290/291" on the BLUETOOTH device.
❹ When the BLUETOOTH connection is established, the BLUETOOTH indicator (blue) lights up (▬).
❺ Start playback on the BLUETOOTH device.
❻ Adjust the volume.

Refer to the supplied Operating Instructions for details on other BLUETOOTH settings.